

Part no	remarks	Alternativ nr.	price £	description	qty:
	12304		ask	VALVE	1
	37325		ask	BOX	5
	85349		ask	SWIVEL UNION PLUG	1
	93322		ask	RING	3
	190546	2/190546	75.21	MANIFOLD	2
	191074		212.60	FUEL PUMP AV	2
	191074		212.60	FUEL PUMP AV	2
	199016		ask	PIPE	2
	199731		78.57	CONNECTING ROD	1
	205374		ask	LEVER	2
	205394		1.13	LEVER	1
	206791		1.50	CYLINDER SHIM	4
	206791		1.50	CYLINDER SHIM	4
	252426		1.10	NOZZLE WASHER	2
	252426		1.10	NOZZLE WASHER	2
	257297		65.07	PISTON ASSY.	2
	257762		1.28	WASHER	2
	265495		1.54	CYLINDER SHIM	4
	265495		1.54	CYLINDER SHIM	4
	266040		7.59	WASHER	9
	266040		0.18	COLLAR	9
	266360		33.46	PUSH ROD	4
	266360		33.46	PUSH ROD	4
	266382		4.60	CAMSHAFT BEARING A	1
	266382		4.60	CAMSHAFT BEARING A	1
	266405		1.51	CYL HEAD GASKET	3
	266405		1.51	CYL HEAD GASKET	3
	267481		ask	FILTER	30
	268135		ask	OIL SEAL	2
	268189		2.44	SPRING	2
	268757		ask	AIR FILTER	7
	269251		ask	LOCK	3
	272362		5.53	PLUG	1
	272362		5.53	PLUG	1
	289185		3.73	AIR CLEANER ELEMENT	2
	294159		91.79	SILENCER	2
	330308		2.11	CYLINDER SHIM	1
	392954		11.34	VALVE GUIDE PJ/PH	4
	392954		11.34	VALVE GUIDE PJ/PH	4
	1524088		ask	?	5
000-07010/7			ask	BEARING	5
001-00007			8.23	BALL BEARING	2
001-00008			9.43	BALL BEARING	2
001-00018C			ask	CONNECTING ROD	3
001-00026/c			ask	SHAFT	3
001-00031			ask	PINION	3
001-00032			ask	ROCKER ARM	4
001-00033			ask	BUSH	15
001-00091			ask	JOINT	9
001-00155			ask	VALVE	8
001-00178			ask	STARTING HANDLE	3
001-00301			80.00	SILENCER	1
001-00323			ask	SPRING	10
001-00802			ask	FLANGE	1
001-01062			ask	CYLINDER HEAD	1

001-01327		5.61 TAP	6
001-04301	ask	BUSH	2
002-00125		10.64 PIN	2
002-00126		1.07 SPRING	5
002-00219/220	ask	BEARING	2
002-00452		0.72 SPRING	8
002-00507		4.19 SWIVEL UNION	6
002-04006	ask	CONROD BOLT	6
003-00140		14.99 DRAIN PLUG	1
003-00155		16.74 BUSH	2
003-00166		119.24 GEARWHEEL	1
003-00174		7.16 SPRING	1
003-00177		7.32 ADJUSTING NUT	3
003-00185		159.67 PINION	1
003-00306		0.50 WASHER	6
003-00307		1.15 JOINT	33
003-00309		0.51 JOINT	412
003-00329		48.33 CAM	3
003-00349	ask	FLANGE	6
003-00362		10.25 CLUTCH PIN	2
003-00363		0.49 SPRING	1
003-00376		0.92 PIN	8
003-00381	ask	VALVE	8
003-00418	ask	HOUSING	3
003-00419	ask	CYLINDER HEAD	3
003-00441	ask	NIPPLE	3
003-00458	ask	SPRING	7
003-00493		55.02 VALVE TAPPET	3
003-00664		1.57 FELT WASHER	4
004-00197		0.50 WASHER	4
007-00039	ask	WASHER	2
007-00406		0.48 JOINT	11
007-00407		1.52 PLUG	15
007-00419		2.93 JOINT	3
007-00425		0.72 STEEL BALL	10
008-00104	ask	PINION	1
008-01073	ask	PIPE	4
008-02004		101.21 STEEL BALL	5
008-02004/119		108.30 BEARING 8/1	5
008-02019		92.87 BEARING 8/1	2
008-02029		56.08 IDLER SPINDLE	4
008-02039(098)		333.57 FUEL PUMP 8/1	2
008-02094		0.27 JOINT	12
008-02102		10.72 SPLASH TRAY	3
008-02134	ask	OIL OPIPE	2
008-02169		198.20 BEARING HOUSING	1
008-02175		28.03 PIPE	3
008-02178		8.36 OIL SEAL	1
008-02187		21.66 OIL PIPE	3
008-03019		3.85 PLUG	24
008-03048	ask	PIPE	10
008-03051		14.70 GASKET	7
008-03071	ask	PIPE	16
008-03072	ask	MANIFOLD	1
008-03076	ask	BOLT	2
008-03116	ask	PIPE	1

008-03178		24.25 PLUG	6
008-03179		22.07 PLUG	1
008-04018/010	ask	BEARING	1
008-04019/010	ask	BEARING	2
008-05024	ask	STARTING HANDLE	1
008-05135	ask	FLYWHEEL	1
008-06106		25.25 GOVERNOR WEIGHT	6
008-07103		5.03 SCREW	6
008-07111	ask	PIPE	1
008-08055	ask	SHAFT	6
008-08138		0.78 SPRING	2
008-24162		24.36 OVERLOAD STOP	4
008-24236	ask	CYLINDER	1
008-24249		4.35 DIPPER	1
008-30001	ask	CRANKCASE	1
008-30004		10.74 JOINT	4
008-30005		298.75 CYLINDER BARREL	1
008-30031		7.54 GASKET	6
008-30046		32.90 FUEL PIPE	2
008-30050	ask	BEARING HOUSING	1
008-30060		33.83 FUEL PIPE	15
008-30172		1.73 GASKET	3
008-41819/010	ask	BEARING	1
009-00524/b	ask	STARTING HANDLE	2
009-02071		2.93 JOINT	6
009-02180		25.41 BOLT	1
009-03036	009-00336	101.28 MANIFOLD	1
009-03158	ask	PIPE	8
009-05013	ask	BEARING	4
009-05014	ask	BEARING	4
009-05102/C		920.61 UNION NUT	1
010-00586	ask	PULLEY	2
010-02008-1	ask	COVER	5
010-02009		2.14 FELT RING	55
010-02010	ask	BRACKET	4
010-02012		1.73 SHIM	1
010-02015		0.17 CIRCLIP	6
010-02016/002	ask	PLATE	3
010-02024		0.35 JOINT	17
010-02033	ask	COVER	4
010-02034		1.07 FELT WASHER	4
010-02046		3.89 VALVE	3
010-02047		4.26 SCREW	2
010-02050		0.65 SPRING	5
010-02051		10.31 PIPE	2
010-02056		15.15 VALVE TAPPET	8
010-02059		0.64 JOINT	300
010-02060		1.21 JOINT	3
010-02061/001		0.34 JOINT	9
010-02062/001		0.25 JOINT	3
010-02063		0.25 JOINT	4
010-02064/001	010-02064	0.88 JOINT	4
010-02064/001		0.14 JOINT	4
010-02065		0.07 JOINT	12
010-02067/001		0.04 JOINT	5
010-02089		2.66 SWIVEL UNION PLUG	4

010-02094	14.56	FLANGE	1
010-02096	ask	SHAFT	3
010-02103	5.32	SHAFT	1
010-02105	2.54	SHAFT	2
010-02110	0.79	DOWEL	17
010-02112	0.20	JOINT	27
010-02114	0.06	JOINT	3
010-02115	0.07	JOINT	4
010-02116	1.26	RUBBER RING	205
010-02157	ask	PIN	9
010-02160	20.93	COVER	2
010-02190	1.13	PIN	7
010-02191	1.11	BOLT	7
010-02192	2.59	STOP	5
010-02231	1.73	PIN	3
010-02263	ask	SHAFT	1
010-02322	37.82	FILTER COVER	2
010-02335	0.46	JOINT	5
010-02338	0.06	JOINT	50
010-02339	0.20	JOINT	298
010-02408	264.93	MAIN BEARING	1
010-02408/010	252.75	BEARING	2
010-02408/020	264.76	MAIN BEARING	1
010-02408/060	174.04	MAIN BEARING	1
010-02409	186.99	MAIN BEARING	2
010-03003	6.83	CHAMBER	11
010-03004	ask	PLUG	6
010-03004/001	13.33	CHAMBER	12
010-03015	12.98	STRIKING PIN	3
010-03020	14.88	PUSH ROD	12
010-03038	2.89	RUBBER RING	9
010-03062	ask	JOINT	6
010-03090	18.27	MAIN PLUG	1
010-03130	9.36	VALVE SPRING CARRIER	1
010-03133	ask	FLANGE	3
010-03143	3.94	FELT ELEMENT	5
010-03180	3.65	VALVE 8/1	31
010-03183	ask	PIPE	2
010-04003	21.17	GUDGEON PIN	77
010-04003	25.53	GUDGEON PIN	77
010-04007/019	16.59	CON ROD BUSH	17
010-04008/010	77.50	BEARING	3
010-04008/060	77.50	BEARING	1
010-04018	ask	PISTON RING	150
010-04038/010	124.90	BEARING	2
010-04039/010	124.90	BEARING	2
010-04063	ask	PISTON RING	166
010-04221	ask	OIL RING	13
010-05002	78.86	PINION	1
010-05031	ask	NUT	2
010-05040	4.81	WASHER	3
010-05044	ask	BOLT	22
010-05086	ask	PULLEY	2
010-06001	ask	CAMSHAFT	1
010-06002	31.82	CAMSHAFT BUSH	2
010-06003	32.29	BUSH	1

010-06005		2.35 KEY	1
010-06006		2.76 PLATE	2
010-06013		2.23 SHAFT	7
010-06034	ask	PINION	3
010-06035		1.27 KEY	10
010-06036	ask	LEVER	1
010-06039/001		16.34 BOLT	2
010-06040		16.69 BRACKET	1
010-06051		2.12 BALL BEARING	2
010-06059		1.63 SPRING	1
010-06064		0.72 WASHER	13
010-06066		0.60 WASHER	4
010-06067		0.49 SPRING	12
010-06068		2.63 PIN	2
010-06070		50.51 GOVERNOR WEIGHT	1
010-06071		0.17 PIN	8
010-06072		0.19 PIN	8
010-07050		44.81 STOP VALVE	2
010-08089		238.07 COUPLING DISC	1
010-08127		22.42 BOLT	39
010-08128		3.65 DISTANCE PIECE	15
010-08128		3.65 DISTANCE PIECE	15
010-08129		5.97 BOLT	1
010-08130		8.16 DISTANCE PIECE	30
010-09117		3.08 SCREW	5
010-13122	ask	BRACKET	2
010-13130		52.63 CHAIN	4
010-13465	ask	PIPE	1
010-19047	ask	GAUGE	2
010-19725	ask	NUT	4
010-19728		11.22 SEAT	11
010-19732		1.93 WASHER	1
010-20355		5.74 SPRING	1
010-54000	ask	PIPE	1
011-00051/c	ask	COVER	1
011-01982	ask	FLANGE	1
011-02039/6	exchange	ask FUEL PUMP	1
011-02055		6.39 SCREW	4
011-02364	ask	PIPE	1
011-02365	ask	PIPE	1
011-02371	ask	PIPE	3
011-02407	ask	COVER	1
011-02459		15.23 STUD	15
011-02469		13.86 BRACKET	4
011-02474	ask	PINION	1
011-03029		100.61 MANIFOLD	3
011-03063	ask	PIPE	2
011-03115		84.25 MANIFOLD	2
011-03183		21.10 FUEL PIPE	3
011-03291		0.56 JOINT	4
011-03294		2.80 WASHER	3
011-03298		18.75 ROCKER SHAFT	14
011-03299		16.72 PIPE	20
011-03303		2.35 CHAMBER	4
011-03305		13.44 CC PLUG	57
011-03306		42.24 CHAMBER	3

011-06010	ask	CAMSHAFT	1
011-06018		8.77 BUSH	4
011-06032		1.84 LEVER	9
011-06132	ask	PINION	1
011-06192	ask	PIN	2
011-07117	ask	DIPSTICK	1
011-09845	ask	SHAFT	1
011-13062		96.26 SILENCER	8
011-13202	ask	MANIFOLD	1
011-13251		22.53 NIPPLE	29
011-13277	ask	PIPE	1
011-13280	ask	PUMP	1
011-13282	ask	BRACKET	3
011-13287		13.63 BUSH	1
011-13288		16.69 SHAFT	1
011-13294	ask	OIL OPIPE	3
011-13300	ask	COVER	1
011-13303	ask	HOUSING	1
011-13307	ask	PINION	6
011-13308		50.74 SHAFT	2
011-13310	ask	BUSH	1
011-13313	ask	PINION	3
011-13315/c	ask	VALVE	7
011-13319		6.29 WASHER	1
011-13335	ask	SCREW	10
011-13340		7.72 VALVE	20
011-13343		8.27 BOLT	5
011-13344		6.12 BOLT	5
011-13369	ask	COVER	1
011-13372		39.33 SPACER	20
011-13376	ask	HOUSING	15
011-13376	ask	BUSH	15
011-13408	ask	SHAFT	1
011-13421	ask	VALVE	1
011-13422	ask	JOINT	3
011-13439		3.80 PLUG	1
011-13441		0.75 SPRING	1
011-13448		78.14 SHAFT	2
011-13460	ask	TOOL	4
011-13469	ask	COVER	2
011-13727	ask	PULLEY	1
011-13875		17.90 SILENCER COVER	4
011-13888	ask	FILTER	1
011-13900	ask	PIPE	1
011-13920/S	ask	CRANKCASE	2
011-13957		4.43 SPRING	4
011-14568	ask	PIPE	1
011-14578	ask	PIPE	2
011-15288		6.91 WASHER	8
011-15449	ask	FLANGE	3
011-15450	ask	SHAFT	4
011-15469	ask	PIPE	2
011-15499	ask	PIPE	1
011-15501		0.24 JOINT	5
011-15530		78.50 PINION	10
011-15543		71.51 SHAFT	7

011-15899	ask	EXTENSION SHAFT	1
011-19245	ask	OIL OPIPE	2
011-19782		43.66 PAWL	3
011-19845	ask	SHAFT	1
011-19846		8.99 WASHER	1
011-19847		0.58 SPRING	1
011-20449	ask	PIPE	2
011-21561		75.82 SILENCER	1
011-22204		38.30 PIPE	1
011-22346	ask	TAP	1
011-23013		3.47 SPRING	8
011-23014		3.62 SHAFT	10
011-23023	ask	SHAFT	4
011-23024	ask	SHAFT	4
011-23025		3.38 CLIPS	14
011-30124	ask	JOINT	79
012-00366	ask	MANIFOLD	1
012-00517/18	ask	BEARIING HOUSING	1
012-02068		3.75 JOINT	1
012-02071		14.90 BOLT	1
012-02252	ask	OIL OPIPE	3
012-02259		0.58 WASHER	6
012-02359		70.25 BEARING	6
012-02359/020		70.25 BEARING	2
012-02402	ask	COVER	1
012-02454	ask	COVER	3
012-02469		5.15 BRACKET	6
012-02475		19.41 PIPE	13
012-03029		139.62 MANIFOLD	1
012-03115		91.91 EXH.MANIFOLD	2
012-03129		9.27 VALVE SPRING 8/1	34
012-03183		36.35 LEAK-OFF PIPE	2
012-03216		197.23 MANIFOLD	1
012-03219		1.84 VALVE SPRING 8/1	24
012-03220		3.14 VALVE SPRING	26
012-03234		24.13 MANIFOLD	2
012-05193	ask	BEARIING HOUSING	1
012-05196	ask	BEARIING HOUSING	6
012-05610	ask	CRANKSHAFT	1
012-08347	ask	DYNAMO	1
012-08351	ask	BOX	1
012-08355		25.26 AMMETER	18
012-08364		36.88 PUSH BUTTON	59
012-08364		36.88 PUSH BUTTON	59
012-13310	ask	BUSH	4
012-13470	ask	MANIFOLD	2
012-13900	ask	PIPE	1
012-13902	ask	PIPE	1
012-13952	ask	PIPE	1
012-13954		29.73 PIPE	5
012-13956		45.87 PIPE	1
012-14484	ask	PULLEY	1
012-15483		2.53 JOINT	2
012-16097	ask	FLANGE	3
012-16186	ask	COVER	1
012-16305	ask	BEND	1

012-19165	20.93 VALVE	2
012-19172	3.57 SPRING	3
012-19258	12.43 NIPPLE	1
012-21917	30.96 TAP	1
012-22471	ask BELT	1
012-23024	ask SHAFT	5
012-23145	ask CRANKSHAFT	1
013-00033	ask STUD	4
013-01617	ask MANIFOLD	1
013-01683	ask FLANGE	4
013-02359/010	118.30 BEARING	1
013-02359/020	118.30 BEARING	1
013-02469	3.95 BRACKET	2
013-02475	30.14 PIPE	7
013-03047	109.59 MANIFOLD	3
013-03116	30.96 EXPANSION PIECE	1
013-06732	ask O-RING	45
013-08088	1.98 SCREW	3
013-13585	ask MANIFOLD	1
013-13885	78.13 MANIFOLD	1
013-13886	153.41 MANIFOLD	1
013-13933	ask MANIFOLD	1
013-14144	95.80 BRACKET	3
013-14152	ask COVER	2
013-14153	0.26 JOINT	10
013-14166	0.28 JOINT	14
013-14167	5.97 JOINT	16
013-14189	7.01 PIN	1
013-14190	1.01 SPRING	3
013-14191	5.97 SCREW	6
013-14192	15.26 STUD	2
013-14194	114.25 FLANGE	1
013-14206	25.52 OIL PIPE	2
013-14319	ask PLATE	2
013-14411	41.50 HOUSING	2
013-14416	4.57 NUT	1
013-14417	2.16 SPRING	1
013-14418	0.93 SPRING	1
013-14419	ask CYL.HEAD COVER	4
013-14420	58.90 CYL.HEAD COVER	3
013-14450	121.36 MANIFOLD	5
013-14506	ask PIPE	3
013-14550	13.47 PIN	3
013-15269	ask PIPE	2
013-15270	ask PIPE	2
013-15488	86.32 RATCHET HUB	3
013-15495	59.09 PIPE	1
013-15498	17.02 PIPE	2
013-15625	95.17 PINION	1
013-16017	ask THERMOSTAT HOUSING	4
013-16248	ask WASHER	6
013-16248	ask STUD	6
013-16248	ask O-RING	6
013-16248	ask COVER	6
013-16248	ask COVER	6
013-16248	ask COOLER	6

013-16410	ask	PIPE	1
013-16514		26.26 OIL OPIPE	2
013-16553	ask	OIL OPIPE	1
013-16554	ask	OIL OPIPE	1
013-19094		11.18 NIPPLE	1
013-19098		1.37 WASHER	5
013-19099		5.66 NUT	2
013-19219	ask	FLYWHEEL	1
013-19245	ask	PIPE	4
013-19925	ask	SHAFT	1
013-20115	ask	THERMOSTAT HOUSING	1
013-20115C	ask	DIPSTICK	2
013-20595	ask	FILTER	2
013-21771	ask	BOLT	6
013-21778		0.83 WASHER	13
013-21787		1.63 WASHER	12
013-22038		70.61 FLANGE	1
013-22039		56.77 FLANGE	1
013-22042		111.40 YOKE	3
013-22053		1.37 SPRING	8
013-22155	ask	BRACKET	1
013-22351	ask	PLUG	4
013-23024	ask	SHAFT	4
013-23941		32.34 EXHAUST FLANGE	1
013-23942		6.63 JOINT	10
014-02342	ask	PINION	1
015-00200	ask	SHAFT	1
018-02003	ask	MANIFOLD	4
018-14206	ask	OIL OPIPE	1
018-27053	ask	PIPE	1
021-00114		0.66 BUSH	8
021-00151		0.58 FELT RING	2
021-00153		1.50 PLUG	16
021-04315	ask	AIR FILTER	1
023-00145	ask	BUSH	1
023-00161	ask	HOUSING	1
023-00215	ask	GUDGEON PIN	7
023-00216	ask	CIRCLIP	63
023-00219	ask	CONNECTING ROD	4
023-00221	ask	BUSH	1
023-00223/010	ask	BEARING	9
023-00227	ask	CAMSHAFT	3
023-00241	ask	PINION	2
023-00256	ask	PUSH ROD	6
023-00257	ask	VALVE GUIDE	1
023-00258	ask	VALVE GUIDE	1
023-00260	ask	GUIDE	8
023-00265	ask	VALVE	2
023-00350	ask	LEVER	3
023-00360	ask	PISTON	8
023-00361		0.60 JOINT	9
023-00362		1.21 JOINT	7
023-00370	ask	ROCKER ARM	3
023-00404		0.09 JOINT	9
023-00471		17.73 SWIVEL UNION	9
023-00472		18.01 SWIVEL UNION	3

023-00475	ask	SPRING	5
023-00539	ask	PINION	5
023-00540	ask	PINION	1
023-00541	ask	PINION	1
023-00606	ask	PINION	5
023-00752	ask	BUSH	2
023-00789	ask	PIPE	2
023-01169	ask	NUT	5
023-01264	ask	PLATE	6
023-01278	ask	TAP	6
023-01281	ask	COVER	3
023-01503		0.29 NUT	7
023-01687	ask	JOINT	1
023-01824	ask	PLATE	12
023-02090		10.62 NUT	6
023-02216		61.95 PINION	1
023-02217		16.34 PAWL	2
023-02218		1.46 BUSH	6
023-02220	ask	WASHER	3
023-02278		0.30 JOINT	12
023-02279		24.70 WICK CONTAINER	1
023-02289		0.65 CLIPS	1
023-02291	ask	PLUG	3
023-02308		22.90 PLUG	1
023-02407		0.65 WASHER	12
023-02509		4.12 SEAL	7
023-02509		6.80 OIL SEAL	7
023-02516	ask	BRACKET	1
023-02589		1.58 KEY	2
023-02633		26.58 NIPPLE	1
023-03113		0.52 RING	4
023-03119		0.37 JOINT	8
023-03120		212.62 PLATE	1
023-03121		3.55 KEY	2
023-03123		11.82 PIN	2
023-03126		218.75 RING	2
023-03127		12.43 SCREW	5
023-03128		20.16 LEVER	7
023-03129		12.78 LEVER	8
023-03130		2.09 SHAFT	33
023-03131		56.13 BUSH	1
023-03132		124.59 YOKE	2
023-03133		26.98 YOKE	6
023-03134		115.44 LEVER	3
023-03135		81.42 OPERATING SHAFT	1
023-03156	ask	STARTING HANDLE	1
023-03207	ask	JOINT	12
023-03212		8.04 STRAINER	2
023-03306	ask	SHAFT	3
023-03410		3.73 RELEASE SPRING	12
023-03411	ask	LEVER	2
023-03423	ask	STUD	6
023-03773	ask	JOINT	5
023-04219	ask	TANK	1
023-04301		15.63 COVER	1
023-05026	ask	JOINT	22

023-05517		144.04	PUMP HOUSING	1
023-11819		ask	PINION	1
023-33651		ask	FLANGE	1
024-00227		ask	CAMSHAFT	3
024-00388		ask	SILENCER	1
024-00400		ask	JOINT	5
024-00865		ask	PIPE	3
024-01626		ask	PIECE	4
024-02367		ask	PIPE	3
024-02509		ask	OIL SEAL	2
024-04330		ask	PIPE	1
024-05140		ask	T.PIECE	2
024-05170		ask	MANIFOLD	1
024-05187		ask	FLANGE	4
024-05268/6	second hand	28.80	STARTER RING	1
024-05394		3.33	SPACER	1
024-05479		ask	FUEL PIPE	1
024-05645		ask	AIR FILTER	4
025-00125		ask	PULLEY	2
026-00081		14.51	NUT	5
026-00098		13.21	ADJUSTING SCREW	6
027-00002		2.38	NUT	10
027-00003		2.89	NUT	15
027-00004		0.54	NUT	20
027-00005		0.38	NUT	3
027-00006		0.49	NUT	14
027-00007		1.83	NUT	30
027-00008		0.20	NUT	50
027-00009		1.14	PIECE	20
027-00015/001		1.62	NUT	10
027-00017		1.96	NUT	20
027-00022		0.27	NUT	25
027-00026		1.43	NUT	1
027-00035		4.74	STUD	4
027-00036		0.69	STUD	50
027-00037		0.46	STUD	100
027-00038		0.60	BOLT	16
027-00045		0.90	STUD	1
027-00048		34.75	SCREW	97
027-00050		0.62	STUD	15
027-00055		0.25	STUD	15
027-00057		5.49	STUD	2
027-00063		2.68	SCREW	20
027-00066		0.48	BOLT	50
027-00083		0.66	WASHER	4
027-00085		0.60	WASHER	20
027-00103		0.38	KEY	8
027-00105		0.98	KEY	6
027-00107		0.48	KEY	2
027-00117		0.69	WASHER	5
027-00121		0.25	SPLIT PIN	6
027-00122		0.47	SPLIT PIN	35
027-00150		0.25	SCREW	8
027-00181		11.70	BEND	1
027-00184		0.25	WASHER	10
027-00203		9.92	SCREW	11

027-00214	1.43 STUD	10
027-00217	0.78 STUD	8
027-00235	0.16 NUT	6
027-00237	0.52 PIN	20
027-00238	0.14 PIN	20
027-00241	0.29 NUT	25
027-00245	4.47 BOLT	9
027-00305	ask BOLT	20
027-00323	2.81 SPANNER	1
027-00352	0.64 KEY	2
027-00353	1.58 KEY	11
027-00367	0.78 TAPER PIN	9
027-00393	0.25 SPRING WASHER	936
027-00394	0.25 SPRING WASHER	8
027-00395	0.25 WASHER	51
027-00396	0.21 WASHER	4
027-00399	9.13 SPANNER	5
027-00403	1.77 KEY	23
027-00413	0.25 SPRING WASHER	84
027-00418	0.09 SPRING WASHER	20
027-00440	10.55 HOSE	1
027-00441	3.44 KEY	1
027-00451	0.25 SPRING WASHER	959
027-00454	0.19 PIN	30
027-00463	1.65 PIECE	4
027-00483	0.06 SCREW	10
027-00496	ask SCREW	20
027-00512	ask STUD	8
027-00517	1.36 SPRING WASHER	5
027-00518	2.44 KEY	2
027-00536	1.42 STUD	1
027-00543	0.18 SCREW	14
027-00545	0.25 WASHER	38
027-00551	0.18 WASHER	6
027-00565	ask SCREW	16
027-00566	0.24 KEY	17
027-00567	2.69 NUT	7
027-00583	0.24 NUT	25
027-00591	1.27 PIN	4
027-00606	10.73 GREASER	10
027-00607	0.65 SCREW	15
027-00613	4.37 PIN	17
027-00617	0.55 PIN	5
027-00618	0.25 WASHER	8
027-00630	0.38 TAPER PIN	20
027-00640	2.83 BOLT	1
027-00647	0.73 SCREW	12
027-00648	1.90 STUD	4
027-00652	ask SCREW	15
027-00655	0.87 DOWEL	30
027-00668	1.28 STUD	15
027-00672	2.68 STUD	1
027-00687	2.49 WING NUT	15
027-00689	7.10 LOCK NUT	4
027-00698	0.25 WASHER	10
027-00699	0.25 SPRING	15

027-00703		2.68 NUT	5
027-00707		0.37 DOWEL	16
027-00708		1.58 NUT	3
027-00714		0.71 LOCK NUT	4
027-00717		0.25 SPRING WASHER	35
027-00720		0.19 PIN	20
027-00733		0.95 HOSE	7
027-00736		1.90 STUD	20
027-00739		3.15 SCREW	25
027-00757		4.24 EXPANSION PLUG	15
027-00758	ask	PLUG	13
027-00768		2.73 EXPANSION PLUG	3
027-00769		2.73 STUD	20
027-00785		1.13 KEY	4
027-00787		2.93 BALL	26
027-00793	ask	SCREW	20
027-00794		3.74 NUT	1
027-00795		0.32 WASHER	12
027-00796		2.46 NUT	9
027-00800		0.75 PIN	8
027-00810		0.23 PIN	8
027-00811		0.96 PIN	1
027-00861		11.19 STUD	8
027-00862		4.16 STUD	2
027-00888		0.24 SCREW	1
027-00889		0.32 SCREW	20
027-00890		0.76 SCREW	25
027-00894		0.53 BOLT	26
027-00901		0.17 SCREW	12
027-00902		0.62 SCREW	20
027-00903		0.56 NUT	30
027-00904		0.41 NUT	3
027-00909		0.06 SPLIT PIN	20
027-00912		0.03 SPLIT PIN	15
027-00913		0.50 SPLIT PIN	11
027-00956	ask	BOLT	6
027-00957		0.25 SPLIT PIN	10
027-00981		0.04 SPLIT PIN	48
027-00984		0.25 WASHER	15
027-00988		0.53 STUD	8
027-01034		0.62 WASHER	8
027-01035		0.56 WASHER	10
027-01087		0.23 SCREW	11
027-01094		0.54 FELT RING	4
027-01117		0.14 BOLT	12
027-01126		7.10 KEY	1
027-01127		0.14 SCREW	20
027-01167		0.43 SETSCREW	50
027-01171	ask	KEY	8
027-01184		15.03 REDUCING BUSH	13
027-01185	ask	BOLT	7
027-01186		5.23 STUD	10
027-01190		3.24 STUD	47
027-01192		1.33 NUT	33
027-01224		2.34 PIN	15
027-01225	ask	BOLT	20

027-01227		3.57 HOSE	3
027-01229	ask	NUT	9
027-01269		0.33 STUD	11
027-0128	ask	STUD	13
027-01282		2.48 STUD	1
027-01285		0.14 SCREW	8
027-01288	ask	STUD	14
027-01289	ask	STUD	30
027-01305		1.15 NUT	4
027-01315		6.21 STUD	25
027-01316		3.26 NUT	9
027-01344	ask	STUD	50
027-01345	ask	STUD	19
027-01347	ask	STUD	30
027-01364	ask	BOLT	4
027-01367		2.49 WASHER	1
027-01368		1.81 WASHER	20
027-01374		0.44 BOLT	9
027-01388		2.25 NUT	9
027-01407		0.08 SPLIT PIN	2
027-01430		1.83 DOWEL	24
027-01434		1.60 DOWEL	5
027-01442		0.44 TAPER PIN	20
027-01451	ask	NUT	20
027-01453		5.28 NUT	15
027-01477		0.71 WASHER	20
027-01496		5.79 PIN	6
027-01508		0.33 FELT RING	8
027-01511	ask	STUD	12
027-01519		4.96 STUD	42
027-01524		1.82 SCREW	2
027-01543		2.06 SWIVEL UNION PLUG	5
027-01544	ask	STUD	25
027-01549		1.17 PLUG	40
027-01552		8.22 SCREW	20
027-01583	ask	STUD	30
027-01604		3.21 PLUG	10
027-01610		1.14 BOLT	10
027-01619		0.66 DOWEL PIN	10
027-01631		0.19 SCREW	7
027-01640		11.97 BALL BEARING	1
027-01643		5.61 BALL BEARING	1
027-01688	ask	NIPPLE	1
027-01690		8.37 STUD	30
027-01698		0.25 WASHER	43
027-01710		0.39 SCREW	25
027-01729		0.50 SPLIT PIN	11
027-01735		0.27 FELT	1
027-01739		9.29 OIL SEAL	1
027-01745	ask	STUD	17
027-01749	ask	BOLT	18
027-01812		0.19 PIN	31
027-01814		0.52 JOINT	4
027-01853		1.88 STUD	3
027-01856		1.84 NUT	20
027-01870	ask	VALVE	2

027-01884	1.98 BOLT	14
027-01886	5.60 PLUG	2
027-01898	5.90 OIL SEAL	3
027-01949	1.49 SCREW	20
027-01950	2.97 STUD	3
027-01961	0.34 STUD	30
027-01974	2.23 NUT	34
027-01986	0.25 SPLIT PIN	23
027-01996	2.36 NUT	7
027-02003	0.42 KEY	1
027-02012	0.54 SPLIT PIN	3
027-02058	1.65 STUD	11
027-02061	0.25 SPRING WASHER	2
027-02071	0.95 LOCK	25
027-02091	0.16 SPLIT PIN	20
027-02093	0.90 SCREW	18
027-02118	8.31 BOLT	1
027-02127	ask CHAIN LINK	10
027-02156	3.67 OIL SEAL	6
027-02212	7.37 HOSE	11
027-02226	0.47 WASHER	7
027-02249	ask GREASE NIPPLE	2
027-02255	0.25 SPLIT PIN	78
027-02274	2.39 SPLIT PIN	1
027-02285	0.99 BOLT	8
027-02287	15.64 ROLLER BEARYNG	4
027-02290	2.36 STUD	14
027-02291	1.95 STUD	20
027-02296	15.26 STUD	27
027-02304	2.67 STUD	1
027-03518	4.52 STUD	3
027-03677	1.13 DOWEL	12
027-03710	0.52 JOINT	4
027-03713	0.32 SPLIT PIN	7
027-03730	4.20 NIPPLE	1
027-03731	1.98 NUT	9
027-03762	0.55 SCREW	3
027-03789	3.81 WASHER	3
027-03838	5.34 SPANNER	4
027-03839	6.77 SPANNER	4
027-03905	2.61 PLUG	2
027-03929	0.06 WASHER	3
027-03936	0.25 SPLIT PIN	1
027-03988	0.25 LOCK WASHER	7
027-03990	ask PLATE	1
027-04031	28.40 AIR FILTER ELEMENT	2
027-04040	0.20 SPLIT PIN	1
027-04051	ask KEY	2
027-04056	7.63 BLANKING PIECE	25
027-04057	1.75 KEY	7
027-04058	0.16 SPRING WASHER	1
027-04074	1.26 SCREW	1
027-04075	4.95 SPANNER	6
027-04076	5.72 SPANNER	10
027-04165	0.35 GREASE NIPPLE	7
027-04167	2.11 GREASE NIPPLE	6

027-04192		ask	NIPPLE	4
027-04208			10.73 EXPANSION PLUG	1
027-04212			1.33 OIL SEAL	7
027-04236			1.40 HOSE	8
027-04315			65.80 AIR CLEANER	2
027-04319			0.90 GREASE NIPPLE	1
027-04321			0.87 KEY	1
027-04330			5.68 REDUCING SOCKET	2
027-04336			0.30 SPLIT PIN	16
027-04342		ask	LEVER	2
027-04343		ask	BRACKET	1
027-04344			7.35 DIPSTICK ADAPTOR	2
027-04363			0.04 SPLIT PIN	100
027-04414			0.54 SCREW	2
027-04429			0.69 KEY	1
027-04434			1.83 NUT	8
027-04435			4.33 LOCK NUT	13
027-04444		ask	BOLT	2
027-04492			7.55 UNION	3
027-04495			5.20 STUD	18
027-04513			0.78 CAPSCREW	12
027-04523/6	second hand		40.65 ROLLER BEARING	1
027-04538			0.54 SPRING PIN	8
027-04540			4.33 GREASE NIPPLE	1
027-04541			2.52 GREASE NIPPLE	9
027-04660			0.25 SETSCREW	50
027-04661			0.76 WASHER	129
027-04683			0.49 LOCKNUT	3
027-04739			16.29 HOSE	12
027-04740			9.72 HOSE	4
027-04775			0.70 WASHER	7
027-04783			1.42 KEY	1
027-04885			0.17 SPLIT PIN	2
027-04900			2.11 PIN	5
027-05326			0.25 WASHER	10
027-05387			9.81 HOSE	4
027-05409			14.55 HOSE	1
027-05420			32.74 AIR CLEANER ELEMENT	1
027-05421			39.49 AIR CLEANER ELEMENT	3
027-05448		ask	AIR FILTER	3
027-05488			0.48 CIRCLIP	8
027-05529			10.49 HOSE	9
027-05530			4.68 HOSE	2
027-05533			95.54 CONYTRON BOX	1
027-05562			67.63 HOSE	1
027-05583			63.06 AIR CLEANER ELEMENT	1
027-05616			20.07 HOSE	1
027-05619			23.50 HOSE	2
027-05620			67.63 HOSE	3
027-05622			25.90 HOSE	6
027-05645			178.32 SPARK ARRESTOR	3
027-05646			256.03 SPARK ARRESTOR	2
027-05646			256.03 SPARK ARRESTOR	2
027-05647			220.51 SPARK ARRESTOR	3
027-05679			0.82 SCREW	20
027-05906			3.20 HOSE CLIP	8

027-05962	ask	PLATE	3
027-06000		11.73 SCREWDRIVER	1
027-06010		12.46 PLIER	1
027-06060		2.37 HOSE	17
027-06081		7.11 HOSE	7
027-06159		0.49 WASHER	11
027-06317		9.39 OIL FILLER	1
027-06354		1.33 NAME PLATE	57
027-06890		0.49 RIVET	6
027-06891		0.46 SPACER	2
027-07878		11.09 RADIATOR CAP	1
027-07893	ask	LABELS	7
027-07894		1.14 LABEL	11
027-07896		25.18 REPAIR KIT	1
027-07898		12.31 REP.KIT	1
027-10040		19.60 REPAIR KIT	5
027-10044		15.94 REPAIR KIT	2
027-12840	ask	PULLEY	1
027-38240	ask	JOINT	2
028-00089		3.75 JOINT	13
028-00099		0.30 CIRCLIP	17
028-00176		341.06 SILENCER	1
029-00098		0.51 SCREW	2
029-00127		2.36 SPRING	1
029-00138		0.38 STEEL BALL	4
029-01386	ask	BOLT	9
029G0024		7.74 TAPER LOCK BUSH	12
029G0040		7.42 TAPER LOCK BUSH	1
030-00305	ask	FLANGE	1
030-00307		73.44 COUPLING DISC	1
031-00968	ask	JOINT	8
031-14144	ask	BRACKET	1
031-32994		0.47 RIVET	68
031-54023		9.78 BALL BEARING	1
031-57673		0.58 BALL BEARING	107
031-61533		2.59 SEAL	144
031-66806		3.16 SEAL	13
031-68785		0.47 SEAL	8
034-08342		1.74 NUT	32
035-10721	ask	PINION	2
043-01603	ask	PIPE	1
045-0026	ask	COVER	1
052-08384	ask	PIPE	1
062-08273	ask	RECTIFIER	1
064-01053	ask	RESISTOR	1
064-02508		0.12 RIVET	8
064-02575/014	ask	SCREW	18
064-02576/005	ask	SCREW	4
064-02577/007		0.50 LOCK NUT	1
064-02582/002		0.25 WASHER	4
064-02582/003		0.66 SPRING WASHER	50
064-02582/004		0.07 SPRING WASHER	30
064-02582/005		0.05 SPRING WASHER	4
064-02582/007		1.00 WASHER	100
064-02582/009		1.27 SPRING WASHER	9
064-02582/011	ask	SPRING WASHER	95

064-02582/012	ask	SPRING WASHER	100
064-03370	ask	DAMPER	3
064-03929	ask	LEVER	5
064-04229	ask	PISTON	1
064-04366	ask	BRACKET	1
064-05033/458		4.11 PLATE	1
064-05758	ask	SWITCH	2
064-06209	ask	COIL	1
064-06530	ask	NUT	1
064-06610/002		0.06 NUT	15
064-06610/003		0.38 LOCK NUT	8
064-06610/004	ask	NUT	4
064-06611/001		0.04 NUT	12
064-06611/002		0.68 NUT	50
064-06611/003		0.25 NUT	6
064-06611/006		0.15 NUT	7
064-06611/008		0.13 NUT	4
064-06611/010		0.15 NUT	6
064-06612/001		0.02 WASHER	45
064-06612/002		0.25 WASHER	7
064-06612/003		0.03 WASHER	5
064-06612/004		0.25 WASHER	39
064-06612/006		0.12 WASHER	3
064-06612/008		0.07 WASHER	3
064-06613/001	ask	NUT	20
064-06613/002		0.16 LOCKNUT	12
064-06613/003	ask	NUT	10
064-06613/006		0.12 NUT	10
064-06613/008		0.16 NUT	10
064-06613/009	ask	NUT	10
064-06614/001		0.07 NUT	20
064-06614/002		0.07 NUT	1
064-06614/003		2.25 NUT	19
064-06614/018	ask	NUT	8
064-06615/005		0.08 SCREW	3
064-06615/010		0.14 SCREW	3
064-06616/003		0.12 SCREW	12
064-06616/010		0.16 SCREW	4
064-06616/012		0.17 SCREW	1
064-06616/013		0.17 SCREW	3
064-06616/017	ask	SCREW	3
064-06616/022	ask	SCREW	1
064-06617/007	ask	SCREW	3
064-06617/008		0.30 SCREW	6
064-06617/012		0.28 SCREW	4
064-06617/025	ask	SCREW	2
064-06618/006		0.10 WASHER	6
064-06618/008		0.08 WASHER	5
064-06649/003		0.74 NUT	19
064-06649/006		0.47 NUT	5
064-06722/003		0.25 SPLIT PIN	5
064-06723/007	ask	STUD	6
064-06723/010		0.15 STUD	10
064-06723/016		0.14 STUD	6
064-06723/017		0.23 STUD	6
064-06723/032	ask	STUD	6

064-06723/034		0.27 SCREW	6
064-06734	ask	COIL	5
064-06771/004		0.14 SCREW	6
064-06771/006		0.22 SCREW	11
064-06771/010		0.48 SCREW	6
064-06771/025		0.17 SCREW	2
064-06771/043		0.12 SCREW	2
064-06772/002		0.25 SCREW	10
064-06772/004		0.25 SCREW	25
064-06772/005		0.34 SCREW	8
064-06772/006		0.18 SCREW	9
064-06772/007		0.14 SCREW	7
064-06772/008	ask	SCREW	5
064-06772/009		0.17 SCREW	6
064-06772/012		0.07 SCREW	2
064-06772/013		0.07 SCREW	60
064-06772/017		0.12 SCREW	8
064-06772/018		0.06 SCREW	2
064-06772/021	ask	SCREW	1
064-06772/024		0.26 SCREW	1
064-06773/003		0.12 SCREW	3
064-06773/005		0.09 SCREW	8
064-07005		0.87 PLATE	2
064-07119	ask	COIL	7
064-07137	ask	COIL	2
064-07171	ask	RELAIS	2
064-07175/001		0.25 SCREW	1
064-07230		1.22 PLATE	1
064-07455		36.89 MICRO SWITCH	1
064-07628	ask	PLATE	2
064-07876		34.61 TOGGLE SWITCH	17
064-07965		4.29 SHAFT	29
064-07966		3.92 KNOB	5
064-07967		0.70 SPRING	7
064-07970		0.19 JOINT	2
064-07971	ask	STUD	12
064-07981		13.77 COUPLING	1
064-07982		4.55 PIN	38
064-07985		7.68 COVER	3
064-07989		0.12 STUD	2
064-08044		11.05 REPEATER THERMOSTAT	1
064-08131/009		7.06 FUSE HOUSE	6
064-08397/010	ask	COIL	1
064-08447	ask	SWITCH	1
064-08523/010		0.25 SCREW	50
064-08523/013		2.50 SCREW	2
064-08770		26.28 MICRO SWITCH	1
064-08856		41.12 PLATE	2
064-08885		11.41 SPACER BUSH	10
064-08886		12.43 SPINDLE	3
064-08888	ask	PAWL	6
064-08890		11.00 WASHER	5
064-08892	ask	PLATE	8
064-08893	ask	WASHER	7
064-08909		18.93 SPINDLE	8
064-08912		11.82 BUSH	3

064-08923	6.98 COVER	4
064-08925	7.90 PIN	6
064-08926	0.35 SPINDLE	6
064-08929	10.46 LINKAGE ROD	18
064-08931	0.66 PIECE	9
064-09126	0.90 SPRING	2
064-09127	24.18 SPRING	1
064-09138	3.07 LEVER	2
064-09155	255.32 SOLENOID COIL	5
064-09157	0.50 BRACKET	5
064-09207	0.13 SPRING	3
064-09246	ask FUSE	3
064-09264	2.93 SPRING	8
064-09267	1.70 BUSH	9
064-09522	0.03 WASHER	4
064-09616	ask BRACKET	2
064-09681/002	8.51 LAMP	7
064-09686	20.67 COVER	3
064-09687	1.69 LEVER	3
064-09688	3.34 SPRING	4
064-09689	3.42 BRACKET	3
064-09692	0.10 SPLIT BOLT	1
064-09694	10.17 LEVER	7
064-09697	5.50 LEVER	3
064-09705	4.70 LEVER	3
064-09708	10.62 BRACKET	5
064-09778	88.65 CONTACTOR	4
064-09966	1.60 PIN	2
064-09967	23.42 LEVER	15
064-09971	10.74 LEVER	2
064-09973	11.71 LEVER	6
064-09975	37.82 LEVER	1
064-09978	89.59 SHAFT	1
064-09980	ask LEVER	5
064-10066	4.00 BRACKET	22
064-10068/003	0.21 SCREW	59
064-10068/004	0.07 SCREW	100
064-10107	5.75 SPRING	110
064-10180	7.68 FIXING PILLAR	3
064-10454/001	250.00 DRAYTON MOTOR	1
064-10529	ask SWITCH	3
064-10560/016	ask RELAIS	2
064-10921	ask COIL	2
064-10922	ask SWITCH	2
064-10923	34.77 CONTACTOR	1
064-10926	ask COIL	7
064-11026	ask BOLT	2
064-11272	ask HOUSING	1
064-11472	ask RESISTOR	2
064-11567	2.31 FULCRUM PIN	6
064-11568	23.49 LINK	2
064-11579	8.62 LINK	1
064-11581	2.76 LINK	1
064-11629	5.50 LINK	10
064-12042	59.43 DOOR	10
064-12045	3.28 SPRING	11

064-12290	ask	LEVER	2
064-12297	ask	BUSH	1
064-12447		4.80 BRACKET	1
064-12545	ask	LEVER	8
064-12556	ask	SHAFT	6
064-12571	ask	BUSH	1
064-12579	ask	BRACKET	1
064-12608	ask	NUT	9
064-12656/002		2.51 TERMINAL	14
064-12656/003		3.21 TERMINAL BLOCK	3
064-12656/008		3.71 TERMINAL BLOCK	6
064-12659		19.38 COUPLING	74
064-12660		5.85 LEVER	37
064-12963		7.16 BULB	60
064-13033/008		0.62 GROMMET	10
064-13059		103.51 DOOR	15
064-13161/001		251.82 SOLENOID	2
064-13161/004	ask	COIL	1
064-13177/002		64.85 COIL	8
064-13177/005	ask	COIL	2
064-13177/006		124.66 COIL	1
064-13177/009		64.85 COIL	1
064-13203		155.02 AIR DUCT	6
064-13204	ask	COVER	1
064-13254	ask	COVER	9
064-13255	ask	PLATE	1
064-13264	ask	COVER	1
064-13664		150.00 AIR DUCT	4
064-13729/002		25.27 PART OF SWITCH	15
064-13729/003		25.27 PART OF SWITCH	5
064-13730/001		25.18 SWITCH	1
064-13730/002		25.18 SWITCH	6
064-13730/003		25.18 SWITCH	6
064-13730/004		25.18 SWITCH	5
064-13730/005		25.18 SWITCH	6
064-13768	ask	BRACKET	2
064-13802		8.10 CLAMP	4
064-13809		4.20 BUSH	3
064-13866		35.35 COVER	3
064-13973	ask	BUSH	3
064-13976	ask	LEVER	8
064-14013	ask	KIT	1
064-14029		1.15 PLATE	1
064-14033	ask	BRACKET	1
064-14035	ask	PIN	1
064-14083/002	ask	SWITCH	1
064-14275		1.84 PLATE	2
064-14281		17.90 LEVER	6
064-14541		7.23 DEC.LEVER	1
064-14544		1.03 BRACKET	1
064-14665	ask	COIL	1
064-15036		48.19 HOUSING	2
064-15037		34.43 COVER	3
064-15867		19.68 LINK	1
064-15869		9.93 SCREW	1
064-15876/001		80.00 COIL	1

064-15876/002		93.01 COIL	2
064-16054		0.44 BRACKET	18
064-16577	ask	COVER	1
064-16579		2.94 LEVER	2
064-16580		3.21 BRACKET	2
064-16581		2.76 BRACKET	6
064-16582		9.37 BOLT	5
064-16588		3.47 SPRING	6
064-16589		2.41 KNOB	2
064-16591		17.95 LEVER	2
064-16593		7.08 LEVER	8
064-16676		0.90 PLATE	1
064-16761/001		223.72 COIL	2
064-16762	ask	SCREW	6
064-16763	ask	COIL	6
064-16764	ask	LEVER	2
064-16770	ask	LEVER	2
064-16772	ask	SPRING	25
064-16776		34.05 KNOB	27
064-16855	ask	SWITCH	1
064-16875		4.85 BRACKET	5
064-16980	ask	BRACKET	1
064-16981	ask	BRACKET	1
064-17025	ask	PLATE	1
064-17095	ask	COIL	2
064-17112		5.82 LEVER	2
064-17171/1	ask	CABLE	1
064-17186	ask	LEVER	5
064-17550/013		8.84 RESISTANCE	13
064-17550/015		2.29 RESISTOR	18
064-17550/016		6.57 RESISTANCE	4
064-17562		8.89 LEVER	1
064-17700	ask	PIN	2
064-18577	ask	COVER	1
064-18708	ask	CAP	1
064-19099		114.13 CONTROLLER	2
064-19684		20.10 ANCHOR BRACKET	2
064-19712		9.72 ADJUSTER	69
064-20787	FARVE?	0.95 LENS	1
064-20787/001		1.71 RED LENS	15
064-20787/003		0.80 LENS,ORANGE	2
064-21568/012		1.56 FUSE	1
064-21568/015		5.40 FUSE	13
064-21568/018		1.34 FUSE	40
064-21639/001	ask	SWITCH	1
064-22320		119.85 GENERATOR	4
064-22510	ask	BRACKET	9
064-22511	ask	PIN	26
064-22617	ask	BRACKET	1
064-22780		116.80 AMMETER	1
064-22819		17.77 PUSHBUTTON	30
064-23038		31.30 COVER	1
064-23155	ask	PUMP HOUSING	3
064-23242	ask	BOLT	1
064-23764	ask	BRACKET	7
064-23766	ask	LEVER	8

064-23833	ask	TAP	1
064-23834	ask	BRACKET	1
064-23835	ask	STUD	1
064-23938	ask	PANEL	2
064-24534		95.77 CONTACTOR	1
064-24537	ask	SWITCH	2
064-24628		0.45 PLATE	3
064-24920		29.44 LEVER	2
064-25259		240.70 SWITCH	6
064-25271		239.32 TEMP-SWITCH	3
064-25495		8.27 SWIVEL UNION PLUG	28
064-25748		15.51 LEVER	4
064-25751		53.22 LEVER	4
064-25752		4.28 BRACKET	4
064-27411/002	ask	PUSH BOTTUM	2
064-27411/003	ask	PART OF SWITCH	3
064-27412/001	ask	SWITCH	5
064-27412/002	ask	SWITCH	5
064-28099	ask	DAMPER	60
064-28291/004	ask	COIL	2
064-28443		1.55 PLATE	11
064-28597		6.35 BOLT	4
064-28809		163.85 BRACKET	5
064-28811		37.23 COUPLING	18
064-29373		41.13 PLATE	7
064-29376		4.80 FELT PAD	48
064-29377		3.09 CLAMPING PLATE	26
064-30014		3.60 STUD	2
064-30899		1.60 DISTANCE PIECE	13
064-31035	ask	COVER	2
064-31087		38.42 PUSHBUTTON	10
064-31173	ask	WASHER	2
064-31176		77.17 BRACKET	2
064-31180		4.89 LEVER	1
064-31322		2.77 ADAPTOR	4
064-31323		10.85 ADJUSTER	24
064-31345		0.90 NUT	4
064-31346		0.49 WASHER	4
064-314484	ask	RELAIS	1
064-31716		25.49 PLATE	3
064-31952		74.17 LOCKING DISC	3
064-31953		127.68 PLUNGER	3
064-32236		19.19 BRACKET	1
064-32437		34.16 BRACKET	3
064-32563		4.34 BRACKET	9
064-32698		24.41 LEVER	1
064-32699		67.32 PLUNGER	3
064-32720		1.25 SPRING	7
064-32784		9.89 STUD PLATE	13
064-32785		6.68 PLATE	19
064-32805		14.19 BRACKET	19
064-32847		1.75 PLATE	7
064-32851		16.57 FORK LINK	4
064-32852		1.14 STOP	2
064-32937		5.20 SPRING	91
064-32977		4.77 LEVER	17

064-32978		8.26 LEVER	13
064-33038	ask	COVER	1
064-33039	ask	COVER	1
064-33049/001	ask	COIL	1
064-33049/002	ask	COIL	6
064-33068/001		0.25 SPRING	51
064-33380/001	ask	TERMINAL	34
064-33429		0.25 PIN	7
064-33991/001		0.25 INSULATING COVER	50
064-34339/002		27.03 RELAY	1
064-34341/001		3.44 CLIP	2
064-34863/007		0.16 NUT	6
064-36423		110.15 A.V.R.	1
064-40764	ask	WIRING	2
064-40791	ask	FUSE ASSY	1
064-40953		67.16 RELAY	1
064-82008/001		892.31 A.V.R.	1
064-82180/001		4.01 BRUSH	4
064-82180/002		7.91 BRUSH	8
064-82180/004		14.64 BRUSH	8
064-82180/005		3.48 BRUSH	4
064-82180/006		20.22 BRUSH	8
064-82181/001		17.65 BRUSH	4
064-82252/001		8.46 SPINDLE	1
064-83008/006		756.93 A.V.R.	1
064-85008/001	ask	AVR	2
064-85008/015		597.85 A.V.R.	1
064-85009/002		27.82 VARISTOR	6
064-85009/003		58.97 VARISTOR	2
064-85009/009		28.48 VARISTOR	6
065-00103		15.32 NUT	2
066-16571	ask	CYLINDER HEAD	3
076-07748	ask	DRAWING	1
079-00136		1.43 NIPPLE	14
079-00192		19.23 SPRING	13
082-99904	8299904 ask	SENDER	3
102-00101		54.70 SILENCER	8
103-00087		3.18 JOINT	13
106-00423	ask	CRANKSHAFT	1
106-04060	ask	HOUSING	1
115-66955	ask	FLANGE	1
170-11280	ask	TAP	2
201-02252	ask	SPLIT PIN	4
201-05530	ask	PIN	4
201-10063		27.87 BEARING LD/SL	6
201-10063/010		40.96 MAIN BEARING	2
201-10063/020		26.55 BEARING	4
201-10063/040		32.81 MAIN BEARING	2
201-10074		86.00 BEARING HOUSING	1
201-10100		0.87 CIRCLIP	29
201-10150		2.80 CON ROD BUSH LD/LR	1
201-10181		12.74 CAMSHAFT BUSH	1
201-10190		23.21 CAMSHAFT BUSH	1
201-10263	ask	JOINT	5
201-10273		187.16 CYLINDER BARREL	4
201-10291		34.00 ROCKER ARM	7

201-10321		7.38 VALVE GUIDE LD/SL	21
201-10350		3.41 CARRIER	2
201-10351		6.03 VALVE SPRING CARRIER	7
201-10363		47.14 VALVE LD	2
201-10382		2.92 CYL HEAD GASKET	5
201-10400		6.67 VALVE GUIDE LD/SL	7
201-10462		22.75 COWLING	7
201-10505		ask PLATE	1
201-10506		ask PLATE	1
201-10523		53.68 ROCKER BRACKET	1
201-10660		2.86 WASHER	4
201-10720		2.54 PIN	1
201-10740		0.37 PIECE	132
201-10760		3.47 DOWEL	2
201-10780		0.36 END CAP	10
201-10790		1.94 PIN	2
201-10800		32.01 GOVERNOR SLEEVE	1
201-10820		4.16 GOV WT SPRING	7
201-10821		3.47 GOV WT SPRING	1
201-10830		15.27 FULCRUM	2
201-10842		39.08 GOVERNOR LEVER	1
201-10842/6		18.50 GOVERNOR LEVER	1
201-10891		10.74 GOVERNOR LINK	2
201-10892		20.92 GOVERNOR LINK	6
201-10894		17.32 GOVERNOR LINK	3
201-10901		1.83 SPEEDER SPRING	6
201-10903		2.19 SPEEDER SPRING	1
201-10904		3.72 SPRING	2
201-10950		39.30 DECOMPRESSOR SHAFT	2
201-10960		13.04 ADJUSTING SCREW	5
201-10982		8.88 BREATHER TUBE	1
201-11052/6	second hand	4.00 CYL HEAD STUD	3
201-11061		3.25 STUD	1
201-11091		3.04 BUSH	14
201-11105		41.74 FUEL PIPE	2
201-11111		25.59 FUEL PIPE	2
201-11125		81.74 MANIFOLD	1
201-11131		0.91 MANIFOLD JOINT	5
201-11160		0.40 DOWEL	8
201-11180/6	second hand	ask COVER	1
201-11190		ask SCREW	7
201-11211		0.25 END COVER JOINT	13
201-11271		2.11 RUBBER BUSH	5
201-11333		285.68 CAMSHAFT	1
201-11340		21.19 SUPPORT	1
201-11371		13.30 OIL PIPE	1
201-11380		3.71 NUT	8
201-11390		0.73 RUBBER WASHER	6
201-11402		2.08 JOINT	2
201-11424		146.04 AIR CLEANER	8
201-11431		74.58 FUEL PUMP TAPPET	4
201-11460		0.50 RETAINING PIN	13
201-11471		8.59 TAPPET GUIDE	6
201-11481		4.71 LOCATING PIN	2
201-11491		9.29 SUPPORT BLOCK	10
201-11510		134.67 FUEL PUMP	2

201-11510/698	exchange	134.67 FUEL PUMP	12
201-11520		0.25 FUEL PUMP SHIM	28
201-11530		0.25 FUEL PUMP SHIM	19
201-11540		15.63 FUEL PUMP CLAMP	5
201-11560		1.45 WASHER	15
201-11571		26.94 DOOR	1
201-11581		1.12 JOINT	20
201-11590		0.31 NUT	28
201-11644		36.25 FUEL PIPE	2
201-11652		6.98 OIL PIPE	2
201-11663		10.25 TEE PIECE	12
201-11675		34.19 FUEL PIPE	9
201-11690		9.26 UNION	22
201-11710		0.93 GROMMET	1
201-11720		0.34 WASHER	10
201-11730		0.25 PIN	3
201-11770		118.17 INJECTOR	2
201-11770/698	exchange	118.17 INJECTOR	5
201-11861		17.79 OIL PIPE	1
201-11890		0.66 WASHER	85
201-12063		46.26 NOZZLE LR	3
201-12081		10.70 OIL PIPE	1
201-12190/020	ask	BEARING	2
201-12210	ask	EXTENSION SHAFT	1
201-12220		12.75 SCREW	1
201-12230		0.70 LOCK WASHER	5
201-12240		0.49 OIL THROWER	10
201-12270		9.91 SPRING	7
201-12280		1.65 BUSH	44
201-12300		0.65 CYL HEAD SHIM	13
201-12320		0.76 CONTROL LEVER	11
201-12330		13.40 SPRING	24
201-12390		6.57 COVER	19
201-12392		12.10 END COVER	3
201-12410		7.92 SHIELD	2
201-12420		8.81 SHIELD	1
201-12450		1.38 SPRING	3
201-12460		1.97 SHIM	8
201-12461		2.32 SHIM	26
201-12462		0.66 SHIM	7
201-12570		1.01 CAP SPRING	8
201-12601		17.32 CAP	1
201-12610		136.64 FAN	3
201-12630		50.27 OIL RETAINING RING	5
201-12681		290.00 CAMSHAFT	1
201-12760		32.10 DYNAMO BRACKET	7
201-12770		18.64 BRACKET	3
201-12793		243.69 HALF COUPLING	11
201-12795		84.81 HALF COUPLING	7
201-12795		84.81 HALF COUPLING	7
201-12810		14.17 BRACKET	2
201-12830		44.38 PULLEY	10
201-12850		3.18 ADJUSTING LINK	6
201-12870		125.03 GEAR RING	2
201-12870/5		95.61 GEAR RING	2
201-12871		169.83 GEAR RING	3

201-12890		50.27 OIL RETAINING RING	1
201-12910		ask BEARING	1
201-12920		ask BEARING	1
201-12951		1.44 GROMMET	10
201-12970		3.13 WASHER	148
201-12990		0.26 TEE SLEEVE	24
201-13000		0.74 NUT	9
201-13160		8.47 BLANKING PLATE	30
201-13180		1.18 WASHER	106
201-13200		2.02 OIL THROWER	53
201-13210		ask DIPSTICK	1
201-13450		90.91 END COVER	1
201-13510/6	second hand	6.90 SPINDLE	2
201-13570		4.82 DOWEL	8
201-13580		0.22 SHIM	37
201-13590		87.09 CAMSHAFT GUARD	1
201-13740		5.74 FLANGE	12
201-13810		12.87 GUARD	5
201-13820		112.05 SHAFT	1
201-13830		0.93 CIRCLIP	12
201-13840		2.47 WASHER	3
201-13870		ask LEVER	1
201-13920		2.01 KEY	15
201-14051		ask GUARD	1
201-14060		ask SHIELD	8
201-14070		7.50 GUARD	3
201-14090		3.72 JOINT	4
201-14110		1.40 CIRCLIP	1
201-14140		2.58 JOINT	6
201-14170		3.28 BOLT	2
201-14171		7.42 SCREW	1
201-14190		ask BRACKET	1
201-14200		42.32 BRACKET	5
201-14320		6.28 WASHER	2
201-14330		64.98 RETAINER	1
201-14341		316.50 SHAFT	2
201-14360		77.54 YOKE	3
201-14380		3.27 SPRING	22
201-14430		ask FLANGE	3
201-14431		63.04 FLANGE	8
201-14440		9.34 LOCK NUT	1
201-14470		9.52 DISTANCE PIECE	1
201-14480		86.27 SHAFT	1
201-14480/6	second hand	59.37 LEVER	2
201-14490		5.14 PIN	6
201-14500		5.32 ADAPTOR	5
201-14520		1.16 BOLT	1
201-14540/6	second hand	50.22 LEVER	1
201-14560		5.63 PLATE	4
201-14570		8.48 ROLLER	1
201-14580		2.60 BOLT	5
201-14590		13.07 CLAMP PLATE	4
201-14600		3.67 SPRING	1
201-14610		0.71 BRACKET	3
201-14620		2.59 WASHER	3
201-14632		ask SHAFT	2

201-14651		1.87 SETSCREW	2
201-14741		1.08 JOINT	12
201-14750	ask	HOUSING	1
201-14800		1.51 JOINT	2
201-15161		2.84 STUD	6
201-15390		11.45 HOSE	11
201-15500		55.04 PLATE	2
201-15520		18.41 RATCHET PAWL	4
201-15540		2.92 SPACER	7
201-15590		190.04 PULLEY	2
201-15600		84.40 CHAIN WHEEL	3
201-15670		17.36 COLLAR	9
201-15690		33.18 SHAFT	5
201-15710		5.15 PIN	2
201-15720		38.32 BRACKET	3
201-15721		38.30 BRACKET	7
201-15800		1.49 SHIM	57
201-15830		89.62 BEARING	3
201-15840		52.15 BRACKET	2
201-15860		5.39 BAND	4
201-15890	ask	BAND	5
201-15930		90.39 TENSIONER	3
201-16100		163.21 ADAPTOR	1
201-16400		0.04 LOCKNUT	1
201-16891		9.27 LIFTING LUG	16
201-17021		70.27 CONTROL CABLE	1
201-17030		28.53 CONTROL LEVER	13
201-17040		2.01 BRACKET	3
201-17061		2.41 SCREW	6
201-17071		34.19 FUEL PIPE	4
201-17080		25.82 FUEL PIPE	1
201-17092		39.82 FUEL PIPE	7
201-17093		34.84 FUEL PIPE	1
201-17100		37.96 COVER	1
201-17122	ask	PIPE	2
201-17150		33.54 BRACKET	29
201-17160		0.64 CLIP	28
201-17170		0.39 FELT	51
201-17190		6.81 BOLT	5
201-17200		13.60 PIN	3
201-17210		23.14 TEE PIECE	6
201-17211		27.49 TEE PIECE	1
201-17212		28.02 TEE PIECE	74
201-17270		10.70 SWIVEL UNION	120
201-17271		9.99 PLUG	44
201-17280		20.91 PLUG	56
201-17290		51.64 PUMP TAPPET	3
201-17300		35.17 TAPPET BUSH	17
201-17310		14.74 BAR	2
201-17423		72.05 CYL HEAD COVER	1
201-17423/6	second hand	50.00 COVER,SECOND HAND	1
201-17430		13.94 BALL BEARING	1
201-17433	ask	COVER	1
201-17460		3.58 CON ROD BUSH	7
201-17520/620	EXCHANGE	36.06 CYLINDER ,020 O/S	3
201-17540		0.62 CYL HEAD SHIM	71

201-17590		6.38	STUD	25
201-17600		8.00	SCREW	3
201-17610		0.44	WASHER	2
201-17620		4.08	NUT	4
201-17671		141.21	PINION	1
201-17680		0.40	JOINT	23
201-17720		ask	HOUSING	2
201-18520		107.20	SEALINGPLATE	1
201-18540		1.87	JOINT RING	10
201-19240/6	second hand	7.70	BRACKET,SECONDHAND	7
201-19272		26.23	COVER	2
201-19280		0.89	BRACKET	1
201-19370		45.57	ROCKER LEVER	5
201-19630/6	second hand	33.66	BRACKER,SECONDHAND	6
201-20150		ask	BEARIING HOUSING	1
201-20990		8.21	OIL SEAL	7
201-21010		ask	DISTANCE PIECE	3
201-21030		ask	DISTANCE PIECE	2
201-21040		ask	SHAFT	1
201-21730		10.01	BUSH	3
201-22050		3.37	SHIM	18
201-22060		3.49	SHIM	19
201-22210		ask	HOUSING	1
201-22220		84.56	BEARIING HOUSING	2
201-22291		117.91	SHAFT	1
201-22370		0.60	JOINT	7
201-22380		19.64	BUSH	2
201-22390		3.18	CIRCLIP	10
201-22410		76.75	ROLLER BEARING	1
201-22420		49.16	OIL SEAL	1
201-22430		11.72	THRUST WASHER	8
201-22440		10.83	THRUST WASHER	5
201-22470		274.56	SHAFT	1
201-22490		0.90	JOINT	18
201-22530		1.09	CIRCLIP	10
201-22550		60.24	COVER	1
201-22580/6	second hand	11.25	BUSH	3
201-22590/6	second hand	8.00	BUSH	4
201-22600		91.25	PLATE	5
201-22650/6	second hand	17.09	DRIVE SHAFT	3
201-22651/6	second hand	6.43	SHAFT	2
201-22660		1.83	SCREW	4
201-22700		21.70	COLLAR	4
201-22730		339.14	HOUSING	6
201-22750		4.59	OIL THROWER	2
201-22780		138.50	CLUTCH SHAFT	1
201-22810		5.00	SPACER	4
201-22811		11.62	DISTANCE PIECE	1
201-22840		241.52	GEAR WHEEL	2
201-22850		91.99	PLATE	2
201-22860		67.13	DRIVEN PLATE	5
201-22890		211.20	CLUTCH BODY	3
201-22900		305.64	CLUTCH CASE	1
201-22940		6.13	NUT	6
201-22950		46.92	ROLLER BEARING	2
201-23420		197.76	HALF COUPLING	19

201-23430		7.86 BOLT	74
201-23510		4.19 BOLT	6
201-24530		2.33 STUD	9
201-24540		14.18 SWIVEL UNION PLUG	39
201-24590		5.88 SPRING	3
201-24771		6.85 VALVE SPRING CARRIER	6
201-24801		4.16 O RING	108
201-25330		87.57 COVER	1
201-25360		18.93 PLUG	1
201-25372		11.73 SHIELD	1
201-25400		86.62 PISTON	1
201-25420		12.22 SCREW	2
201-25430		1.28 CIRCLIP	3
201-25450		138.68 SHAFT	1
201-25460		16.52 SHAFT	2
201-25520		11.46 CLAMP	2
201-25530		5.84 SPRING	1
201-25540		234.04 VALVE	1
201-25554		66.97 NUT	1
201-25571		7.87 SCREW	1
201-25591		15.06 LEVER	3
201-25660		1.24 KEY	3
201-25670		185.96 PINION	3
201-25680		46.10 DELIVERY PIPE	1
201-25700		255.04 DRIVING GEAR	2
201-25700/6	second hand	255.04 DRIVING GEAR,SECOND HAND	2
201-25740		1.93 JOINT	5
201-25770	201-25778	5.37 DOWEL	10
201-25770		7.07 DOWEL	10
201-25780		1.65 O RING	12
201-25820		11.73 OIL OPIPE	1
201-25830		12.83 SWIVEL UNION PLUG	2
201-25860		1.28 DISTANCE PIECE	1
201-25870		1.33 SPRING	1
201-25880		18.31 PLUG	1
201-25900		9.74 SCREW	5
201-26110		4.21 JOINT	8
201-26150		3.31 KEY	8
201-26270		9.57 SCREW	3
201-26280		3.79 DOWEL	3
201-26350		67.92 STRAINER	1
201-26400		12.66 NUT	1
201-26410		0.49 SHIM	10
201-26450		6.32 JOINT	8
201-26490		423.75 FANSHROUD	2
201-26491		242.02 FLYWHEEL	3
201-26500		238.34 FLYWHEELHOUSING	3
201-26540		0.50 TAB WASHER	8
201-26550	ask	STARTING HANDLE	1
201-26550	ask	FLANGE	1
201-26600		0.56 SPACER	4
201-26670/6	second hand	24.70 PINION, SECONDHAND	1
201-26680/6	second hand	14.85 PINION	6
201-30080		3.09 VALVE SPRING TS/TR	40
201-30100		5.12 PUSH ROD	3
201-30110		1.42 ADJUSTING SCREW	6

201-30130	8.35 TAPPET	1
201-30221	ask BEARING	2
201-30330	1.77 ADJUSTING SCREW	1
201-30340	45.10 RETAINING SCREW	1
201-30390	2.97 THRUST WASHER	1
201-30400	0.82 SPRING RING	8
201-30460	6.15 DEC.LEVER	5
201-30470	2.90 SCREW	7
201-30480	0.25 SPRING	5
201-30490	0.21 WASHER	1
201-30510	83.93 ADAPTOR	2
201-30550	17.50 PUMP PUSH ROD	25
201-30590	2.45 COVER	1
201-30630	0.84 LOCATING SCREW	8
201-30650	39.92 ROCKER LEVER	9
201-30680	0.35 SHIM	2
201-30681	0.38 SHIM	5
201-30682	0.39 SHIM	7
201-30683	0.58 SHIM	7
201-30684	0.58 SHIM	4
201-30721	4.45 RETAINER	10
201-30797	ask COVER	2
201-30821	73.57 FUEL TANK	4
201-30890	13.11 UNION ADAPTOR	10
201-30910	ask FELT RING	2
201-30930	4.21 EXPANSION PLUG	5
201-30940	1.64 SHIM	11
201-30941	0.39 SHIM	6
201-30942	0.54 SHIM	6
201-30943	2.38 SHIM	6
201-30944	3.04 SHIM	8
201-30950	0.39 LOCK WASHER	12
201-31070	1.01 SEALING RING	6
201-31320	1.82 JOINT	58
201-31340	1.26 SPRING	7
201-31361	12.51 SPEEDER SPRING	3
201-31364	2.90 SPEEDER SPRING	2
201-31365	3.02 SPEEDER SPRING	8
201-31381	0.64 PLATE	1
201-31930	6.38 STUD	1
201-32010	3.62 BREATHER	6
201-32720	3.66 CIRCLIP	7
201-32730	21.94 SPACER	1
201-32941	1.35 JOINT	1
201-33012	4.54 JOINT	7
201-33050	14.93 VALVE INSERT	4
201-33060	15.61 VALVE INSERT	4
201-33070	6.35 INLET VALVE TR	10
201-33090	ask VALVE	6
201-33110	1.36 CYL HEAD GASKET	23
201-33650	ask LEVER	1
201-34150	2.84 STUD	4
201-36080	14.62 BELT	4
201-36081	13.68 BELT	1
201-37280	1.51 SPACER	1
201-37291	2.79 KNOB	20

201-37700/620	EXCHANGE	45.45	CYLINDER ,020 O/S	2
201-37750		0.30	SUMP JOINT	7
201-37751		3.88	SUMP JOINT	1
201-37851		51.44	MANIFOLD	1
201-37852		69.72	MANIFOLD	1
201-38010		2.86	SPRING	22
201-38230		6.79	BLANKING PLATE	18
201-38940		18.45	FUEL PIPE	1
201-39410		36.46	COIL	3
201-39540		7.89	PILLAR	2
201-39660		4.01	CONNECTION	2
201-39672		84.61	FUEL LIFT PUMP	1
201-39680		2.03	PIN	1
201-39701		1.15	JOINT	9
201-39830		1.44	BREATHER TUBE	2
201-39850		49.10	SIDE SHIELD	8
201-39961		61.21	FUEL PIPE	5
201-41070		27.77	FUEL PIPE	2
201-41160		12.00	BRACKET,SECONDHAND	6
201-41181		28.69	OIL PIPE	1
201-41190		19.27	OIL PIPE	6
201-41320	ask		JOINT	16
201-41640		0.38	WASHER	7
201-41930		0.98	CIRCLIP	2
201-42440		1.65	DISTANCE PIECE	1
201-42450		0.65	SPACER	14
201-42520		1.16	SPACER	3
201-42530		31.27	CONTROL LEVER	2
201-42600		11.92	CONNECTION	3
201-42620		2.36	FUEL HOSE	3
201-42630		14.37	CONNECTOR	9
201-42640		4.22	PIPE CLIP	7
201-42830		1.47	SPACER	2
201-43421		39.98	VALVE ROCKER	3
201-43450		1.89	JOINT	2
201-43620		0.55	SHIM	16
201-43630		0.63	SHIM	9
201-43640		0.97	SHIM	8
201-43770		6.77	CYL HEAD BOLT	10
201-43782		36.40	PULLEY	1
201-43984		13.48	BRACKET	1
201-44460	ask		PULLEY	1
201-44592		78.19	FUEL PUMP	2
201-44930		6.54	MOUNTING PLATE	1
201-45180		15.53	BEARING	4
201-45343		43.78	FUEL LIFTPUMP	2
201-46800		12.23	FUEL PIPE	1
201-46830		11.63	BRACKET	1
201-46880		10.63	FUEL PIPE	1
201-47012/698	exchange	47.52	INJECTOR TX	2
201-47032		21.59	NOZZLE TX/P600	7
201-47062		21.59	NOZZLE TR	58
201-47092		21.59	NOZZLE TS	18
201-47290		5.94	EXPANSION PLUG	4
201-50050		8.54	CON ROD BOLT	11
201-50060/020		16.80	BEARING SR	1

201-50060/040		16.80 BEARING SR	4
201-50070		150.61 BEARING HOUSING	1
201-50220		ask PLATE	3
201-50420		1.33 SHIM	9
201-50421		1.39 SHIM	45
201-50423		2.52 SHIM	19
201-50431/698	exchange	106.43 FUEL PUMP	4
201-50441		139.49 INJECTOR SR	5
201-50461		21.00 NOZZLE SR	27
201-50521		52.38 OIL UM TAET	1
201-50540		5.82 CON ROD BUSH SR	5
201-50570		0.33 CON ROD BUSH SR	33
201-50610		0.79 CYL HEAD GASKET	204
201-50632/640	EXCHANGE	49.55 CYLINDER ,040 O/S	1
201-50690/6	second hand	4.50 SIDE SHIELD	2
201-50860		28.33 FUEL PIPE	3
201-50921		0.79 VALVE COTTER	6
201-50940		82.78 ROCKER LEVER	6
201-50950		2.19 GROMMET	51
201-50980		44.45 BRACKET	2
201-51007		ask COVER	1
201-51021/6	second hand	ask SHIELD	1
201-51100		7.15 CLAMP	9
201-51125		64.42 MANIFOLD	3
201-51125/6	second hand	64.42 MANIFOLD	1
201-52110		19.78 VALVE SPRING CARRIER	12
201-52111		4.08 VALVE SPRING CARRIER	12
201-52300		0.62 SPACER	9
201-52500		3.09 JOINT	20
201-52790		0.79 FELT STRIP	4
201-53120		9.45 NUT	2
201-53140		11.63 SPRING	3
201-53400		6.47 SWIVEL UNION	17
201-54970		7.43 ADAPTOR SLEEVE	2
201-54971		ask HOSE	3
201-54980		5.68 ADAPTOR SLEEVE	23
201-55050		25.75 OIL PIPE	1
201-55300		47.78 OIL PIPE	1
201-55321		9.66 OIL PIPE	2
201-55330		33.28 CONNECTOR	8
201-55340		47.67 CRANKCASE DOOR	2
201-55350		3.35 DOOR JOINT	21
201-55360		31.95 UNION	1
201-55520		20.23 BUSH	4
201-55530		25.97 BUSH	19
201-55640		3.30 VALVE GUIDE SR/ST	7
201-55650		3.36 VALVE GUIDE SR/ST	6
201-55660		0.48 RETAINING PLATE	1
201-55710		45.20 BRACKET	4
201-55740		18.98 FUEL PIPE	1
201-55790		8.36 RUBBER BUSH	4
201-60001		ask CYLINDER	1
201-60012		ask CYLINDER HEAD	2
201-60050		ask COVER	2
201-60071		1.64 SHIM	38
201-60080		2.19 PLUG	8

201-60180		15.19 BUSH	1
201-60220		0.25 JOINT	2
201-60230		5.88 HOSE	11
201-60300		124.18 HOUSING	1
201-60300-2	ask	PIPE	1
201-60373		87.87 WATER PIPE	1
201-60420		6.43 DISTANCE PIECE	2
201-60440		134.94 INJECTOR	2
201-60440/698	exchange	100.00 INJECTOR	2
201-60970		15.49 SHAFT	1
201-60980		6.59 DECOMPRESSOR LEVER	1
201-60990		6.98 ADJUSTING SCREW	1
201-61031		35.24 CLAMP	5
201-61041		11.35 pillar	1
201-61050		6.24 SCREW	3
201-61180		12.04 CYL HEAD STUD	2
201-61190		12.04 CYL HEAD STUD	2
201-61290		3.09 SHIM	6
201-70031		174.89 injector LR	6
201-70031/698	exchange	174.89 INJECTOR	2
201-70050/098		109.92 FUEL PUMP LR	3
201-70050/698	exchange	109.92 FUEL PUMP	4
201-80030	ask	CYLINDER HEAD	1
201-80041		14.56 VALVE INSERT	6
201-80110		1.46 SHIM	14
201-80112		0.96 SHIM	11
201-80113		1.46 SHIM	41
201-80114		0.77 SHIM	33
201-80115		2.53 SHIM	23
201-80170		1.26 JOINT	38
201-80180		2.75 JOINT	12
201-80200		1.26 O RING	7
201-80220		1.07 CYL HEAD SHIM	23
201-80230		10.59 VALVE SPRING CARRIER	65
201-80264		75.00 INJECTOR	1
201-80264		75.00 INJECTOR	1
201-80265		78.30 INJECTOR ST	3
201-80290		3.29 OIL THROWER	19
201-80300		5.54 CON ROD BOLT	143
201-80310	ask	BUSH	1
201-80321		29.28 FUEL PIPE	11
201-80340/6	second hand	49.70 ROCKER BRACKET	1
201-80350		55.84 ROCKER BRACKET	4
201-80350/6	second hand	26.50 ROCKER BRACKET	1
201-80400		71.16 BALANCE WEIGHT	4
201-80400/6	second hand	71.16 BALANCE WEIGHT	4
201-80420		0.69 CIRCLIP	5
201-80460		2.63 LOCK WASHER	4
201-80470		49.58 RETAINING SCREW	2
201-80480/6	second hand	114.28 FANSCROUD	1
201-80500/6	second hand	114.06 FAN	1
201-80510		65.89 SHAFT EXTENSION	4
201-80530		43.16 COWLING	1
201-80530/6	second hand	43.16 COWLING	1
201-80550		1.66 FLYWHEEL KEY	13
201-80651		3.33 STUD	6

201-80660		1.55 MANIFOLD JOINT	110
201-80670/9	non genuine	3.57 NUT	51
201-80730		13.26 SIDE SHIELD	1
201-80751		20.83 OIL PUMP TAPPET	6
201-80760		24.75 SIDE SHIELD	4
201-80780		226.40 CAMSHAFT SR/ST1	1
201-80840		101.05 FAN	1
201-80850		94.00 SHAFT EXTENSION	2
201-80910		97.73 SHAFT EXTENSION	2
201-80950		0.25 TAB WASHER	191
201-80980		0.25 JOINT	62
201-80990		117.17 STARTING DOG	2
201-81000		149.98 STARTING DOG	2
201-81150		210.32 YOKE	2
201-81300		21.81 CRANKCASE DOOR	1
201-81300/6	second hand	21.81 CRANKCASE DOOR	1
201-81391		15.00 NOZZLE	1
201-81492		122.27 MANIFOLD	4
201-81860		1.52 PLUG	5
201-81921		22.53 FUEL PIPE	1
201-81940	ask	PIPE	3
201-82220		18.18 SWIVEL UNION PLUG	20
201-82521		22.21 ADAPTOR PLATE	1
201-82530		11.63 LEAK-OFF PIPE	6
201-82540		24.62 PIPE	29
201-82610		22.00 PUMP PUSH ROD	1
201-82620		23.69 PUMP PLUNGER	1
201-82630		24.28 PLUNGER CAP	1
201-82710		0.25 SHIELD	1
201-83070		43.06 governor link	2
201-83170		6.16 SPRING	2
201-83200		27.53 FILTER BRACKET	1
201-90021		69.56 cyl head cover	1
201-90030		2.84 CYL HEAD GASKET	2
201-90040		27.21 INLET VALVE STW	10
201-90051		14.58 EXHAUST VALVE STW	5
201-90070		26.86 PUSH ROD	7
201-90120		11.10 RESTRICTOR	1
201-90130		1.19 JOINT	1
201-90150		2.16 JOINT	4
201-90160		7.19 OIL PIPE	15
201-90170		3.85 SCREW	6
201-90230		3.36 VALVE SPRING	18
201-90240		17.27 VALVE SPRING CARRIER	8
201-90290		2.77 DOWEL PIN	2
201-90470		21.59 FUEL PIPE	6
201-90541		1.80 JOINT	14
201-90541		1.80 JOINT	14
201-90670		10.00 VALVE GUIDE STW	11
201-90930		39.09 BEND	1
201-91390		27.73 BRACKET	1
201-91430		6.61 distance piece	1
201-91440		3.41 SCREW	3
201-91510		37.93 SNOUT	12
202-05478	ask	BRACKET	1
202-10014	ask	CRANKCASE	1

202-10426		498.56	FANSCHROUD	1
202-10427/6	second hand	498.56	FANSCHROUD	1
202-11103		38.66	FUEL PIPE	4
202-11161		ask	PINION	1
202-11175/6	second hand	124.40	FUEL PUMP HOUSING	2
202-11176/6	second hand	124.40	FUEL PUMP HOUSING	1
202-11335		325.78	CAMSHAFT	1
202-11402		3.65	JOINT	20
202-11490		9.72	SUPPORT BLOCK	2
202-11572		23.39	DOOR	2
202-11573		42.66	DOOR	2
202-11573/6	second hand	30.00	DOOR	1
202-11582		2.51	JOINT	57
202-11583		2.46	JOINT	53
202-11942		128.12	BEARING	4
202-12003		10.37	SHACKLE	12
202-12011		4.60	ROD	7
202-12020		2.57	SPRING	29
202-12080		4.00	OIL PIPE	3
202-12420		11.12	SHIELD	5
202-12690		34.35	CRANKCASE DOOR	1
202-12700		3.11	DOOR JOINT	59
202-12710		0.16	SPRING	25
202-12800		14.10	STUD	5
202-13170		2.35	TAB WASHER	14
202-13670		3.32	PIN	35
202-13671		6.02	PIN	2
202-13690		7.29	SHIELD	1
202-13700		3.41	OIL PIPE	2
202-13710		3.35	OIL PIPE	2
202-13711		4.65	OIL PIPE	4
202-13990		121.44	MANIFOLD	3
202-13991		103.50	MANIFOLD	2
202-14000		77.21	MANIFOLD	1
202-14002		77.21	MANIFOLD	1
202-14010		3.22	WASHER	4
202-14210/6	second hand	ask	BRACKET	2
202-15420		55.98	DISTANCE PIECE	2
202-15480		150.00	FANSCHROUD	1
202-15520		ask	FLANGE	2
202-15610		28.15	BAND	3
202-15700		137.14	SHAFT	2
202-15741		62.25	SHAFT	1
202-15910		ask	BAND	4
202-16020		96.06	plate	1
202-16060		35.74	GUARD	5
202-16100		291.69	HOUSING	1
202-16111		ask	HOUSING	2
202-16130		19.16	DISTANCE PIECE	1
202-16140		11.70	DISTANCE PIECE	1
202-16150		ask	EXTENSION SHAFT	2
202-16170		60.67	DISTANCE PIECE	2
202-16180		87.11	shaft extension	1
202-16200		46.15	SHAFT	1
202-16210		95.21	COVER	3
202-16240		50.64	OIL SEAL	5

202-16250		0.95 CIRCLIP	4
202-16290		2.25 WASHER	4
202-16300		0.38 WASHER	3
202-16310		11.05 BUSH	2
202-16320		5.93 BUSH	2
202-16350		0.30 joint	3
202-16870		85.16 BRACKET	1
202-16920		0.34 OLIVE	4
202-16930		1.38 NUT	67
202-17122		26.92 FUEL PIPE	2
202-21700		63.75 SHAFT EXTENSION	1
202-21701	ask	SHAFT EXTENSION	4
202-22030	ask	TANK	3
202-22730		458.65 ADAPTOR	3
202-24040		4.65 LOCKING PLATE	2
202-24050		2.36 WASHER	3
202-24060		0.49 WASHER	62
202-25720	ask	WASHER	2
202-26110		10.99 JOINT	6
202-26490/6	second hand	278.70 FANSHROUD	1
202-26550		42.56 DISTANCE PIECE	1
202-26550		42.56 DISTANCE PIECE	1
202-30350	ask	COVER	3
202-30540		0.53 JOINT	20
202-30541		6.44 SUMP JOINT	6
202-30600		4.03 INSPECTION DOOR	1
202-30742		89.16 AIR COWLING	1
202-31000		120.40 MANIFOLD	1
202-31003		75.86 MANIFOLD	3
202-31003		75.86 MANIFOLD	3
202-31010		69.21 manifold adaptor	10
202-31031		67.44 MANIFOLD ADAPTOR	4
202-31055		2.48 SPRING	1
202-31090		4.83 DOWEL	13
202-31100		2.36 PLUG	1
202-31430		0.72 SUPPORT BRACKET	1
202-31593		131.97 AIR DUCT	1
202-31671		31.02 OIL PIPE	1
202-31981		13.04 FUEL PIPE	1
202-32120		0.85 BALL VALVE	4
202-32161	ask	PIPE	1
202-33160		24.62 DISTANCE PIECE	1
202-33180		16.91 DISTANCE PIECE	1
202-33241		52.43 AIR FILTER	2
202-33241		204.81 AIR CLEANER	2
202-33241		204.81 AIR CLEANER	2
202-33250	ask	FILTER	1
202-33790		14.62 FLYWHEEL NUT	2
202-33790		14.62 FLYWHEEL NUT	2
202-33800		1.47 WASHER	1
202-33800		1.47 WASHER	1
202-34070		49.25 FUEL PIPE	1
202-34161		3.30 LEVER	1
202-34171		10.08 SHAFT	3
202-34192		0.64 BRACKET	1
202-34270		46.64 SIDE SHIELD	3

202-34700		ask	PIPE	1
202-34961			120.45 STARTER MOTOR	1
202-35280/6	second hand		167.37 ADAPTOR	1
202-35310			177.32 COUPLING FLANGE	8
202-35330			102.67 COUPLING FLANGE	8
202-35340			54.58 TAPER LOCK	1
202-35341			20.00 taper lock	1
202-35344			54.58 TAPER LOCK	13
202-35344			54.58 TAPER LOCK	13
202-35360			83.75 DRIVEMEMBER	1
202-35430			14.88 STUD	2
202-35441			163.97 SHAFT EXTENSION	1
202-35450			9.36 BRACKET	1
202-35500			4.52 MOUNTING PLATE	7
202-35940		ask	LEVER	4
202-35950		ask	BRACKET	2
202-36380			6.88 STUD	1
202-36390			13.22 DISTANCE PIECE	1
202-36400			10.36 DISTANCE PIECE	1
202-36530			37.97 BRACKET	1
202-36620		ask	SWIVEL UNION PLUG	1
202-36670			42.73 MOUNTING BRACKET	5
202-36742			169.00 SILENCER	3
202-36891			26.91 BRACKET	4
202-36900			30.46 OUTLET BEND	4
202-37580			2.26 SEAL	14
202-37600			2.45 SPRING	1
202-37710			3.56 COVER	9
202-37950			15.98 UNION ADAPTOR	1
202-37970			0.69 STUD	10
202-38491			7.59 CONNECTION	1
202-38702			78.31 FUEL PIPE	4
202-38721			98.80 MANIFOLD ADAPTOR	2
202-38721			98.80 MANIFOLD ADAPTOR	2
202-39432			12.06 GOVERNOR LINK	1
202-39870			220.02 SHAFT EXTENSION	3
202-41280			1.15 FUEL HOSE	3
202-41320			2.90 GROMMET	7
202-41320			2.90 GROMMET	7
202-41690			23.83 NUT	2
202-41966		ask	FLYWHEEL	1
202-42370			3.11 UNION	14
202-42371			2.61 UNION	17
202-42470			196.97 STARTER MOTOR	1
202-43720			15.63 CAMSHAFT BUSH	5
202-44871			4.84 FUEL PIPE	17
202-44940/9	non genuine		476.23 STARTER MOTOR	1
202-45052			29.97 FUEL PIPE	5
202-45053			29.41 FUEL PIPE	3
202-45310			86.59 TEMPERATURE SWITCH	1
202-46300			40.63 FUEL PIPE	1
202-46680			46.63 ADAPTOR	1
202-46800			33.45 FUEL PIPE	1
202-46980			3.04 UNION	3
202-50012		ask	CRANKCASE	1
202-50170			210.71 BEARING	1

202-50710		11.26 SHIELD	1
202-50730		12.69 SHIELD	3
202-51000		102.88 manifold	1
202-51062		255.00 CAMSHAFT SR/ST2	1
202-51082		255.00 CAMSHAFT SR/ST2	2
202-51082/6	second hand	255.00 camshaft	1
202-51121/6	second hand	133.90 manifold	1
202-51610		ask FAN	1
202-54700		ask BRACKET	2
202-54730		31.82 BRACKET	5
202-54740		34.21 PLATE	5
202-54780		50.54 LINK	1
202-55030		0.28 PLATE	3
202-55040		0.52 SHIM	18
202-55340		74.39 CRANKCASE DOOR	3
202-55380		92.39 OIL PIPE	1
202-55400		19.14 OIL PIPE	5
202-55440		123.82 CRANKCASE DOOR	1
202-55720		108.90 BRACKET	4
202-55810		27.78 BRACKET	2
202-60193		ask CAMSHAFT	1
202-60350		11.90 HOSE	8
202-60550		11.90 BRACKET	2
202-60590		ask BRACKET	2
202-60641		43.43 FUEL PIPE	1
202-60722		42.81 COVER	1
202-60761		94.15 MANIFOLD	1
202-61120		ask ADAPTOR	1
202-61130		ask ADAPTOR	3
202-61210		77.84 BUSH	4
202-80590/6	second hand	86.16 BEARING HOUSING	4
202-80600		ask PIPE	1
202-80650		0.79 STUD	1
202-80891		ask FLYWHEEL	1
202-80960		137.81 COUPLING PLATE	45
202-81080		600.49 CAMSHAFT	2
202-81900		51.37 PIPE	9
202-81920		44.92 LEAK-OFF PIPE	1
202-82610		52.61 PUMP PUSH ROD	3
202-90331		58.00 COVER	1
202-90590		32.38 FUEL PIPE	1
202-90650		1.72 JOINT	3
202-90651		ask JOINT	3
202-90850		4.15 BRACKET	1
202-91090		1.88 GASKET	5
202-91140		14.68 NIPPLE	1
202-91140/6	second hand	10.00 NIPPLE	2
202-91150		15.33 NIPPLE	1
202-91360		50.04 CONNECTION	1
202-91400		105.09 SWITCH	9
202-91710		4.07 bush	6
203-10830		42.82 FULCRUM	1
203-10841		29.68 GOVERNOR LEVER	3
203-10841		29.68 GOVERNOR LEVER	3
203-10841/6	second hand	29.68 GOVERNOR LEVER	1
203-10890		16.43 LINK	1

203-10904		8.54 SPEEDER SPRING	3
203-11130		0.49 JOINT	22
203-11140		132.25 PINION	1
203-11150		168.38 GEARWHEEL	2
203-11171/6	second hand	234.21 FUEL PUMP HOUSING	1
203-11261		8.84 BRACKET	4
203-11331		272.51 CAMSHAFT	1
203-11340		50.84 SUPPORT	2
203-11371		ask OILPIPE	2
203-11400		4.18 JOINT	19
203-11570/6	second hand	80.12 COVER	7
203-11580		3.04 JOINT	4
203-11610		ask BOWL	3
203-11640		116.15 FUEL PIPE	4
203-11641		139.98 FUEL PIPE	2
203-11860		22.66 OIL OPIPE	2
203-11861		20.19 OIL OPIPE	5
203-12080		5.38 OIL PIPE	5
203-12420		14.53 SHIELD	6
203-12550		14.89 RELIEF VALVE	1
203-12572		1.21 SEAT	5
203-12681		272.51 CAMSHAFT	1
203-12691		ask COVER	7
203-12801		21.58 STUD	29
203-13570		4.72 DOWEL	16
203-13710		3.92 OIL PIPE	9
203-13991		261.29 MANIFOLD	1
203-14380		19.76 CLUTCH SPRING	5
203-14390/6	second hand	ask HOUSING	1
203-15870		36.59 CHAIN	2
203-17081		17.07 WENT PIPE	2
203-17091		48.36 FUEL PIPE	8
203-17132		90.97 FUEL PIPE	2
203-17881		71.23 STRAINER	1
203-17883		55.22 STRAINER	4
203-17941		0.35 BRACKET	2
203-17942		0.68 BRACKET	1
203-17960		8.00 SWIVEL UNION	5
203-17990		5.90 PIECE	1
203-18000		13.72 PLUG	6
203-18060		10.94 SHIELD	1
203-18090		2.82 PIN	4
203-18100		2.56 LEVER	4
203-18121		19.71 DISTANCE PIECE	2
203-18130		4.65 WASHER	15
203-18150/6	second hand	52.65 PLATE	1
203-18160		108.87 COUPLING DISC	2
203-18390		46.90 SHAFT	1
203-18400		28.97 BRACKET	3
203-18410		6.17 LEVER	2
203-18420		1.52 LEVER	2
203-18480		ask LEVER	1
203-18490		ask LEVER	1
203-19961		0.38 JOINT	9
203-20040		8.14 FLANGE	2
203-20060		1.49 JOINT	4

203-20080		5.90 COLLAR	11
203-20135		ask EXTENSION SHAFT	1
203-21801/6	second hand	136.96 ADAPTOR	1
203-21950		3.00 JOINT	4
203-23430		12.85 BOLT	9
203-23970		18.79 DISTANCE PIECE	3
203-24811		1.99 O RING	17
203-26610		17.11 PLATE	1
203-31000		87.75 MANIFOLD	4
203-31001		146.16 MANIFOLD	1
203-31003		96.90 MANIFOLD	1
203-31010		73.54 MANIFOLD ADAPTOR	8
203-31961		11.58 FUEL PIPE	1
203-32130		ask BRACKET	9
203-32140		ask BRACKET	9
203-32470		2.47 FUEL FILTER ELEMENT	8
203-32490		1.50 O RING	9
203-32500		ask WASHER	2
203-33540		65.06 FAN	1
203-34070		78.24 FUEL PIPE	4
203-35560		145.61 MANIFOLD ADAPTOR	5
203-35570		2.84 SUPPORT BRACKET	1
203-36060		ask DISTANCE PIECE	2
203-36070		ask DISTANCE PIECE	2
203-38701		ask FUEL PIPE	4
203-38702		122.45 FUEL PIPE	2
203-38740		90.13 FUEL PIPE	1
203-40750		4.93 SPACING WASHER	5
203-41963		237.16 FLYWHEEL	1
203-44871		6.31 FUEL PIPE	2
203-50356		ask PIPE	2
203-50780/6	second hand	5.18 SIDE SHIELD	1
203-50800		157.96 SIDE SHIELD	2
203-50800/6	second hand	140.60 SIDE SHIELD	2
203-51070		ask CAMSHAFT	1
203-51080		ask CAMSHAFT	2
203-51640		28.46 DISTANCE PIECE	9
203-55050		47.52 OIL OPIPE	4
203-55340		66.48 CRANKCASE DOOR	1
203-55340/6	second hand	66.48 CRANKCASE DOOR	2
203-55410		130.78 OIL PIPE	7
203-55410		130.78 OIL PIPE	7
203-55440		153.14 CRANKCASE DOOR	1
203-55690		71.73 BRACKET	1
203-55750		1.27 O RING	4
203-81070		ask CAMSHAFT	1
203-81230		23.21 SHAFT EXTENSION	2
203-81260		246.45 MANIFOLD	1
203-81681		42.20 PIPE	7
203-81690		1.17 JOINT	12
203-81730		10.05 NIPPLE	2
203-81750		16.82 SPRING	2
203-81760		13.42 SCREW	2
203-81810		1.74 CLAMP	2
203-81820		5.42 BRACKET	2
203-82180		175.60 COUPLING DISC	7

203-82352		13.64	SPRING	1
203-82360		0.39	RETAINING PLATE	4
203-82370		36.88	PLUG	26
203-82370		36.88	PLUG	26
203-82600		117.08	MANIFOLD ADAPTOR	3
203-82640		25.75	BRACKET	1
203-82760		136.30	MANIFOLD	2
203-82760/6	second hand	121.00	FLANGE ADAPTOR	1
203-82770		134.51	FUEL PIPE	1
203-82790		32.42	PIPE	1
203-82820		82.19	ADAPTOR	10
203-82850		12.63	SUPPORT BLOCK	11
203-82870		3.09	SUPPORT STRAP	13
203-82880		19.14	FUEL PIPE	15
203-82890		15.87	PIPE	6
203-90732		46.20	COVER	2
203-90740		5.44	DOOR JOINT	2
203-90750		176.55	MANIFOLD	2
203-91360		24.99	FLANGE	1
203-91520		37.24	PIPE	1
203-91550		28.99	PIPE	2
203-91560		50.69	PIPE	3
204-00189		1.26	COLLETS	19
204-11152		126.12	GEARWHEEL	1
204-11203	ask		COVER	1
204-12000		17.84	SHACKLE	11
204-12010		9.08	ROD	5
204-13141	ask		PINION	1
204-13670		1.90	PIN	13
204-15420	ask		FLANGE	2
204-18150	ask		FLANGE	3
204-19613	ask		PINION	1
204-20420		0.32	JOINT	8
204-20460		1.95	HOSE	3
204-21480		15.14	ADJUSTING SLEEVE	9
204-21491		0.65	IDLER SPRING	15
204-21500		3.03	LOCK NUT	2
204-22340		157.43	COULING	6
204-22770		69.47	HOUSING	2
204-22770/6	second hand	69.47	HOUSING	1
204-23560		1.17	FUEL HOSE	41
204-23600		10.62	SPRING	3
204-23610		1.38	PACKING DISC	4
204-23611		0.05	SHIM	10
204-24630		3.66	THRUST WASHER	1
204-25240	ask		LEVER	1
204-50003	ask		CRANKSHAFT	1
204-52331		2.08	THRUST WASHER	2
204-52940		12.31	CONNECTION	5
204-52970		135.97	FUEL PIPE	1
204-53090		254.32	AIR CLEANER	2
204-53540		0.55	PLUG	17
204-53550	ask		DISTANCE PIECE	46
204-54100		102.92	HOUSING	1
205-00195	ask		VALVE	3
205-20140	ask		PIPE	1

208-00016	ask	PISTON	6
208-00216		0.25 CIRCLIP	23
208-20111	ask	SHAFT	2
210-00121	ask	BEARING	2
210-00127	ask	JOINT	6
210-00143		3.33 CLUTCH PIN	1
210-00249		31.26 LEVER	2
210-00250		115.08 RING	2
210-00259		2.75 SPRING	2
210-00263		9.15 PIN	1
210-00372	ask	FELT RING	3
210-00393		0.57 BALL VALVE	51
210-00510	ask	VALVE	4
211-00461		12.55 FLANGE	2
211-22070	ask	BEARIING HOUSING	1
218165/2D	ask	ELEMENT	1
224-14340	ask	SHAFT	1
251-07820	ask	EXTENSION SHAFT	1
270-00001		0.25 NUT	7
270-00002		0.25 NUT	133
270-00003		0.28 NUT	6
270-00004		0.34 NUT	27
270-00005		0.48 NUT	3
270-00007		4.10 NUT	14
270-00008		1.09 NUT	10
270-00009		4.71 NUT	81
270-00012		1.03 NUT	41
270-00013		0.48 NUT	21
270-00014		0.82 NUT	9
270-00015		1.61 NUT	32
270-00017	ask	STUD	3
270-00023		0.26 BOLT	67
270-00024		0.43 BOLT	12
270-00025		0.54 BOLT	115
270-00026		1.53 SCREW	1
270-00027		3.59 BOLT	24
270-00029		2.39 SCREW	23
270-00030		6.86 SCREW	25
270-00033	ask	SCREW	19
270-00034		1.40 BOLT	4
270-00036		0.62 NUT	30
270-00042		1.09 NUT	15
270-00043		7.18 NUT	2
270-00046		4.82 NUT	12
270-00047		3.25 NUT	26
270-00049		0.55 CAPSCREW	46
270-00051		6.57 SCREW	74
270-00052		1.10 SCREW	46
270-00055		0.34 SETSCREW	1163
270-00056		0.26 BOLT	20
270-00057		3.66 BOLT	50
270-00058		0.62 SETSCREW	2
270-00059		0.26 SETSCREW	14
270-00060		0.48 SETSCREW	21
270-00062		0.78 SETSCREW	77
270-00064		0.60 SETSCREW	25

270-00065	0.64 SETSCREW	35
270-00066	0.76 SETSCREW	546
270-00067	0.80 BOLT	20
270-00068	0.64 BOLT	6
270-00069	0.69 BOLT	2
270-00070	0.68 SCREW	30
270-00071	0.74 BOLT	16
270-00072	0.95 SETSCREW	19
270-00073	0.47 BOLT	5
270-00075	0.58 BOLT	27
270-00076	0.42 BOLT	40
270-00078	0.19 BOLT	15
270-00079	3.23 STUD	2
270-00080	0.69 STUD	22
270-00082	0.71 STUD	3
270-00083	0.65 STUD	401
270-00084	0.93 STUD	2
270-00085	4.41 STUD	13
270-00086	2.32 STUD	20
270-00087	1.09 STUD	19
270-00088	1.19 STUD	5
270-00089	1.60 STUD	30
270-00090	3.41 STUD	1
270-00091	0.39 STUD	19
270-00092	2.93 STUD	25
270-00093	0.44 STUD	1
270-00094	2.79 STUD	6
270-00096	3.33 STUD	49
270-00098	1.97 STUD	31
270-00102	0.39 SCREW	3
270-00103	0.29 SETSCREW	22
270-00106	0.73 BOLT	45
270-00108	1.75 CAPSCREW	12
270-00109	0.27 PIECE	5
270-00110	0.63 STUD	17
270-00111	1.45 STUD	10
270-00112	6.11 SCREW	2
270-00113	0.43 BOLT	7
270-00114	0.39 BOLT	3
270-00115	0.18 BOLT	50
270-00117	1.19 STUD	2
270-00118	2.43 STUD	11
270-00119	0.98 SCREW	18
270-00120	0.66 STUD	6
270-00121	0.58 BOLT	4
270-00122	0.49 BOLT	35
270-00123	3.31 STUD	130
270-00124	2.29 STUD	2
270-00127	1.50 STUD	9
270-00128	1.51 STUD	25
270-00129	1.92 STUD	1
270-00130	ask STUD	2
270-00131	0.87 STUD	9
270-00136	0.29 NUT	30
270-00139	ask NUT	30
270-00143	6.31 STUD	19

270-00145		1.68 BOLT	5
270-00147		3.92 BOLT	28
270-00149		1.21 BOLT	6
270-00150/9	non genuine	3.43 NUT	1
270-00153		1.13 LOCK NUT	51
270-00154		1.19 NUT	13
270-00155		1.27 STUD	12
270-00159		1.73 NUT	2
270-00160		3.44 STUD	30
270-00162		0.62 SETSCREW	16
270-00163	ask	STUD	20
270-00164		1.50 STUD	24
270-00165		3.12 STUD	30
270-00166		2.85 SCREW	1
270-00167		0.66 STUD	30
270-00169		2.03 SETSCREW	9
270-00170		3.50 STUD	33
270-00172		0.65 SCREW	7
270-00174		1.54 CAPSCREW	25
270-00175		1.85 STUD	25
270-00176		1.41 BOLT	30
270-00177		0.98 CAPSCREW	30
270-00179		5.17 STUD	15
270-00180		1.45 STUD	2
270-00181		2.22 STUD	25
270-00182		0.47 BOLT	115
270-00183		2.05 SCREW	50
270-00184		0.33 SCREW	2
270-00185		2.29 CAPSCREW	2
270-00186		3.57 BOLT	50
270-00187		1.43 BOLT	54
270-00189		3.22 SCREW	11
270-00190		0.48 CAPSCREW	12
270-00193		1.13 SCREW	9
270-00195		0.51 CAPSCREW	20
270-00200		2.46 SCREW	16
270-00204		0.47 BOLT	19
270-00205		0.30 BOLT	77
270-00208		0.25 SCREW	11
270-00211		0.59 SETSCREW	8
270-00216		1.68 SCREW	24
270-00221		0.60 BOLT	3
270-00222		1.15 BOLT	43
270-00225		4.82 SETSCREW	31
270-00230		2.31 SCREW	12
270-00231		0.64 BOLT	20
270-00235		0.98 CAPSCREW	17
270-00236		2.81 LOCK NUT	13
270-00239		0.68 SCREW	49
270-00242		4.59 STUD	15
270-00243		0.59 STUD	20
270-00244		0.61 SCREW	11
270-00245		1.14 BOLT	20
270-00247		3.32 STUD	11
270-00248		1.51 STUD	12
270-00249		5.77 STUD	8

270-00252	10.09 BOLT	39
270-00258	0.74 CAPSCREW	15
270-00259	2.98 STUD	6
270-00263	2.30 SCREW	30
270-00268	1.80 NUT	20
270-00272	0.71 SCREW	27
270-00274	1.20 BOLT	3
270-00277	ask STUD	2
270-00279	2.19 CAPSCREW	1
270-00284	1.45 STUD	10
270-00285	0.34 BOLT	9
270-00286	0.83 SCREW	114
270-00287	0.32 SCREW	39
270-00288	0.60 SCREW	166
270-00289	1.26 STUD	12
270-00290	0.78 STUD	5
270-00293	2.36 SCREW	6
270-00294	0.34 BOLT	3
270-00295	3.89 CAPSCREW	6
270-00297	11.30 STUD	2
270-00298	1.53 STUD	20
270-00299	1.08 CAPSCREW	3
270-00301	0.96 SCREW	46
270-00306	1.42 STUD	6
270-00307	1.25 BOLT	93
270-00310	1.45 SCREW	6
270-00311	1.63 NUT	60
270-00317	1.13 BOLT	6
270-00318	1.07 STUD	14
270-00320	1.09 STUD	26
270-00323	1.40 STUD	7
270-00326	ask STUD	1
270-00327	1.09 CAPSCREW	50
270-00328	ask CAPSCREW	15
270-00329	0.70 SETSCREW	10
270-00330	1.77 BOLT	35
270-00331	10.59 BOLT	18
270-00334	0.88 STUD	2
270-00336	3.22 STUD	48
270-00337	0.62 STUD	20
270-00340	0.48 LOCK NUT	25
270-00341	0.90 BOLT	35
270-00342	3.65 STUD	28
270-00344	2.56 BOLT	11
270-00348	2.63 STUD	11
270-00349	0.80 SETSCREW	80
270-00350	0.85 SETSCREW	3
270-00352	4.65 BOLT	30
270-00354	ask CAPSCREW	20
270-00355	2.52 STUD	7
270-00356	2.29 STUD	3
270-00359	1.71 BOLT	20
270-00360	1.19 SCREW	6
270-00366	0.38 BOLT	25
270-00370	3.60 BOLT	3
270-00372	0.51 STUD	6

270-00373	0.81 BOLT	6
270-00374	0.96 BOLT	7
270-00375	1.45 PIECE	10
270-00376	2.05 SCREW	9
270-00377	4.04 STUD	3
270-00380	1.70 STUD	1
270-00384	2.77 CAPSCREW	30
270-00385	0.25 SETSCREW	30
270-00386	4.04 SCREW	20
270-00387	0.50 STUD	25
270-00388	0.34 SETSCREW	30
270-00389	1.58 BOLT	50
270-00390	1.05 STUD	30
270-00392	2.64 STUD	75
270-00394	5.77 STUD	6
270-00395	0.14 SCREW	16
270-00396	1.77 STUD	2
270-00397	1.11 SCREW	1
270-00398	2.14 STUD	1
270-00399	0.61 SCREW	20
270-00401	0.80 STUD	8
270-00404	0.31 SETSCREW	1
270-00405	0.48 SCREW	101
270-00410	0.21 BOLT	6
270-00414	1.66 STUD	6
270-00415	4.60 STUD	10
270-00416	4.53 BOLT	2
270-00417	5.38 BOLT	2
270-00418	2.80 BOLT	11
270-00424	14.87 BOLT	19
270-00427	0.95 BOLT	20
270-00431	3.91 STUD	12
270-00438	4.61 SCREW	7
270-00445	0.32 NUT	30
270-00451	7.33 STUD	9
270-00452	0.64 STUD	1
270-00454	1.04 SCREW	10
270-00457	0.81 BOLT	20
270-00461	4.47 STUD	5
270-00462	1.58 SCREW	10
270-00470	0.27 SCREW	15
270-00471	2.00 STUD	21
270-00474	1.79 BOLT	4
270-00477	2.10 STUD	1
270-00481	1.41 STUD	54
270-00483	0.37 NUT	42
270-00485	0.80 BOLT	2
270-00486	0.84 BOLT	22
270-00487	3.46 BOLT	3
270-00488	0.53 BOLT	25
270-00490	0.97 STUD	22
270-00491	1.66 BOLT	19
270-00502	6.93 SCREW	30
270-00512	0.63 BOLT	16
270-00524	0.38 BOLT	7
270-00526	1.20 SETSCREW	4

270-00531	0.66 SCREW	30
270-00538	0.40 NUT	1
270-00539	3.05 SCREW	20
270-00540	0.25 BOLT	10
270-00543	4.92 STUD	25
270-00544	0.64 STUD	12
270-00547	3.17 STUD	4
270-00548	1.45 BOLT	2
270-00551	1.98 BOLT	210
270-00553	4.02 SCREW	3
270-00556	0.53 SETSCREW	5
270-00557	2.93 STUD	20
270-00561	0.52 STUD	7
270-00564	4.09 STUD	4
270-00579	2.30 LOCK NUT	1
270-00581	0.49 SETSCREW	2
270-00582	ask SCREW	18
270-00583	3.96 STUD	10
270-00583	3.96 STUD	10
270-00587	1.68 SETSCREW	5
270-00594	0.65 STUD	16
270-00595	1.17 STUD	20
270-00601	5.46 SCREW	1
270-00605	1.77 STUD	9
270-00609	1.67 STUD	1
270-00617	2.94 CAPSCREW	20
270-00618	1.86 BOLT	4
270-00631	4.62 SCREW	1
270-00655	4.23 SCREW	10
270-00664	0.62 SCREW	145
270-00674	3.96 BOLT	22
270-00680	1.11 STUD	21
270-00682	0.51 STUD	1
270-00683	2.69 SETSCREW	15
270-00684	1.22 SCREW	1
270-00687	4.23 STUD	19
270-00707	1.85 STUD	20
270-00712	0.79 STUD	1
270-00715	4.82 SCREW	16
270-00717	0.58 STUD	20
270-00721	1.81 STUD	5
270-00728	ask BOLT	8
270-00734	0.97 SCREW	14
270-00738	1.34 SCREW	30
270-00739	ask STUD	4
270-00745	4.90 SCREW	9
270-00756	3.45 BOLT	1
270-00765	1.51 CAPSCREW	11
270-00777	2.10 BOLT	2
270-00778	0.62 NUT	40
270-01075	ask BOLT	1
272-00002	0.25 NUT	48
272-00002	0.25 NUT	48
272-00004	0.48 NUT	40
272-00005	0.37 NUT	74
272-00006	1.99 NUT	109

272-00008	4.42 NUT	34
272-00010	0.03 NUT	16
272-00011	0.05 NUT	130
272-00012	3.20 NUT	101
272-00013	5.08 NUT	188
272-00017	1.09 LOCK NUT	20
272-00018	1.37 NUT	59
272-00020	4.88 LOCK NUT	5
272-00023	1.08 NUT	20
272-00024	0.58 LOCK NUT	6
272-00025	0.92 NUT	36
272-00026	0.34 NUT	35
272-00027	2.46 NUT	27
272-00028	2.45 NUT	15
272-00029	7.28 LOCK NUT	8
272-00031	0.88 CAPSCREW	36
272-00033	ask SCREW	34
272-00035	0.55 SETSCREW	12
272-00036	0.42 SETSCREW	51
272-00037	0.69 SETSCREW	24
272-00038	0.69 SETSCREW	75
272-00040	0.74 SETSCREW	60
272-00041	0.96 SETSCREW	156
272-00042	0.65 SETSCREW	20
272-00043	0.78 BOLT	20
272-00044	0.98 SETSCREW	4
272-00046	1.30 SETSCREW	14
272-00047	1.30 SETSCREW	10
272-00048	2.10 SETSCREW	5
272-00050	1.55 BOLT	18
272-00052	0.18 SCREW	23
272-00053	0.23 BOLT	23
272-00054	1.30 STUD	10
272-00055	2.00 STUD	20
272-00056	1.25 STUD	26
272-00057	2.36 STUD	3
272-00058	0.87 STUD	21
272-00060	2.68 STUD	46
272-00061	0.25 SCREW	12
272-00062	0.25 SCREW	20
272-00063	0.49 SETSCREW	35
272-00064	0.29 SCREW	8
272-00065	0.86 STUD	5
272-00066	0.48 NUT	4
272-00067	1.85 SETSCREW	6
272-00068	1.70 STUD	15
272-00069	0.22 SPRING WASHER	124
272-00070	0.25 SPRING WASHER	82
272-00071	0.25 SPRING WASHER	20
272-00072	0.25 SPRING WASHER	76
272-00073	0.25 SPRING WASHER	2
272-00074	0.25 SPRING WASHER	26
272-00077	0.15 SCREW	21
272-00078	4.61 STUD	23
272-00080	1.51 SETSCREW	30
272-00081	6.80 SETSCREW	7

272-00082	0.44 SCREW	58
272-00086	0.25 WASHER	10
272-00089	0.25 SPRING WASHER	3
272-00090	0.19 WASHER	10
272-00093	ask SPRING WASHER	2
272-00101	2.86 STUD	14
272-00103	0.35 SCREW	14
272-00104	0.76 BOLT	12
272-00106	0.81 SETSCREW	45
272-00107	1.38 SETSCREW	3
272-00108	1.26 STUD	18
272-00109	0.87 STUD	12
272-00110	6.81 STUD	6
272-00111	0.41 STUD	1
272-00112	1.17 STUD	3
272-00113	2.56 NUT	3
272-00114	5.41 NUT	3
272-00115	0.83 BOLT	17
272-00116	3.21 BOLT	21
272-00117	2.46 SETSCREW	14
272-00118	1.13 SETSCREW	6
272-00120	0.25 SCREW	16
272-00122	7.67 STUD	9
272-00124	2.34 BOLT	38
272-00131	3.93 STUD	14
272-00132	0.40 SETSCREW	30
272-00133	1.67 SCREW	5
272-00135	2.29 STUD	4
272-00136	2.43 STUD	19
272-00137	1.81 STUD	7
272-00138	0.30 BOLT	3
272-00140	0.11 SCREW	3
272-00142	2.41 BOLT	10
272-00143	0.11 BOLT	24
272-00146	7.92 STUD	1
272-00147	1.52 STUD	3
272-00149	0.09 BOLT	25
272-00150	0.39 BOLT	3
272-00151	0.87 NUT	32
272-00152	2.72 NUT	10
272-00155	5.33 NUT	11
272-00165	0.54 SETSCREW	24
272-00166	1.06 SETSCREW	63
272-00167	0.49 CAPSCREW	7
272-00168	1.63 BOLT	20
272-00169	0.64 BOLT	75
272-00172	0.12 BOLT	7
272-00174	1.52 SCREW	25
272-00182	3.63 CAPSCREW	10
272-00185	2.31 BOLT	6
272-00186	0.23 BOLT	3
272-00187	0.39 SCREW	31
272-00191	0.58 BOLT	22
272-00194	0.25 SCREW	20
272-00199	11.79 SPANNER	1
272-00204	0.18 ALLAN KEY	3

272-00205		0.08 SCREW	4
272-00207		1.85 CAPSCREW	4
272-00212		0.80 BOLT	24
272-00222		0.35 SCREW	4
272-00227		0.09 SCREW	12
272-00228		2.10 BOLT	14
272-00241		0.78 SETSCREW	8
272-00244		0.03 WASHER	7
272-00252		1.16 BOLT	1
272-00254		1.06 BOLT	2
272-00256		0.76 BOLT	6
272-00257		1.84 CAPSCREW	142
272-00260		0.25 BOLT	2
272-00261		1.79 SCREW	6
272-00275		0.72 CAPSCREW	1
272-00282		0.34 SCREW	27
272-00302		6.13 STUD	10
272-00305		1.44 STUD	18
272-00306		1.81 STUD	14
272-00307		1.84 STUD	1
272-00308	ask	SCREW	9
272-00311	ask	SPRING WASHER	3
272-00343		0.76 CAPSCREW	3
272-00344		0.25 SCREW	3
272-00349		0.39 SCREW	5
272-00364		0.25 WASHER	166
272-00366		2.89 STUD	17
272-00379		0.61 NUT	1
272-00380		0.76 NUT	2
272-00381		1.17 SCREW	5
272-00605		1.66 STUD	4
272-00618		1.84 STUD	11
272-00621		1.35 SCREW	6
272-00668		0.70 BOLT	2
272-00680		0.35 NUT	40
272-00687		0.36 WASHER	7
272-00688		0.36 WASHER	4
272-00694		0.35 WASHER	2
272-00706		0.80 SCREW	6
272-00715		0.34 WASHER	18
272-00717		0.35 SETSCREW	1
272-00728		0.37 SCREW	4
272-00730		1.42 STUD	16
272-00751		0.25 WASHER	6
272-00757		0.87 STUD	4
272-00759		0.55 BOLT	1
284985/6	exchange	41.67 FUEL PUMP	1
291-2001/2S	ask	CRANKCASE	1
291-20030		98.64 CONNECTING ROD	1
291-20050		9.73 BOLT	8
291-20060/010		60.83 MAIN BEARING	1
291-20060/040		63.73 MAIN BEARING	1
291-20100	ask	COVER	1
291-20120		4.95 STUD	27
291-20140		10.99 SCREW	9
291-20170		0.35 JOINT	1

291-20180		0.74 JOINT	60
291-20190		14.56 SHAFT	1
291-20200		1.50 SCREW	4
291-20240	ask	OIL OPIPE	1
291-20270		10.28 VALVE	3
291-20300		1.66 SPRING	6
291-20320		80.88 PINION	1
291-20331		106.44 SHAFT	3
291-20340	ask	GUIDE	3
291-20360	291-02036 ask	JOINT	21
291-20360		0.35 JOINT	21
291-20370		0.18 CIRCLIP	1
291-20430		3.22 SPRING	1
291-20440		5.02 SPRING	1
291-20461		5.51 BUSH	2
291-20470		88.39 PINION	1
291-20480		88.00 PINION	3
291-20530		9.20 SCREW	2
291-20540		1.49 WASHER	5
291-20550	291-02055 ask	PISTON	2
291-20550		82.29 SHAFT	2
291-20560		7.96 BOLT	1
291-20590		1.50 KEY	8
291-20601		10.87 VALVE	5
291-20611		9.80 EXHAUST VALVE	6
291-20620		8.09 VALVE GUIDE	3
291-20671		3.36 VALVE SPRING CARRIER	2
291-20690		39.24 ROCKER ARM	14
291-20720		57.64 BRACKET	10
291-20740		0.34 PLATE	10
291-20750		0.73 WASHER	3
291-20760		1.50 SCREW	20
291-20770		0.66 STUD	38
291-20800		35.45 JOINT	9
291-20810		5.49 JOINT	5
291-20840		1.24 JOINT	5
291-20861		18.03 BAR	7
291-20870		5.45 STUD	8
291-20890		1.70 NUT	3
291-20900		1.50 SCREW	5
291-20910		14.56 OIL OPIPE	2
291-20980		1.50 SPRING	12
291-20990		6.23 STUD	3
291-21040		18.98 BRACKET	9
291-21061		28.03 LEVER	2
291-21070		12.28 SPRING	4
291-21080		10.95 PLUG	5
291-21128		38.72 CHAMBER	1
291-21130		30.66 C O VALVE	22
291-21131		30.66 C O VALVE	1
291-21141		6.42 UNION	17
291-21151		2.82 UNION NUT	15
291-21161		1.03 NIPPLE	18
291-21181		20.90 OIL PIPE	5
291-21200		24.73 PIPE	10
291-21232		5.51 CLAMP	1

291-21240	1.24 SCREW	15
291-21320	14.84 GUIDE	1
291-21330	1.24 KEY	9
291-21470	0.18 JOINT	18
291-21480	ask KEY	8
291-21525	4.31 SPRING	15
291-21530	11.48 OIL SEAL	8
291-21540	3.87 CIRCLIP	34
291-21571	6.19 JOINT	21
291-21580	11.88 JOINT	1
291-21590	2.25 PLUG	3
291-21620	0.69 JOINT	5
291-21630	44.18 BUSH	3
291-21640	83.56 COUPLING FLANGE	1
291-21651	9.43 KEY	6
291-21670	3.24 PLUG	1
291-21690	0.34 JOINT	12
291-21801	43.13 BRACKET	2
291-21810	61.18 ROCKER ARM	1
291-21821	9.20 BUSH	6
291-21830	8.29 SHAFT	4
291-21840	1.23 PIN	11
291-21850	3.71 SHAFT	9
291-21870	4.97 SCREW	8
291-21880	2.36 CAP	1
291-21890	0.34 NUT	14
291-21922	21.99 DISTANCE PIECE	1
291-21931	23.42 PLATE	1
291-21950	0.37 SPRING	10
291-21960	1.50 PIN	13
291-22000	2.36 BOLT	3
291-22020	10.11 ROLLER	12
291-22060	1.50 SCREW	20
291-22082	11.18 LEVER	3
291-22092	3.00 SHAFT	5
291-22103	2.49 WASHER	3
291-22112	1.49 SPRING	3
291-22122	10.07 WASHER	2
291-22130	4.62 SCREW	6
291-22170	24.83 NUT	10
291-22180	6.39 WASHER	2
291-22191	7.10 KEY	3
291-22203	ask SUMP	1
291-22211	2.70 JOINT	9
291-22221	39.02 FLANGE	1
291-22231	ask JOINT	4
291-22252	39.02 FLANGE	1
291-22262	49.33 PIPE	1
291-22300	9.20 LEVER	1
291-22310	2.40 ADJUSTING NUT	15
291-22320	23.42 OIL OPIPE	2
291-22350	3.88 SPRING CAGE	1
291-22371	50.38 COVER	1
291-22380	1.23 PLUG	8
291-22430	1.41 PLUG	5
291-22440	3.39 DOWEL	7

291-22470		1.33 DOWEL PIN	18
291-22491		21.15 OIL PIPE	1
291-22550		8.07 ROLLER BUSH	4
291-22590		9.77 OVERLOCK	1
291-22600		1.49 SPRING	3
291-22610	ask	PIN	5
291-22631		0.34 SCREW	15
291-22640		0.17 WASHER	3
291-22650		0.66 WASHER	34
291-22651		0.23 JOINT	138
291-22666		46.54 COVER	1
291-22671		1.14 JOINT	2
291-22720		2.49 NUT	3
291-22730		8.80 VINCE	1
291-22820		5.30 PIECE	2
291-22830		0.47 JOINT	29
291-22871		0.73 ROLLER	4
291-23040		2.48 FELT	3
291-23110		0.25 CIRCLIP	26
291-23130		4.07 BOLT	1
291-23140		1.50 ROLLER	8
291-23161		6.39 COVER	2
291-23191	ask	BRACKET	10
291-23200		3.30 BRACKET	3
291-23210		0.34 SCREW	2
291-23240		3.32 PIN	7
291-23290		7.07 COVER	2
291-23391		11.65 WASHER	3
291-23542		129.24 OIL RETAINING RING	1
291-23553		37.82 OIL THROWER	2
291-23751		4.21 STRAINER PLATE	1
291-24260	291-02426	0.27 JOINT	21
291-24260		0.35 JOINT	21
291-24370		4.62 SPRING	1
291-24410		4.08 LEVER	1
291-24430		28.76 BEARING	3
291-24472		40.07 LEVER	1
291-24620		1.23 JOINT	7
291-24680		4.60 JOINT	1
291-24691	ask	COVER	1
291-24880		3.22 SHAFT	1
291-24980		2.61 JOINT	2
291-24990		54.99 PLATE	7
291-25011	ask	PUMP HOUSING	3
291-25020		0.09 JOINT	27
291-25030		74.94 PINION	3
291-25074		125.57 GEAR SHAFT	4
291-25104		120.69 GEAR SHAFT	6
291-25110		5.99 BUSH	1
291-25131		50.66 COVER	1
291-25141	ask	HOUSING	1
291-25152		106.21 PLATE	10
291-25161		0.15 JOINT	38
291-25171	ask	PUMP HOUSING	1
291-25181	ask	BOLT	2
291-25191		9.77 BOLT	2

291-25210			0.33 FELT	4
291-25220			0.47 PIN	40
291-25271			1.35 RUBBER RING	15
291-25360			2.61 OIL THROWER	3
291-25470	291-02547	ask	SUCTION PIECE	4
291-25490			13.40 PIPE	8
291-25580			5.49 JOINT	1
291-25591			21.65 OIL OPIPE	2
291-25630			0.57 WASHER	59
291-25630			0.57 WASHER	59
291-25630			0.57 WASHER	59
291-25740			0.35 JOINT	89
291-25770			0.35 JOINT	3
291-25790		ask	HOUSING	1
291-25802		ask	HOUSING	1
291-25850	291-02585		3.61 DOWEL	10
291-25850			3.61 DOWEL	10
291-25860			1.66 PIN	1
291-25880			0.89 JOINT	24
291-26000		ask	WASHER	39
291-26070			5.88 SWIVEL UNION PLUG	13
291-26080			1.23 PLUG	5
291-26090			0.25 WASHER	84
291-26500			23.37 STUD	3
291-26510			4.82 LOCK WASHER	21
291-26550			0.14 JOINT	5
291-26911			9.23 PIPE	4
291-26960			0.60 WASHER	25
291-26970			0.65 WASHER	19
291-27290			0.02 BALL	2
291-27370			0.60 JOINT	3
291-27490		ask	THERMOSTAT HOUSING	2
291-27510			0.43 JOINT	5
291-27560			38.88 PINION	1
291-27570			35.73 PINION	1
291-276211		ask	PIPE	5
291-27640		ask	RING	2
291-27750		ask	CHAIN	1
291-27881			11.88 LEVER	3
291-27900			3.17 WASHER	2
291-28350			24.37 PLUG	3
291-28400	291-02840		0.65 JOINT	4
291-28400			0.68 JOINT	4
291-28450			172.08 FLANGE	1
291-28460			2.49 PLUG	2
291-28470			19.45 NUT	2
291-28480			1.14 WASHER	2
291-28620	291-02862	ask	PIPE	1
291-28620			28.76 BEND	1
291-28630		ask	MANIFOLD	4
291-28710			31.92 COVER	1
291-28730			15.92 FLANGE	1
291-28821		ask	PIPE	1
291-28851			0.15 JOINT	77
291-28860			1.02 WASHER	15
291-29031			21.22 PIPE	1

291-29440		2.80 DISTANCE PIECE	3
291-29623		17.31 FLEXIBLE MOUNTING	1
291-29760		2.23 PIN	1
291-29780		61.85 PINION	3
291-29810		4.68 PLATE	3
291-29870		8.65 PIN	2
291-29880		0.48 CIRCLIP	25
291-29930		0.45 PLUG	1
291-29950		2.43 NIPPLE	10
291-30030		ask WASHER	1
291-30120		69.14 FLEXIBLE PIPE	2
291-30231		304.03 FUEL TANK	2
291-30300		0.51 WASHER	10
291-30340		1.98 SCREW	7
291-30350		4.04 DISTANCE PIECE	8
291-30420		ask BRACKET	7
291-30421		11.95 RETAINING COLLAR	10
291-30520		21.58 LEVER	3
291-30580	291-03058	58.68 PUMP	2
291-30580		59.68 PUMP	2
291-30580/6	second hand	59.68 PUMP	1
291-30610		0.73 SPRING	15
291-30620		0.47 WASHER	5
291-30640		1.43 WASHER	17
291-30730		8.88 LINKAGE ROD	2
291-30730/6	second hand	7.76 LINK PIN	2
291-30740		0.15 JOINT	40
291-30880		9.23 PLUG	5
291-30890		ask OIL THROWER	14
291-30952		114.26 SHAFT	3
291-30962		113.62 SHAFT	2
291-31000		16.22 BOLT	2
291-31010		ask COVER	2
291-31101		67.88 FLEXIBLE PIPE	2
291-31101		67.88 FLEXIBLE PIPE	2
291-31110		48.27 FLEXIBLE PIPE	5
291-31111		42.97 FLEXIBLE PIPE	2
291-31120		2.68 MOUNTING PAD	15
291-31130		7.87 BUSH	16
291-31410		ask PIPE	1
291-31480		ask OIL THROWER	3
291-31490		35.07 OIL THROWER	1
291-31560		222.96 SHAFT EXTENSION	3
291-31570		6.26 COUPLING BOLT	22
291-31590	291-3159c	32.55 FILTER WICK	3
291-31590		32.55 FILTER WICK	3
291-31600		1.95 NUT	8
291-31690		2.49 SPRING	3
291-32240		ask LEVER	2
291-32270		4.26 BRACKET	2
291-32720	291-03272	28.49 WATER PIPE	1
291-32720		37.13 WATER PIPE	1
291-32760		8.50 ADAPTOR	5
291-32840		ask PIPE	1
291-33101		49.76 BRACKET	8
291-33330		ask COVER	1

291-33680		ask	JOINT	6
291-33760			2.09 NUT	20
291-34310			0.21 FELT	4
291-34330			0.14 JOINT	9
291-34340			135.36 SHAFT	1
291-34410			0.15 JOINT	4
291-34780		ask	VALVE	1
291-35120			3.97 RING	1
291-35510			35.07 SHAFT	1
291-36940			0.28 SCREW	42
291-36970			28.62 DYNAMO PULLEY	5
291-37000		ask	PIPE	1
291-37050	291-03705		58.46 AMMETER	15
291-37050			58.46 AMMETER	15
291-37190			208.81 OIL FILTER	1
291-37450			5.21 DISTANCE PIECE	1
291-37460			0.25 SCREW	44
291-37482		ask	HOUSING	1
291-37520/9	non genuine		56.55 OIL SEAL	2
291-37530	291-03753		51.00 END COVER	1
291-37530	291-03753		51.00 END COVER	1
291-37540		ask	PINION	2
291-37550			4.01 KEY	6
291-37590			0.61 JOINT	11
291-37610			15.21 STUD	1
291-37721			106.59 GOVERNOR WEIGHT	2
291-37730			6.69 BOLT	14
291-37900			20.22 PIPE	3
291-37920			12.22 GAUGE ADAPTOR	9
291-38010		ask	CUP	10
291-38300			131.29 FLEX.PIPE	5
291-38380		ask	HOUSING	1
291-38390		ask	CAP	2
291-38480		ask	PINION	2
291-38490		ask	PINION	3
291-39600			35.69 CARBON SEAL DRIVER	12
291-40821		ask	HOUSING	1
291-50030			124.06 CON ROD	3
291-50100			0.28 CIRCLIP	115
291-50150			12.39 EXHAUST VALVE HA	26
291-50190		ask	PISTON RING	26
291-50190/010		ask	PISTON RING	14
291-50210		ask	PISTON RING	16
291-50210/040		ask	PISTON RING	72
291-50570		ask	BRACKET	1
291-50640		ask	PULLEY	2
291-50650		ask	SHAFT	1
291-50800			6.90 VALVE GUIDE HA/HR	8
292-01670			5.01 ADJUSTING SCREW	8
292-10350			0.42 JOINT	4
292-10400			1.49 SHAFT	1
292-10640			3.82 OIL SEAL RING	20
292-11450			0.34 LEVER	4
292-12000			0.64 CIRCLIP	16
292-2000/2		ask	CRANKSHAFT	1
292-20082			4.64 BEARING	2

292-20082/020		6.05 MAIN BEARING	3
292-20110	ask	COVER	1
292-20441		4.98 SPRING	1
292-20800		9.50 JOINT	1
292-20810		3.57 CYL HEAD SHIM	10
292-20850		2.97 JOINT	1
292-20870		2.96 STUD	20
292-21171		12.93 LEAK-OFF PIPE	8
292-21200		24.73 PIPE	15
292-21301		454.63 CAMSHAFT	1
292-21910		15.21 PIPE	1
292-21940		11.34 BRACKET	2
292-22150		54.99 PIPE	1
292-22211		9.20 JOINT	4
292-22341	ask	JOINT	2
292-22520		124.80 NANIFOLD	1
292-22530		0.63 JOINT	2
292-24793	ask	WHEEL	3
292-24900	ask	FLANGE	3
292-26061		12.98 LEAK-OFF PIPE	3
292-29031	ask	PIPE	1
292-29041		19.75 PIPE	1
292-29850		46.50 BEND	1
292-30600	ask	PIPE	2
292-33700		49.33 PIPE	2
293-20821	ask	ROCKER BOX	2
293-20850		5.25 JOINT	3
293-20952		39.39 SHAFT	5
293-22141	ask	PIPE	1
293-22150		77.35 PIPE	1
293-22211		8.99 JOINT	9
293-22341		15.74 JOINT	1
293-22570		35.35 PIPE	1
293-24160		15.26 LINK	2
293-24890	ask	MANIFOLD	1
293-25320		10.07 JOINT	6
293-29030		29.82 PIPE	1
293-29040	ask	PIPE	1
293-32710		31.82 BEND	1
293-40090		40.72 PLUG	6
293-40100	ask	BRACKET	1
293-40290	ask	BRACKET	1
294-06440	294-00644 ask	COVER	1
294-06440		9.23 PIPE	1
294-06480		0.23 JOINT	8
294-06480		0.43 JOINT	8
294-07250		0.21 JOINT	12
294-21360	ask	COVER	2
294-21691		0.60 JOINT	2
294-22262		45.41 PIPE	2
294-23250		10.11 WENT PIPE	3
294-24060		2.06 LOCK	1
294-24070	ask	LINK	3
294-24381		13.25 GUIDE	1
294-24802		0.10 RIVET	12
294-24890	ask	MANIFOLD	1

294-24980	294-02498	ask	JOINT	3
294-24980			12.98 JOINT	3
294-25580		ask	SCREW	1
294-25880			3.00 JOINT	1
294-26520		ask	COVER	2
294-26551			0.37 JOINT	13
294-26560			1.49 JOINT	6
294-26590			3.78 GEAR RING	3
294-27070			6.56 OIL SEAL	3
294-27080			3.39 CROSS PIECE	4
294-27770			6.33 KEY	9
294-27871		ask	LEVER	1
294-29600			5.11 KEY	8
294-29780			70.35 GEAR	2
294-30280			3.18 SPRING	4
294-30280/6	second hand	ask	SPRING	2
294-30290			12.20 SHAFT	2
294-31980			12.95 BALL BEARING	3
294-31990			19.33 PLATE	1
294-32000			2.36 CIRCLIP	19
294-32820			6.92 DISTANCE PIECE	1
294-32830		ask	DISTANCE PIECE	2
294-32840			20.74 FLEXIBLE MOUNTING	2
294-32850			2.80 PILLAR	5
294-32860			47.20 BRACKET	3
294-33070			18.03 HOSE	6
294-33080			1.37 JOINT	3
294-33130			4.13 BOLT	1
294-33470		ask	PIPE	1
294-33500			177.25 GEAR RING	1
294-34600		ask	PLUG	2
294-35750			7.32 KEY	12
294-36420			0.73 JOINT	4
294-37440		ask	DISTANCE PIECE	2
294-37490		ask	COVER	1
294-37500		ask	SHAFT	1
294-37540		ask	PINION	1
294-37590			0.75 JOINT	10
294-37640			14.64 CIRCLIP	4
294-37660			49.25 NUT	3
294-38480		ask	PINION	2
294-38490		ask	PINION	3
294-39850			16.43 BUSH	5
294-39870			103.51 ROCKER ARM	3
294-40241			244.38 BRAKE BAND	1
294-40310			34.53 CLUTCH PLATE	1
294-40690			2.18 SHIM	32
294-41860		ask	BRACKET	1
295-02290			14.06 BUSH	3
295-02310			24.04 BUSH	2
296-00001		ask	HOSE	2
296-21910			28.03 PIPE	1
296-22211			14.90 JOINT	4
296-22522		ask	MANIFOLD	1
296-24802			0.13 RIVET	9
296-24980			11.39 JOINT	1

296-25320	7.62 JOINT	1
296-25880	3.87 JOINT	4
296-31590	ask FILTER WICK	2
296-34590	2.01 BUSH	16
296-34670	ask BOLT	8
296-39620	42.94 SHAFT	5
296-39640	0.73 JOINT	1
296-39950	ask PIPE	2
296-39960	80.88 PIPE	1
3/4 TYPE 106	24.12 SEAL	6
306-02554	ask PULLEY	1
317-00006	29.39 SPANNERADAPTOR	1
317-00015	ask TOOL	2
317-00016	19.11 SPANNER ADAPTOR	1
317-00091	4.72 VALVE SPRING COMPRESSOR	2
317-00146	142.41 CRANKCASE ASSY. TOOL	1
317-00280	ask TOOL	1
317-00287	15.69 INJECTOR SLEEVE TOOL	1
317-00351	38.36 OIL SEAL ASSY. TOOL	1
317-00352	33.99 OIL SEAL ASSY TOOL	1
317-00371	22.81 OIL SEAL ASSY. TOOL	1
317-00750	ask BEARING	1
317-50004	17.68 FLYWHEEL EXTRACTOR	1
317-50087	67.48 TIMING PIN	1
317-50702	9.06 INJECTOR TESTER	13
318812/5FT	30.89 CABLE ASSY	4
32232-7001	30.87 COVER	5
328-10060	41.82 TEMPERATURE SWITCH	2
328-10130	0.63 JOINT	11
328-10170	ask BRACKET	4
328-10180	ask ADJUSTING LINK	8
328-10230	ask NUT	17
328-10260	ask NUT	9
328-10300	ask BRACKET	5
328-10310	ask BOLT	2
328-10340	17.37 HOSE	3
328-10900	251.07 SOLENOID	1
328-11003	9.01 WASHER	4
328-11007	0.21 SPRING	90
328-11008	8.50 PUSH ROD	11
328-11011	0.11 PLUG	6
328-11019	3.76 VALVE STEM CAP	12
328-11027	11.33 OIL FILLER CAP	2
328-11029	0.05 SCREW	8
328-11031	1.14 VALVE SEAL	14
328-11032	2.97 VALVE SEAL	12
328-11054	3.82 SPACER	1
328-11057	2.24 CYL HEAD GASKET	1
328-11058	3.90 DOWEL	6
328-11059	3.90 DOWEL	8
328-11062	0.46 DOWEL	1
328-11067	2.84 PLUG	1
328-11076	8.56 JOINT	2
328-11077	17.11 JOINT	2
328-11093	3.04 PIN	2
328-11099	0.31 SCREW	10

328-11100	0.30 SCREW	10
328-11102	1.42 BOLT	4
328-11105	0.17 SCREW	6
328-11107	0.79 BOLT	4
328-11109	1.50 WASHER	4
328-11110	0.92 WASHER	6
328-11114	13.78 CON ROD BOLT	1
328-11118	0.50 CIRCLIP	10
328-11136	14.55 HOSE	1
328-11139	0.92 CLAMP	8
328-11141	11.74 HOSE	2
328-11142	5.55 HOSE	2
328-11149	0.11 WASHER	3
328-11153	1.59 JOINT	8
328-11154	3.55 NIPPLE	2
328-11159	0.22 BOLT	11
328-11165	0.39 STUD	17
328-11167	1.78 JOINT	1
328-11170	0.16 NUT	6
328-11171	2.87 HOSE	1
328-11177	0.47 SPRING	6
328-11179	1.12 JOINT	3
328-11180	4.44 PLUG	9
328-11182	4.06 SCREW	12
328-11183	48.38 CONNECTOR	1
328-11184	0.28 NUT	8
328-11186	0.52 JOINT	1
328-11190	0.08 SCREW	6
328-11204	0.10 SCREW	6
328-11213	0.09 SCREW	4
328-11217	0.03 WASHER	4
328-11223	0.35 BOLT	167
328-11227	78.91 NOZZLE CST	6
328-11230	0.39 WASHER	8
328-11231/010	2.47 SHIM	85
328-11231/016	2.47 SHIM	66
328-11231/018	2.47 SHIM	80
328-11231/020	2.52 SHIM	81
328-11231/023	1.52 SHIM	5
328-11231/040	1.52 SHIM	5
328-11232	2.60 WASHER	35
328-11233	2.06 WASHER	10
328-11245	0.20 SCREW	6
328-11247	0.84 STUD	6
328-11248	0.03 WASHER	17
328-11263	2.19 JOINT	6
328-11264	0.14 NUT	2
328-11265	21.50 HOSE	2
328-11272	1.04 GASKET	4
328-11273	0.16 WASHER	6
328-11274	1.62 GASKET	6
328-11276	15.87 HOSE	4
328-11310	61.11 CYLINDER	1
328-11390	27.59 VALVE GUIDE CS	17
328-11500	6.96 OIL FILTER ELEMENT	1
328-20090	2.59 GASKET	3

328-21110		37.53 CYL HEAD GASKET	1
328-21200		10.09 CAMSHAFT BEARING	1
328-21690		1.65 SCREW	3
328-21750		3.24 SPACER	3
328-21760		28.30 EXHAUST VALVE CR	3
328-21770		20.02 INLET VALVE CR	8
328-21780		4.61 VALVE SPRING CR	6
328-22290		29.97 GASKET	4
328-22360		6.25 GASKET	1
328-22370		5.92 GASKET	1
328-22390		0.78 BOLT	10
328-22430		6.29 CON ROD BUSH CR	3
328-22470		20.14 SEAL SEAT	1
328-22480		30.45 BEARING	1
328-22491		4.72 GASKET	1
328-22500		57.72 PULLEY	1
328-22520		0.25 GASKET	20
328-22521		0.76 JOINT	1
328-22570		14.13 BELT	9
328-22590		3.72 GASKET	8
328-22680		57.84 NOZZLE CR	3
328-51118		50.88 FUEL LIFT PUMP	1
328-51122		162.30 FUEL FILTER	1
328-51123		13.43 FUEL PIPE	1
328-51124		15.41 FUEL PIPE	1
328-51127		2.045.00 FUEL PUMP	1
328-51153		31.55 FUEL IE	1
328-51154		192.19 INJECTOR CS	1
328-51155		168.12 INJECTOR CST	2
328-51220		97.32 BEARING CS	1
328-51240		9.59 THRUST WASHER CS	2
328-51350		68.64 PISTON RING SET CS	7
328-51370		20.73 BEARING CS	6
328-61190		19.80 BEARING CR	6
328-61250		83.77 THRUST BEARING CR	10
328-61370		35.00 OIL SEAL	1
328-61420		238.61 OIL PUMP	1
328-61460		230.56 PISTON CR	3
328-61510		38.04 BEARING CR	15
328-61540/6	second hand	15.15 WATER PUMP	1
328-61541		161.62 WATER PUMP	1
328-61551		149.09 WATER PUMP KIT	1
328-61570		19.69 FUEL PIPE	2
328-61620		22.60 FUEL PIPE	2
328-61630		24.90 FUEL PIPE	2
328-61640		31.30 FUEL PIPE	2
328-61660		30.53 FUEL PIPE	2
328-61880		221.03 FUEL FILTER	1
328-72260		10.51 OIL FILTER	5
328-73970		20.88 FUEL FILTER ELEMENT	7
328-73980		91.50 NOZZLE CD	4
329-10071		790.13 RADIATOR	3
329-10250		40.83 PULLEY	1
329-10260		43.77 PULLEY	2
329-10300	ask	ADAPTOR	2
329-10710	ask	BRACKET	1

329-10980		10.52 FUEL PIPE	5
329-11210		104.79 SOLENOID	1
329-11870		8.54 ADAPTOR	1
329-12340		27.96 FUEL PIPE	1
329-12400		36.65 CONNECTION	1
329-15130		16.71 ADAPTOR	9
329-20220		81.06 MANIFOLD ADAPTOR	4
329-20280		1.84 JOINT	2
329-20390		9.38 ADAPTOR	5
329-20610		ask SHIELD	1
329-20620		ask SHIELD	1
329-20660		ask BRACKET	1
329-20670		ask BRACKET	1
329-20690		100.10 GUARD	1
329-20720		ask SHIELD	1
329-20730		7.70 GUARD	1
329-20750		ask BRACKET	1
329-20770		ask BRACKET	1
329-20780		ask BRACKET	1
329-20820		73.61 MANIFOLD ADAPTOR	1
329-21860		ask JOINT	10
329-22920		ask ADAPTOR	2
329-23210		36.38 AIR CLEANER ELEMENT	3
329-23620		188.56 SILENCER	1
329-23710		9.91 CONNECTOR	1
329-50030		115.16 MANIFOLD ADAPTOR	1
329-50401		75.55 SWITCHES	1
329-50410		226.91 FUEL SOLENOID	1
329-50550		66.27 EXH.FLANGE	2
329-50720		ask FLEX. EXHAUST	2
329-60230		87.96 FUEL LIFT PUMP KIT	1
329-61370		241.66 EXH.BELLOWS	2
350-83340		ask JOINT	9
351-00060		ask BOLT	3
351-10060		39.35 MAIN BEARING	5
351-10060/020		39.35 MAIN BEARING	1
351-10060/040		39.35 MAIN BEARING	2
351-10180		7.09 LOCATING PLATE	1
351-10180/6	second hand	5.54 LOCATING PLATE	2
351-10210		21.92 VALVE TAPPET	2
351-10210/6		5.30 TAPPET	1
351-10220		5.67 CYL HEAD NUT	3
351-10230		177.63 SHAFT EXTENSION	12
351-10240		12.91 CYL HEAD STUD	3
351-10280		66.79 SHAFT EXTENSION	1
351-10290		26.14 ROCKER LEVER	1
351-10300		3.80 DOWEL	5
351-10361		11.29 INLET VALVE HA	37
351-10390		1.48 JOINT	8
351-10426/6	second hand	904.87 FANSCHROUD	1
351-10431		13.33 STRAINER	2
351-10432		32.41 STRAINER	1
351-10480		3.67 JOINT	2
351-10490		54.56 CYL HEAD COVER	11
351-10501		ask PLATE	3
351-10520		52.27 ROCKER BRACKET	7

351-10520/6	second hand	52.27	ROCKER BRACKET	4
351-10530		54.28	ROCKER BRACKET	4
351-10577		134.94	INJECTOR	6
351-10577/698	exchange	134.94	INJECTOR	8
351-10580/6	second hand	28.18	INJECTOR CLAMP	5
351-10611		23.44	PLUG	1
351-10620		10.65	PIECE	5
351-10620/6	second hand	ask	PIECE	1
351-10690		1.26	LOCATING WASHER	8
351-10700		0.70	PLUG	11
351-10711		212.84	PINION	2
351-10711/6	second hand	189.44	PINION	4
351-10721/6	second hand	169.98	GEARWHEEL	3
351-10722		142.78	GEAR WHEEL	1
351-10730		ask	PINION	1
351-10761/6	second hand	177.39	GEAR	2
351-10810		37.91	THRUST RACE	8
351-10820		1.94	CIRCLIP	6
351-10842		25.93	GOVERNOR BEARING	1
351-10850		0.20	RETAINING RING	2
351-10951		57.47	BRACKET	1
351-10970		6.84	PIN	15
351-10990		0.23	WASHER	45
351-11011		5.41	SPEEDER SPRING	1
351-11012		3.94	SPRING	11
351-11013		5.31	SPEEDER SPRING	2
351-11020		10.72	CONNECTING ROD	7
351-11032		20.84	FORK	25
351-11040		5.42	CONNECTING ROD	21
351-11050		22.96	CONNECTING ROD	29
351-11062		18.81	OVERLOAD STOP	13
351-11070		6.84	PISTON	2
351-11071		19.01	LUNGER	1
351-11080		4.61	SPRING	2
351-11090		4.16	BUSH	4
351-11100		4.08	KNOB	4
351-11140		1.90	DISTANCE PIECE	1
351-11151		1.00	SPRING	2
351-11161		2.45	CONTROL LEVER	1
351-11180		0.48	JOINT	9
351-11250		2.78	ADJUSTING SCREW	13
351-11251		2.61	SCREW	2
351-11271		24.51	SUPPORT PLATE	8
351-11342		ask	END COVER	4
351-11343		ask	COVER	3
351-11401		17.22	CLAMP	16
351-11401/6	second hand	15.33	CLAMP	3
351-11470		0.49	PIN	9
351-11472		2.18	PIN	6
351-11480		8.61	BALL BEARING	6
351-11510		3.47	GOV WT SPRING	2
351-11530		10.56	FELT WASHER	2
351-11540		2.13	OIL THROWER	4
351-11580		148.65	FUEL PUMP	2
351-11581/698	exchange	148.65	FUEL PUMP	2
351-11630		2.30	SPACER	1

351-11781/6	second hand	34.84 CONNECTOR	2
351-11810		0.48 SPRING	9
351-11930		3.28 SHIM	12
351-11931		3.65 SHIM	13
351-11934		2.18 SHIM	7
351-11950		8.23 BLANKING PLATE	5
351-12031		90.62 DRIVING SHAFT	1
351-12080		0.82 PIN	1
351-12130		15.56 LOCATING PIN	4
351-12140		2.97 CLAMP	3
351-12160		17.89 BACK PLATE	1
351-12180		10.43 ADJUSTING SCREW	11
351-12190		0.25 JOINT	37
351-12210		0.64 JOINT	14
351-12222		305.32 BRACKET	4
351-12224	ask	COVER	2
351-12260		29.06 BRACKET	1
351-12290		15.46 DISTANCE PIECE	1
351-12300		9.67 ADJUSTING LINK	5
351-12334		103.09 BRACKET	4
351-12400		9.19 ADJUSTING LINK	4
351-12490		28.23 SPINDLE	3
351-12511		91.84 BRACKET	2
351-12542	ask	LEVER	4
351-12560		2.15 ADJUSTING SCREW	8
351-12580	ask	COVER	3
351-12590		1.95 CRANKSHAFT PLUG	3
351-12600		3.76 SCREW	20
351-12620		0.96 JOINT	6
351-12630		8.87 BEARING	1
351-12650		355.50 SHAFT	1
351-12680		1.49 STAY	4
351-12720		20.61 PLUG	1
351-12831		375.43 COVER	1
351-12900		47.24 OIL THROWER	5
351-12920		3.81 SPRING	10
351-12981		0.25 PIN	5
351-13021	ask	BRACKET	2
351-13120		583.75 SHAFT EXTENSION	1
351-13140		17.43 PLATE	3
351-13150		11.97 OIL SEAL	1
351-13160		2.84 JOINT	20
351-13171		188.02 HOUSING	1
351-13280		2.20 CLAMP	1
351-13481	ask	COVER	3
351-13500		66.98 PLATE	2
351-13510		146.15 FLANGE	1
351-13520		40.42 PLATE	3
351-13540		381.20 CLUTCH BODY	1
351-13543	ask	CABLE	5
351-13581		17.07 LIFTING LUG	1
351-13590		50.00 PINION	4
351-13590/6	second hand	50.00 DRIVING GEAR	6
351-13600		79.54 PINION	9
351-13610		46.22 PINION	9
351-13620		157.15 HOUSING	5

351-13630	ask	HOUSING	9
351-13640		133.39 SHAFT	8
351-13650		23.07 COUPLING	10
351-13660		1.48 DOWEL PIN	2
351-13690		0.86 JOINT	6
351-13700		0.77 JOINT	5
351-13730		3.62 BUSH	5
351-13800		0.91 PIN	10
351-13810	ask	PINION	1
351-13830		8.25 BUSH	3
351-13840		53.75 CHAINWHEEL	2
351-13860		9.84 CYL HEAD NUT	12
351-13870		120.94 SPROCKET	3
351-13871	ask	PINION	2
351-13880		5.74 PAD	8
351-13880		5.74 PAD	8
351-13890		9.17 SPRING	7
351-13891		28.76 SPRING	5
351-13930		77.75 TENSIONER	7
351-13931		98.19 TENSIONER	2
351-13940		0.25 JOINT	8
351-13950		70.79 CHAIN	1
351-13980	ask	PINION	4
351-14010		0.78 JOINT	9
351-14020		2.19 JOINT	66
351-14031	ask	BRACKET	2
351-14043	ask	HOUSING	1
351-14060		4.12 OIL THROWER	2
351-14090		8.76 OIL TROUGH	1
351-14100		8.76 TROUGH	4
351-14120		6.19 NUT	5
351-14130		95.29 PULLEY	1
351-14140		56.01 PULLEY	1
351-14810		1.94 WASHER	9
351-14961		37.03 PLUG	35
351-14970		3.97 SPACER	7
351-15011		14.09 SWIVEL UNION PLUG	21
351-15020		6.22 CLIP	5
351-15030		4.13 DOWEL	2
351-15050		1.07 LOCK WASHER	10
351-15121		15.23 ADJUSTING LIMK	2
351-15170		295.06 BEARING HOUSING	1
351-15180	ask	WASHER	1
351-15890		49.48 COVER	1
351-15910	ask	BRACKET	7
351-15962		48.14 CONTROL LEVER	4
351-16002		6.57 NIPPLE	13
351-16011		3.66 CONNECTOR	11
351-16012		2.96 ADAPTOR	26
351-16022		59.70 RATCHET	2
351-16150		34.91 GUARD	7
351-16160		10.62 DISTANCE PIECE	15
351-16170		15.05 SCREW	3
351-16180		146.94 SPIGOT RING	4
351-16191	ask	BEARING	10
351-16210		2.76 PLUG	4

351-16240		ask	BRACKET	2
351-16241			93.15 BEARER	1
351-16280		ask	BRACKET	2
351-16290			32.88 LEVER	4
351-16350			9.44 CONTROL CABLE	4
351-16370			26.13 CONTROL CABLE	1
351-16371			38.00 CABLE & WIRE	3
351-16390		ask	JABSCO PUMP	1
351-16491			7.10 CONTROL ROD	2
351-16500			12.04 BALL JOINT	20
351-16540			58.07 BRACKET	2
351-16620			6.95 DISTANCE PIECE	1
351-16621			5.19 DISTANCE PIECE	16
351-16630			2.33 SHIM	15
351-16661			25.94 BRACKET	3
351-17380			4.69 GROMMET	3
351-17400			35.73 FLEX.PIPE	1
351-17490			0.64 BUSH	10
351-17900			1.08 PLATE	11
351-17910			1.44 DISTANCE PIECE	17
351-18080			3.66 CLIP	5
351-18090			0.31 FELT PAD	10
351-18320			41.80 BEARING HOUSING	2
351-18460			189.50 FLEXIBLE DRIVE	1
351-18870		ask	BRACKET	2
351-18890		ask	OIL OPIPE	1
351-18961			12.85 COVER	1
351-18990			23.56 OIL OPIPE	2
351-19073			20.75 OIL PIPE	3
351-19252		ask	PISTON	2
351-19510			1.90 SPRING	10
351-19910			93.05 FLEXIBLE PIPE	1
351-19920			4.20 CLIP	22
351-19950			8.62 PLATE	13
351-20170		ask	BRACKET	1
351-20612			18.58 VALVE GUIDE	23
351-20622		ask	VALVE SEAT	10
351-21380			19.83 COVER	1
351-21560			24.82 GOVERNOR WEIGHT	1
351-21561		ask	GOVERNOR WEIGHT	3
351-21610			11.80 UNION PLUG	2
351-21620			0.04 JOINT	159
351-21630			3.33 UNION NUT	16
351-21640			0.91 OLIVE	18
351-22010			5.74 SPACER	18
351-24650			3.48 SPRING	1
351-25920		ask	WASHER	2
351-26090			2.14 DISTANCE PIECE	4
351-26800			3.12 SCREW	2
351-28850			58.53 GAUGE PANEL	3
351-28850			58.53 GAUGE PANEL	3
351-32420			6.38 SWIVEL UNION	2
351-32430			8.69 SWIVEL UNION PLUG	2
351-34780/6	second hand		38.47 CONNECTING ROD	1
351-34801		ask	PLUG	9
351-34850			5.62 GOVERNOR SHOE	10

351-34980		1.50 NUT	8
351-34990		1.23 SPRING CLIP	1
351-35910		6.70 GOVERNOR WEIGHT	6
351-36220		8.66 STUD	14
351-36580		0.25 NYLON CAP	5
351-40050	ask	COVER	1
351-40070		3.60 JOINT	18
351-40081		2.57 JOINT	7
351-40091		197.50 INJECTOR HRW	6
351-40091		197.50 INJECTOR HRW	6
351-40091/698	exchange	197.50 INJECTOR HRW	9
351-40111		23.93 CYL BLOCK SLEEVE	31
351-40140		8.62 BREATHER TUBE	7
351-40190		0.76 EXPANSION PLUG	8
351-40201		1.93 O RING	708
351-40260		1.03 PLUG	15
351-40330		330.23 WATER PUMP COVER	1
351-40332	ask	COVER	2
351-40340		0.47 JOINT	224
351-40383		41.55 IMPELLOR	1
351-40460		5.39 DISTANCE PIECE	2
351-40470		64.95 BRACKET	1
351-40490		6.59 ADJUSTING LINK	1
351-40512		178.82 THERMOSTAT BODY	1
351-40551		23.51 JUNCTION PIECE	4
351-40560	ask	PIPE	4
351-40600	ask	PIPE	3
351-40620		1.20 JOINT	2
351-40631		2.95 HOSE	6
351-40640		3.95 HOSE CONNECTION	32
351-40700		19.66 CONNECTION	24
351-40710		34.56 HOSE BEND	1
351-40820		9.12 HOSE CONNECTION	7
351-41271		103.65 PULLEY	2
351-41291	ask	BRACKET	1
351-41330		97.17 THERMOSTAT COVER	1
351-41510		1.44 PLUG	10
351-41571		5.07 BRACKET	1
351-41590		5.66 HOSE	1
351-41880	ask	PULLEY	3
351-41890	ask	PULLEY	1
351-41891	ask	PULLEY	1
351-41910		49.70 DRIVE BELT	1
351-42130		1.47 JOINT	6
351-42400		12.53 DISTANCE PIECE	2
351-42860		54.70 BELT	2
351-42870/6	second hand	54.07 DOOR	8
351-42890		0.33 JOINT	36
351-42940		4.47 HOSE	1
351-43950		38.48 BALL BEARING	5
351-43960		2.30 CIRCLIP	5
351-43980		149.44 SPINDLE	1
351-43981		67.63 SPINDLE	3
351-43990		54.02 BRACKET	1
351-50090		0.76 CIRCLIP	3
351-50101/010	ask	PISTON RING	17

351-50101/020		ask	PISTON RING	14
351-50110/010		ask	PISTON RING	22
351-50110/020		ask	PISTON RING	10
351-50123/010		ask	OIL RING	22
351-50123/020		ask	OIL RING	14
351-50150			52.82 ROCKER BRACKET	6
351-50181			3.03 CYL HEAD GASKET	21
351-50191			0.98 CYL HEAD SHIM	9
351-50192			1.22 CYL HEAD SHIM	2
351-50204/640	EXCHANGE		65.91 CYLINDER ,040 O/S	2
351-50260/030			12.94 BEARING HR/HL	8
351-50260/040			12.94 BEARING HR/HL	5
351-50570			11.40 VALVE SPRING CARRIER	64
351-50791			78.30 INJECTOR HR	14
351-50800			1.47 PLUG	110
351-51080/098			103.96 FUEL PUMP	6
351-51080/698	exchange		92.53 FUEL PUMP	4
351-52540			553.94 HOUR RECORDER	4
351-55650			12.80 STUD	14
351-55660/6	second hand		14.76 SEALING TUBE	12
351-55670			4.81 VALVE GUIDE HL	6
351-55680			1.56 RETAINING PLATE	10
351-55700			4.29 BREATHER TUBE	12
351-55711			84.93 ROCKER LEVER	4
351-55750		ask	DEC.LEVER	4
351-55783/6	second hand		66.60 CYL HEAD COVER	12
351-55790			1.52 RUBBER STRIP	12
351-55881			136.06 INJECTOR	2
351-55890			20.44 INJECTOR CLAMP	8
351-55890/6	second hand		18.19 INJECTOR CLAMP	6
351-55911/6	second hand		13.18 FUEL PIPE	1
351-55990			1.37 JOINT	44
351-57720			16.58 OIL PIPE	12
351-58070			27.08 NOZZLE HL	12
351-59880			62.86 OIL PIPE	1
351-60020			2.07 CYL HEAD GASKET	49
351-60030			1.29 CYL HEAD SHIM	209
351-60560			9.97 STUD	4
351-82690			66.69 LEVER	1
352-11171			5.66 JOINT	8
352-11211			62.56 COVER	4
352-11212			61.05 COVER	2
352-11261			47.79 FUEL PIPE	3
352-11301			222.51 BEARING HOUSING	3
352-11460		ask	BRACKET	26
352-11602			63.57 MANIFOLD	1
352-11840			3.50 O RING	18
352-11890		ask	PIPE	1
352-11891			43.92 OIL PIPE	6
352-11911			2.84 O RING	10
352-12671			35.00 MAIN BEARING	9
352-12671/010			17.54 MAIN BEARING	5
352-12671/020			28.03 BEARING HA	4
352-12671/040			28.03 BEARING HA	6
352-12672		ask	BEARING	3
352-12730			4.65 OIL PIPE	1

352-12740		7.44 OIL PIPE	3
352-12750		7.18 OIL PIPE	3
352-12770/6	second hand	321.53 GEARWHEEL	1
352-12780		346.02 GEAR WHEEL	1
352-12780/6	second hand	313.18 GEARWHEEL	1
352-12971		19.08 GUARD	2
352-13080		51.69 OIL PIPE	5
352-13080/6	second hand	45.15 OIL PIPE	1
352-13090		51.34 OIL PIPE	2
352-13191		24.28 PLATE	5
352-13230		16.82 LINK	1
352-13241	ask	BRACKET	3
352-13341		55.25 SUPPORT	1
352-13351		215.02 MOUNTING FRAME	1
352-13370		35.10 OIL OPIPE	13
352-13390		10.95 LINING	3
352-13450	ask	COVER	11
352-13450/6	second hand	ask COVER	2
352-13451		175.15 CRANKCASE DOOR	1
352-13742	ask	PIPE	1
352-13820		50.08 SHAFT	1
352-14990	ask	PIPE	3
352-15450		26.52 COVER	2
352-15480		0.70 FELT STRIP	1
352-15490		2.84 STUD	2
352-15710/6	second hand	175.47 OUTLET DUCT	2
352-15840	ask	PLATE	1
352-16040		3.19 DISTANCE PIECE	3
352-16050		79.14 GUARD	2
352-16640		15.87 BLANKING PLATE	24
352-16720		8.20 PLUG	2
352-16733	ask	ADAPTOR	5
352-16740		36.59 FLANGE	1
352-16790		30.71 CONNECTION	5
352-16800		2.34 SEAT	1
352-16810		0.16 CIRCLIP	47
352-16840		7.04 BLANKING PLATE	4
352-16920		8.38 LINK	8
352-16920		6.53 COUPLING ROD	8
352-17340		36.73 FUEL PIPE	2
352-17820		2.82 ADAPTOR	6
352-20510		4.03 BRACKET	3
352-23745	ask	PIPE	3
352-24800		1.42 STAY	3
352-26900		1.33 SPRING	2
352-28160	ask	PIPE	1
352-28250	ask	WENT PIPE	1
352-28720		94.90 FUEL PIPE	4
352-28731		9.17 FUEL PIPE	16
352-28760		18.10 UNION	27
352-28760		18.10 UNION	27
352-29960		0.61 WASHER	25
352-30660		50.67 PIPE	2
352-32010	ask	DYNAMO	3
352-32060	ask	RELAIS	1
352-32068	ask	RELAIS	6

352-32070		ask	RELAIS	1
352-32230		ask	ADAPTOR	1
352-32470			8.49 OIL SEAL	1
352-32640			5.39 TIE STRAP	4
352-32800/6	second hand		144.24 COWLING	1
352-35070			81.63 PULLEY	12
352-35080			107.89 PULLEY	11
352-35090			127.88 BRACKET	11
352-35140			7.00 BRACKET	1
352-35760			68.10 ADJUSTING LINK	3
352-36110			13.67 BRACKET	1
352-36121			13.77 BRACKET	1
352-36130		ask	BRACKET	1
352-36131			29.28 BRACKET	1
352-36310			51.52 FUEL PIPE	4
352-36320			56.23 FUEL PIPE	2
352-37130			40.61 STAY	4
352-37140			0.23 WASHER	4
352-37340			46.03 CAM BLOCK	2
352-40211			114.68 CYLINDER DOOR	1
352-40211/6	second hand		114.68 CYLINDER DOOR	3
352-40212			122.27 COVER	2
352-40221/6	second hand		110.62 CYLINDER DOOR	1
352-40272		ask	PIPE	1
352-40293		ask	MANIFOLD	1
352-41430/6	second hand		33.30 DOOR	1
352-41440			91.40 MANIFOLD	2
352-41450			82.25 EXH.MANIFOLD	4
352-42120			147.30 MANIFOLD	1
352-43830			13.90 AIR FILTER ELEMENT	8
352-44380			80.48 PULLEY	3
352-50580			319.92 BEARING HOUSING	1
352-50620			14.68 BEARING HR	4
352-50620/020			14.68 BEARING HR	2
352-50620/040			14.68 BEARING HR	6
352-50670			129.05 BRACKET	1
352-51521			29.54 DECOMPRESSOR SHAFT	1
352-51550			21.87 SCREW	10
352-54980			54.05 VEE BELT	1
352-55390			189.97 MANIFOLD	1
352-55400			113.47 MANIFOLD ADAPTOR	2
352-83340			7.62 JOINT	3
353-10600/6	second hand		281.12 FUEL PUMP HOUSING	1
353-11212		ask	COVER	7
353-11821			162.22 OIL PUMP	1
353-11870			33.22 OIL PIPE	1
353-12100		ask	COVER	1
353-12950			4.45 OIL PIPE	1
353-13230			36.80 CONNECTING ROD	1
353-13726		ask	PIPE	3
353-13742		ask	PIPE	2
353-13820			57.39 SHAFT	1
353-15450			64.86 COVER	9
353-15460			5.35 JOINT	3
353-15500		ask	SHIELD	5
353-16050			75.41 GUARD	1

353-17160		225.11 OIL PIPE	2
353-17170		84.36 OIL PIPE	6
353-24800		1.84 STRAP	1
353-28720		136.90 FUEL PIPE	3
353-32580		27.50 LOCK	1
353-32590		0.90 FELT	1
353-36310		62.60 FUEL PIPE	1
353-36320		62.60 FUEL PIPE	6
353-40272		ask MANIFOLD	1
353-40272/6	second hand	ask MANIFOLD	3
353-40280		550.86 EXH.MANIFOLD	1
353-41440		427.52 MANIFOLD	1
353-41450		464.59 MANIFOLD	3
353-41470		1.83 JOINT	3
353-50670		153.10 AIR DUCT	1
353-55390		213.59 MANIFOLD	4
353-58160		5.17 COUPLING PLATE	2
353-70310		11.12 OIL FILTER ELEMENT	1
353-70310		11.12 OIL FILTER ELEMENT	1
353-70650		87.66 PULLEY	1
353-70840		17.62 VENT PIPE	1
353-71370		6.42 SPRING CLIP	5
353-71460/6	second hand	17.11 LIFTING LUG	1
353-81780		0.48 CIRCLIP	6
353-82100/6	second hand	12.17 TAPPET GUIDE CLAMP	6
353-82400/6	second hand	296.37 PULLEY	1
354-05034		ask COVER	2
354-10160/6	second hand	ask CAMSHAFT	2
354-10161		ask CAMSHAFT	1
354-10161/6	second hand	ask CAMSHAFT	1
354-10170/6	second hand	82.99 BUSH	1
354-10300		3.29 PIN	12
354-10310/6	second hand	ask PUSH ROD	20
354-10311		17.30 PUSH ROD	24
354-10311/6	second hand	15.40 PUSH ROD	13
354-10500		ask PLATE	3
354-10710		ask PINION	1
354-10711		243.26 INION	1
354-10711/6	second hand	243.26 PINION	1
354-10722		380.27 CAMSHAFT GEARWHEEL	1
354-10722/6	second hand	380.27 CAMSHAFT GEARWHEEL	4
354-10770		ask PIN	2
354-10800		22.90 THRUST CAP	6
354-10880		141.61 DISTANCE PIECE	36
354-11350		ask JOINT	2
354-11501		ask GOVERNOR WEIGHT	2
354-11681/6	second hand	40.00 SIDE SHIELD	1
354-11691		18.44 SHIELD	1
354-11691/6	second hand	21.12 SHIELD	2
354-11811		2.30 SPRING	7
354-13510		ask PLATE	2
354-13520		108.42 PLATE	2
354-13530		ask COUPLING	5
354-13951		ask CHAIN	1
354-13961		ask HOUSING	1
354-13980		350.17 PINION	4

354-14020		ask	JOINT	8
354-15621		ask	BRACKET	2
354-15700		1.09	FELT SIDE	14
354-15711		ask	COVER	1
354-15714		221.54	SHIELD	1
354-16050		188.81	GUARD	3
354-16780		ask	VALVE CUP	2
354-17520/6	second hand	ask	BRACKET	1
354-17530/6	second hand	ask	BRACKET	1
354-17540/6	second hand	ask	BRACKET	5
354-18000		279.06	SUMP	1
354-18070		1.94	NIPPLE	1
354-18120		4.42	SUMP JOINT	2
354-18130		ask	STRAINER	2
354-18170		3.72	FLANGE	2
354-18180		26.84	STUD	12
354-18320		240.49	BEARIING HOUSING	3
354-18330/6	second hand	105.47	EXTENSION PLATE	5
354-18350		224.39	MANIFOLD	1
354-18370/6	second hand	230.19	MANIFOLD	4
354-18391/6	second hand	ask	ADAPTOR	3
354-18432		185.78	FUEL PUMP GEAR	2
354-18432/6	second hand	185.78	FUEL PUMP GEAR	4
354-18621		175.77	FAN BRACKET	2
354-18641		ask	FAN	1
354-18661		85.00	FAN SHAFT	3
354-18685		44.70	PULLEY	2
354-18686		45.33	PULLEY	1
354-18740		34.47	DISTANCE PIECE	1
354-18810/6	second hand	ask	PLATE	1
354-18813/6	second hand	99.78	SEALING PLATE	3
354-18820		7.37	SEALING TUBE	17
354-18820/6	second hand	6.56	SEALING TUBE	14
354-18830		0.77	BUSH	1
354-18850/6	second hand	24.82	TAPPET GUIDE	28
354-18853		11.03	GUIDE	1
354-18854		31.66	TAPPET GUIDE	4
354-18854/6	second hand	28.18	TAPPET GUIDE	10
354-18901		51.23	BRACKET	3
354-18910		12.82	BRACKET	3
354-18930		10.44	PLATE	2
354-18940		9.50	PLATE	2
354-18950		0.33	JOINT	25
354-18951		1.22	JOINT	4
354-19012/6	second hand	77.79	GEARWHEEL	1
354-19020		10.39	SHAFT	1
354-19030		14.87	DOWEL	4
354-19040		2.98	DOWEL	3
354-19060		1.48	SCREW	8
354-19140		15.47	COVER	1
354-19270		0.51	JOINT	1
354-19280		98.87	OIL THROWER	1
354-19290		2.35	LOCKING PLATE	5
354-19311		19.90	OIL THROWER	1
354-19330		45.04	BEARING BUSH	1
354-19350		0.87	JOINT	3

354-19400		1.07 JOINT	1
354-19420		13.30 FELT WASHER	1
354-19450		127.69 PLATE	3
354-19460		32.87 OIL THROWER	1
354-19470		0.49 joint	20
354-19480		0.38 JOINT	3
354-19541		143.52 ADAPTOR	4
354-19550		169.58 SHAFT	3
354-19580		7.76 LOCATING PIN	3
354-19581		15.92 LOCATING PIN	4
354-19591		14.49 THRUST WASHER	1
354-19600		1.25 JOINT	24
354-19610		1.29 JOINT	23
354-19622		ask PIPE	1
354-19622/6	second hand	ask PIPE	2
354-19630		0.55 JOINT	17
354-19641		80.56 BRACKET	5
354-19802		172.46 OIL PIPE	1
354-19810		12.30 PLUG	2
354-19820		2.73 RETAINING RING	7
354-19851		64.97 OIL PIPE	1
354-19862		21.16 OIL OPIPE	2
354-19880		12.82 REDUCING BUSH	1
354-19892		21.69 OIL OPIPE	2
354-19902		54.35 OIL OPIPE	1
354-20010/6	second hand	175.04 TACHOMETER GEARWHEEL	1
354-20020		1.63 BUSH	1
354-20030		0.58 WASHER	2
354-20180		ask ADAPTOR	2
354-20210		125.70 SHIELD	1
354-20270		13.67 SHIELD	1
354-20342		34.43 COVER	1
354-20382/6	second hand	28.16 SIDE SHIELD	2
354-20430		2.22 DISTANCE PIECE	1
354-20570		ask BRACKET	1
354-20581		ask FUEL PIPE	3
354-21560		ask GOVERNOR WEIGHT	6
354-21561		ask GOVERNOR WEIGHT	2
354-22510		33.45 LOCATING WASHER	1
354-22510/6	second hand	29.22 LOCATING WASHER	1
354-22531		ask FUEL PUMP	1
354-22550		178.03 SHIELD	1
354-22611		ask SHAFT	4
354-22620		8.05 NUT	9
354-22631		ask JOINT	2
354-22652		217.63 ADAPTOR	2
354-22660		255.95 GOVERNOR CASING	1
354-22670		49.55 COVER	3
354-22740		14.16 COUPLING DISC	9
354-22760		1.88 NUT	1
354-22800		3.36 SPRING	1
354-22860		9.54 SPRING	5
354-22910		21.73 SPRING	4
354-22920		24.62 NUT	2
354-22950		6.47 SCREW	6
354-22970		7.18 LEVER	2

354-23030		0.65 STUD	8
354-23040		23.44 CARRIER	1
354-23050		6.56 SPLIT BOLT	2
354-23060		0.26 JOINT	107
354-23082		9.52 CAP	1
354-23100		4.41 JOINT	3
354-23120		3.19 PLATE	1
354-23221		0.62 PIN	8
354-23230		0.96 SPRING CAGE	1
354-23250		0.85 SCREW	9
354-23260		3.33 PIN	2
354-23270		27.14 OIL OPIPE	2
354-23280		14.51 JOINT	33
354-23430		1.81 RUBBER BUSH	6
354-23470		0.94 NUT	11
354-23492		39.90 PLATE	2
354-23502		62.51 LEVER	1
354-23510		0.90 O RING	8
354-23522		63.59 LEAK-OFF PIPE	2
354-23541	ask	COVER	2
354-23613	ask	SHIELD	1
354-23650		7.16 PLATE	4
354-23840		0.69 JOINT	4
354-23860	ask	PINION	2
354-23870	ask	PINION	3
354-23880	ask	PINION	3
354-23940		63.82 BRACKET	8
354-24040		66.41 GOVERNOR LEVER	2
354-24050	ask	SHAFT	1
354-24060		42.16 DISTANCE PIECE	1
354-24070	ask	BALL BEARING	2
354-24080		119.00 PLATE	4
354-24090		4.82 JOINT	7
354-24101		16.47 DISTANCE PIECE	2
354-24110	ask	BEARING	1
354-24120		3.46 SHIM	8
354-24121		14.44 SHIM	9
354-24230		18.47 ADJUSTMENT	1
354-24240		7.09 CAP	2
354-24250		5.74 SEAT	15
354-24260		1.82 SPRING	18
354-24270		0.46 SPRING	12
354-24301		53.02 LEVER	1
354-24320		9.41 SHAFT	9
354-24330		3.03 SPRING	14
354-24340		6.59 SCREW	11
354-24350		14.44 LEVER	5
354-24400		0.26 WASHER	2
354-24410		19.00 CABLE	1
354-24411		47.43 CABLE & WIRE	5
354-24420		3.19 LEVER	2
354-24420/6	second hand	2.88 POINTER	5
354-24550		4.27 SCREW	10
354-24600		18.99 STUD	11
354-24620	ask	PINION	1
354-24700	ask	DYNAMO	1

354-24740		19.92	SCREW	7
354-24770		9.10	SHIELD	4
354-24770/6	second hand	9.10	SHIELD	7
354-24871		224.09	PULLEY	4
354-24890		0.84	SPACER	17
354-24910		10.22	BRACKET	2
354-24950		2.98	O-RING	11
354-24960		2.04	PLUG	9
354-24970		205.41	COUPLING FLANGE	1
354-25941		6.19	SPEEDER SPRING	2
354-26150/6	second hand	9.97	END CAP	1
354-26200		186.10	PLATE	2
354-26220		20.92	SWIVEL UNION PLUG	3
354-26230		15.83	SWIVEL UNION	1
354-26260		22.84	PLUG	8
354-26270		18.64	PIPE	5
354-26310		0.55	WASHER	117
354-26480		4.80	BOLT	1
354-26481		8.30	BOLT	1
354-26530		2.72	BOLT	1
354-26561		57.58	BRACKET	1
354-26601		6.79	PLATE	1
354-26701		274.67	AIR DUCT	2
354-26730		40.00	FUELPIPE	3
354-26731		96.51	FUEL PIPE	1
354-26740		40.00	FUELPIPE	4
354-26741		98.35	FUEL PIPE	2
354-26751		96.58	FUEL PIPE	2
354-26761		96.58	FUEL PIPE	2
354-26810		8.25	PIECE	5
354-26820		5.87	PIECE	7
354-26830		8.49	PIECE	8
354-26850		12.66	SPRING	4
354-26871		11.70	HOOK	3
354-26880		2.87	SCREW	15
354-28250		9.27	LEAK-OFF PIPE	3
354-28280		8.79	SCREW	1
354-28350		ask	GOVERNOR WEIGHT	1
354-28360/6	second hand	60.74	FUEL FILTER	2
354-28380		9.38	SWIVEL UNION	2
354-28440		36.88	VENT PIPE	7
354-28450		ask	PIPE	12
354-28451		45.00	FUEL PIPE	1
354-28460		89.71	FUEL PIPE	2
354-28530		4.65	PLUG	4
354-28600		35.81	COVER	1
354-28610		30.49	FUEL PIPE	9
354-28650		27.61	FUELPIPE	1
354-28660		11.26	FUELPIPE	1
354-28950		112.28	BRACKET	1
354-29180		8.10	OIL PIPE	4
354-29190		8.27	OIL PIPE	4
354-29200		0.63	PLUG	9
354-29210		2.59	WASHER	1
354-29220/6	second hand	ask	NUT	1
354-29600		2.45	NUT	12

354-29620		2.44	O RING	8
354-30180		0.36	FILTER	1
354-30190		1.93	JOINT	8
354-30231		17.63	SPRING	6
354-30460		ask	PIPE	1
354-30470		ask	BAND	1
354-30580		13.72	VALVE	2
354-30590		ask	SPRING	8
354-30610		90.84	OIL OPIPE	1
354-30630		25.92	OIL OPIPE	6
354-30770		0.69	PIN	4
354-31600		11.19	SCREW	2
354-31620		5.11	GROMMET	5
354-31640		3.03	O RING	6
354-31650		3.90	O RING	22
354-31760		8.46	BUSH	6
354-31780		73.16	PINION	2
354-31790		84.99	PINION	2
354-31800		ask	YOKE	1
354-31850		5.27	JOINT	1
354-31890		15.35	PIPE CLAMP	1
354-32480		0.57	BOLT	4
354-32870		11.40	WASHER	4
354-32880		1.97	PIN	2
354-32890		0.21	SPRING RING	2
354-32920		0.21	SHIM	6
354-32940		32.80	SHIELD	2
354-33020		0.97	FELT	1
354-33030		6.45	FELT	1
354-33190		36.55	PLATE	3
354-33230/6	second hand	ask	PISTON	1
354-33280/6	second hand	ask	PLATE	1
354-33290/6	second hand	ask	CIRCLIP	1
354-33340/6	second hand	ask	PIPE	1
354-33360/6	second hand	ask	SHAFT	1
354-33380/6	second hand	ask	CIRCLIP	2
354-33390/6	second hand	ask	DISTANCE PIECE	1
354-33400/6	second hand	ask	FLANGE	1
354-33420/6	second hand	ask	COVER	1
354-33440/6	second hand	ask	PINION	2
354-33450/6	second hand	ask	PINION	2
354-33460/6	second hand	ask	SHAFT	6
354-33490/6	second hand	ask	PINION	1
354-33500/6	second hand	ask	BEARING	1
354-33510/6	second hand	ask	BUSH	1
354-33520/6	second hand	ask	NUT	1
354-33530/6	second hand	ask	LEVER	1
354-33540/6	second hand	ask	LEVER	1
354-33551/6	second hand	ask	LEVER	2
354-33560/6	second hand	ask	SHAFT	1
354-33570/6	second hand	ask	SHAFT	2
354-33580/6	second hand	ask	SHAFT	1
354-33590/6	second hand	ask	SPRING	1
354-33600/6	second hand	ask	NUT	1
354-33610/6	second hand	ask	LEVER	1
354-33620/6	second hand	ask	BOLT	1

354-33630/6	second hand	ask	COVER	1
354-33640		4.98	JOINT	1
354-33650/6	second hand	ask	COVER	1
354-33730		0.61	FELT RING	1
354-33830/6	second hand	ask	ROLLER BEARYNG	1
354-33840/6	second hand	ask	NUT	1
354-33860/6	second hand	ask	ROLLER BEARYNG	1
354-33870/6	second hand	ask	NUT	1
354-33880/6	second hand	ask	COVER	1
354-33920		2.87	SEAL	2
354-33932/6	second hand	ask	HOUSING	1
354-33970/6	second hand	ask	BRAKE CYLINDER	1
354-33980		3.28	SHIM	5
354-34030/6	second hand	ask	NIPPLE	1
354-34040		ask	O-RING	9
354-34080		ask	PINION	1
354-34090/6	second hand	ask	PINION	1
354-34100/6	second hand	ask	PINION	1
354-34120/6	second hand	ask	SHAFT	1
354-34140/6	second hand	ask	SHAFT	1
354-34190		2.71	SHIM	5
354-34230		ask	FLANGE	2
354-34331		33.10	LINK	1
354-34390/6	second hand	ask	DISTANCE PIECE	2
354-34720		ask	END COVER	1
354-34721		303.77	END COVER	1
354-34730		101.83	PULLEY	3
354-34750		55.12	ADJUSTING LINK	21
354-34830/6	second hand	ask	NIPPLE	1
354-34870		139.31	PULLEY	1
354-34872		135.78	PULLEY	1
354-35050		166.21	CONTROLLER	16
354-35282		ask	BRACKET	1
354-35302		ask	BRACKET	1
354-35980/6	second hand	ask	SEPARATOR	1
354-35990/6	second hand	ask	COVER	1
354-36270		14.71	INSULATOR	2
354-36350		44.92	BRACKET	2
354-36422		58.81	OIL SEPERATOR BOWL	1
354-36422/6	second hand	58.81	OIL SEPERATOR BOWL	1
354-36540		4.33	DISTANCE PIECE	1
354-36550		3.12	DISTANCE PIECE	1
354-36910		71.15	FLEXIBLE PIPE	1
354-37710		16.62	BRACKET	1
354-37850		33.42	ADJUSTING LINK	1
354-37990		32.30	GUARD	1
354-38020		ask	SHIELD	2
354-38100		9.62	UNION ADAPTOR	1
354-38130		ask	BRACKET	2
354-40470		ask	BRACKET	2
354-41440		ask	MANIFOLD	1
354-42600		67.33	COVER	1
354-42800		164.55	MANIFOLD	26
354-42920		0.67	JOINT	28
354-42970		81.31	BRACKET	2
354-42970/6	second hand	96.77	BRACKET	2

354-43070/6	second hand	ask	WATER PIPE	1
354-43100		39.65	BEND	5
354-43121		190.85	THERMOSTAT BODY	1
354-43160		122.92	OIL PIPE	1
354-43181		451.77	MANIFOLD	1
354-43210		2.24	JOINT	12
354-43220		24.39	STRAP	2
354-43220/6	second hand	24.39	STRAP	1
354-43230/6	second hand	189.10	BRACKET	1
354-43240		31.43	BRACKET	5
354-43401		ask	MANIFOLD	1
354-43410		20.86	NIPPLE	2
354-43470		ask	PIPE	3
354-43470/6	second hand	ask	PIPE	2
354-43472		35.56	PIPE	3
354-43480		9.30	T.D.C. INDIKATOR	2
354-43580		40.23	HOSE BEND	22
354-43600		2.33	JOINT	24
354-44070		27.99	THERMOSTAT	6
354-44073		29.53	THERMOSTAT	2
354-44180		14.41	BRACKET	7
354-44190		ask	BEND	1
354-44300		ask	BRACKET	2
354-44310		108.28	PULLEY	3
354-44320		32.14	ADJUSTING LINK	4
354-44340		57.58	DRIVE BELT	4
354-44870		51.30	DRIVE BELT	10
354-44910		ask	BEND	1
354-44950		0.82	KOINT	4
354-50210		91.60	COVER	2
354-50240/6	second hand	ask	BRACKET	4
354-50250/6	second hand	ask	BRACKET	1
354-50300		14.68	STUD	78
354-50310		10.44	STUD	68
354-50330		8.15	OIL THROWER	2
354-50341/6	second hand	294.20	END COWER	1
354-50350		162.35	OIL RETAINING RING	2
354-50360		19.10	FELT WASHER	3
354-50370		ask	HOUSING	1
354-50380		376.83	PLATE	5
354-50410		ask	PLATE	12
354-50440		405.42	LOCKING PLATE	1
354-50450/6	second hand	175.31	IDLER GEAR	1
354-50500		13.13	WASHER	7
354-50510		27.73	WASHER	5
354-50520		3.08	PIN	2
354-50530		0.78	SPRING RING	5
354-50570		ask	NIPPLE	1
354-50730		226.84	STRAINER	1
354-50810		365.33	FUEL PUMP	8
354-50890		ask	FLANGE	1
354-50921		ask	HOUSING	1
354-50960		10.94	CONNECTING ROD	1
354-51090		28.12	CABLE HOLDER	1
354-51100		67.97	BRACKET	2
354-51110		17.39	SPRING	1

354-51400		1.00 JOINT	11
354-51560		ask BRACKET	1
354-51880		ask FUEL PUMP	1
354-52830		57.74 FLEXIBLE PIPE	1
354-53080		54.91 PUSH ROD	2
354-53080/6	second hand	54.91 PUSH ROD	6
354-53140/6	second hand	189.20 PUMP ADAPTOR	1
354-53790		6.01 SEALING RING	103
354-53794		ask O-RING	1
354-53920		54.63 FUEL PIPE	1
354-53990		84.51 BRACKET	2
354-54180/6	second hand	ask WENT PIPE	2
354-54200		15.57 SWIVEL UNION PLUG	1
354-54310		ask BRACKET	1
354-54390		ask BRACKET	1
354-54960/6	second hand	176.73 FUEL PIPE	1
354-55110		4.02 BRACKET	4
354-55130		1.63 LEVER	5
354-55170		342.77 AIR CLEANER	2
354-55832		69.61 OIL PIPE	1
354-58110		4.24 BELT	10
354-80231		92.81 FUEL PIPE	2
354-82520/6	second hand	ask SHIELD	1
354-82530/6	second hand	ask SHIELD	1
354-82810		21.18 BEARING	1
356-11680		35.78 SHIELD	1
356-11680/6	second hand	35.78 SIDE SHIELD	1
356-15716		199.04 AIR DUCT	3
356-16050		144.30 GUARD	4
356-18353/6	second hand	335.22 MANIFOLD	2
356-18362		ask MANIFOLD	1
356-18363/6	second hand	279.77 MANIFOLD	1
356-18372		156.18 MANIFOLD	3
356-18372/6	second hand	334.86 MANIFOLD	2
356-18373/6	second hand	259.32 MANIFOLD	1
356-18380		262.89 MANIFOLD	3
356-18380/6	second hand	262.89 MANIFOLD	3
356-18381/6	second hand	243.40 MANIFOLD	1
356-18631		70.90 FAN BRACKET	1
356-18641		225.40 FAN	2
356-18651		271.37 FAN	1
356-18671		57.72 FAN SHAFT	1
356-18772		169.21 COUPLING	1
356-18781		253.77 COUPLING	5
356-18861		169.99 PULLEY	1
356-19303		222.50 CRANKSHAFT PULLEY	1
356-19305		181.57 PULLEY	1
356-19391/6	second hand	ask PIPE	3
356-19723		66.07 DRIVE BELT	3
356-20271		18.25 SHIELD	1
356-20480		118.65 FUEL PIPE	4
356-20490		144.14 FUEL PIPE	2
356-21750		3.17 OIL THROWER	2
356-22523		ask OIL OPIPE	1
356-22550		166.25 COVER	1
356-23270		29.53 OIL OPIPE	2

356-23391		18.01 BRACKET	7
356-23411		8.89 COVER	4
356-23421		14.76 STAY	3
356-23522		73.34 LEAK-OFF PIPE	4
356-24151		79.02 FUEL PIPE	2
356-24161		80.52 FUEL PIPE	2
356-24171		62.90 FUEL PIPE	2
356-24181		62.90 FUEL PIPE	3
356-24191		80.52 FUEL PIPE	2
356-24201		80.52 FUEL PIPE	3
356-24350		24.11 LEVER	3
356-25960		64.31 FLANGE	1
356-25960/6	second hand	73.64 FLANGE	2
356-26010		0.67 JOINT	61
356-26431		ask AIR FILTER	2
356-26561		54.64 SHIELD	4
356-26561/6	second hand	54.64 SHIELD	3
356-26701		362.98 AIR DUCT	1
356-26731		98.42 FUEL PIPE	3
356-26741		96.58 FUEL PIPE	3
356-26750		40.00 FUELPIPE	22
356-26751		98.42 FUEL PIPE	3
356-26760		40.00 FUELPIPE	32
356-26761		98.42 FUEL PIPE	3
356-26770		40.00 FUELPIPE	5
356-26771		98.42 FUEL PIPE	2
356-26781		98.42 FUEL PIPE	3
356-26790		52.87 BRACKET	3
356-28710		ask PIPE	1
356-28891		232.01 OIL STRAINER	3
356-28930		44.57 RETAINING PLATE	3
356-29911		18.16 FUEL PIPE	1
356-30830		10.39 BRACKET	2
356-31042		162.73 EXH.MANIFOLD	1
356-31042/6	second hand	162.73 EXH.MANIFOLD	1
356-31062		150.00 EXH.MANIFOLD	1
356-31062/6	second hand	141.44 MANIFOLD	1
356-31070		56.13 MANIFOLD TUBE	1
356-31070/6	second hand	49.03 MANIFOLD TUBE	4
356-31080		28.40 RING	4
356-31190		9.03 SHIELD	3
356-31190/6	second hand	9.03 SHIELD	7
356-31210		1.54 BRACKET	2
356-31290		75.00 CYLINDER BARREL	5
356-31310		18.37 SHIELD	7
356-31310/6	second hand	16.59 SHIELD	1
356-31340/6	second hand	ask SHIELD	1
356-31610		33.26 UNION	1
356-31890/6	second hand	ask CLAMP	1
356-34450		0.89 SHIM	5
356-34460/6	second hand	34.82 CONNECTION	1
356-34960		24.83 COWL	2
356-35260/6	second hand	137.87 COWLING	1
356-35350/6	second hand	29.76 RETAINER	1
356-36450		26.22 UNION PLUG	5
356-42491		313.27 MANIFOLD	2

356-42491/6	second hand	372.80	MANIFOLD	1
356-42511/6	second hand	394.87	MANIFOLD	1
356-42960/6	second hand	227.23	MANIFOLD	1
356-43401		ask	MANIFOLD	1
356-43402/6	second hand	369.65	MANIFOLD	2
356-43841		239.26	MANIFOLD	4
356-43841/6	second hand	284.73	PIPE	1
356-43849		ask	FLANGE	1
356-43860		4.59	JOINT	21
356-44600		32.12	HOSE	1
356-44700		116.15	HOUSING	1
356-44810		158.06	FLANGE	1
356-50210		77.96	SIDE SHIELD	1
356-50730/6	second hand	174.36	OIL STRAINER	2
356-50813		1.347.70	FUEL PUMP	1
356-50824		1.177.13	FUEL PUMP	1
356-51120		142.77	SIDE SHIELD	2
356-51270		141.15	INJECTOR HR	3
356-51270/098		141.15	INJECTOR HR	18
356-51300/6	exchange	262.71	FUEL PUMP	1
356-51330		4.20	PIN	2
356-51830		10.65	BREATHER TUBE	7
356-51980		169.87	BEARING BUSH	2
356-51992		106.25	BREATHER STACK	1
356-52030		24.02	PLUG	1
356-52041		34.75	FUELPIPE	4
356-52043		21.50	PIPE	2
356-52180		49.02	FUEL LIFT PUMP	2
356-52360		6.11	FUEL PIPE	1
356-52641		224.06	EXH.MANIFOLD	1
356-52641/6	second hand	338.80	MANIFOLD	1
356-52830		9.09	FLEX.PIPE	3
356-52900		9.76	JOINT	7
356-52901		2.39	JOINT	2
356-52910		2.50	JOINT	3
356-52911		0.41	JOINT	2
356-52930		12.58	JOINT	3
356-52970		21.10	BOLT	10
356-52980		5.29	NUT	13
356-53010		3.90	JOINT	3
356-53050		13.15	STUD	4
356-53061		ask	SHIELD	2
356-53191/6	second hand	190.85	BOTTOM COWL	1
356-53220/6	second hand	152.74	END PLATE	1
356-53250		11.12	STUD	3
356-53350		51.95	PLATE	1
356-53380		160.94	OIL PIPE	1
356-53440/6	second hand	274.14	COWLING	1
356-53491		295.58	SHIELD	1
356-53720		20.69	SWIVEL UNION PLUG	2
356-53800/6	second hand	56.66	OIL PIPE	1
356-53840		84.59	OIL PIPE	2
356-53860		40.00	FUELPIPE	15
356-53861		96.58	FUEL PIPE	1
356-53870		40.00	FUELPIPE	17
356-53880		40.00	FUELPIPE	6

356-53890		40.00 FUELPIPE	10
356-53891		96.58 FUEL PIPE	1
356-53900		40.00 FUELPIPE	10
356-53901		98.42 FUEL PIPE	2
356-53910		40.00 FUELPIPE	1
356-53940		64.47 FUEL PIPE	1
356-53970		27.88 SHIELD	2
356-53990		94.98 CLAMPING PLATE	3
356-53991/6	second hand	ask BRACKET	2
356-54000		41.72 BRACKET	1
356-54010		3.98 BRACKET	1
356-54070		57.22 FUEL PIPE	2
356-54120		173.73 INJECTOR	24
356-54120/698	exchange	151.74 INJECTOR HRS	6
356-54610/6	exchange	500.27 MINIMEC FUEL PUMP	1
356-54615		ask FUEL PUMP	1
356-54930		55.40 BELT	2
356-55832		81.21 OIL PIPE	3
356-55832/6	second hand	72.28 OIL PIPE	2
356-56253/6	second hand	72.02 AIR COWL	1
356-58481		63.13 FUEL PIPE	3
356-58491		63.13 FUEL PIPE	4
356-58501		63.13 FUEL PIPE	4
356-58511		63.13 FUEL PIPE	4
356-58521		64.33 FUEL PIPE	3
356-58531		63.13 FUEL PIPE	3
356-58760		ask BRACKET	2
356-58780		ask BRACKET	2
356-58990		ask BLOCK	1
356-59030/6	second hand	ask ROCKER ARM	12
356-59031		80.01 ROCKER LEVER	12
356-59080		2.83 JOINT	35
356-59140		ask OIL OPIPE	1
356-59340		55.50 BELT	5
356-59350		66.95 STUB SHAFT	8
356-59640		17.70 OIL HOSE	3
356-59850		40.62 HOSE	2
356-60040		113.58 INJECTOR	12
356-60040/698	exchange	28.97 INJECTOR	6
356-60060		31.30 OIL OPIPE	1
356-60100		19.06 PIPE	3
356-60120		ask PIPE	3
356-60160		40.17 PIPE	1
356-60180		ask OIL OPIPE	1
356-60191		143.96 PIPE	1
356-60250		8.60 STAY	3
356-60260		3.42 SCREW	12
356-60340		183.56 INJECTOR	31
356-80110		ask NUT	2
356-80110/6	second hand	ask NUT	2
356-80120		8.23 SCREW	2
356-80231		83.89 FUEL PIPE	2
356-80270		6.13 PIPE CLAMP	2
356-80390		1.683.38 MINIMEC FUEL PUMP	1
356-81210		19.66 VALVE	6
356-83250		21.07 JOINT	3

357-13500		ask	FLANGE	1
362-01325		ask	GAUGE	1
362-01438		ask	TAPER LOCK BUSH	2
362-02095			72.73 VOLTAGE REDUCER	2
362-02465			48.64 VOLTMETER	2
362-02497			23.65 TEMP GEUGE	2
362-02683			1.137.15 EXH.MANIFOLD	1
362-02738			0.41 GASKET	6
362-02993			94.58 SEA WATER PUMP	1
362-03047			4.14 BELT	2
362-03049			4.97 ELBOW	3
362-03105			46.56 HARNESS	1
362-03109			16.56 SENDER	1
362-03120			105.93 KEYSWITCH	1
362-03137			1.55 O RING	2
362-03171			1.02 BULB	10
362-03242		ask	PLATE	4
362-03245			17.67 ELBOW	1
362-03286/6	second hand		324.71 STARTER	1
362-03288			23.13 RELAIS	1
362-03329			0.26 SEALING RING	2
362-03337			4.33 PLUG	2
362-03343			6.30 STUD COUPLING	2
362-03344			8.58 ELBOW	3
362-03350			8.71 ELBOW	2
362-03357			249.28 WATER PUMP	1
362-03363		ask	CLAMP	1
364-00210			148.54 FLEXIBLE PIPE	2
364-00730		ask	COVER	1
364-02049		ask	FLANGE	1
364-02211		ask	PIPE	1
365-11710		ask	NUT	2
366-00002			76.24 BRACKET	4
366-00014			39.37 FLEXIBLE EXHAUST	7
366-00123			11.50 LEVER	4
366-00139			76.24 BRACKET	1
366-00451			60.00 PIPE CONNECTION	9
366-00453			0.52 JOINT	14
366-00467			37.85 FLANGE	15
366-00473		ask	PUMP HOUSING	1
366-00621			6.29 WASHER	3
366-00622			20.78 PLATE	1
366-00747		ask	FUEL PUMP HOUSING	3
366-00799			3.23 JOINT	2
366-00864			68.68 AIR DUCT	6
366-00867			1.61 BRACKET	3
366-00868			6.85 DISTANCE PIECE	10
366-00884			19.75 UNION	3
366-00886			33.17 OIL OPIPE	1
366-00888			13.72 SWIVEL UNION PLUG	10
366-00889			34.60 OIL OPIPE	3
366-00890			19.80 NIPPLE	3
366-00894			31.05 SWIVEL UNION	1
366-00896			114.87 OIL FILTER	1
366-00908			3.23 PLATE	3
366-00909			12.63 COVER	2

366-00910		2.62 BRACKET	4
366-00932		47.53 ADAPTOR	1
366-00949		ask BRACKET	1
366-00954		15.90 SWIVEL UNION	11
366-00974		ask SHAFT	2
366-01002		ask BRACKET	1
366-01005		ask BALL BEARING	2
366-01032		59.22 DOOR	2
366-01038		4.40 PLATE	5
366-01058		3.60 BRACKET	10
366-01101		13.94 UNION	2
366-01102		38.03 OIL PIPE	1
366-01103		63.35 OIL PIPE	2
366-01104		65.21 OIL PIPE	2
366-01110		44.14 OIL OPIPE	2
366-01195/6	second hand	ask AIR DUCT	3
366-01197		21.04 LEVER	6
366-01198		20.74 LEVER	5
366-01201		3.99 PIECE	45
366-01202		41.03 ROLLER	18
366-01205		20.86 ROLLER	8
366-01264		11.52 LEVER	3
366-01265		33.67 EXHAUST FLANGE	1
366-01271		44.55 PLUG	2
366-01272		16.86 SWIVEL UNION PLUG	2
366-01287		1.47 JOINT	77
366-01325		1.21 SHIELD	5
366-01361		ask EXTENSION SHAFT	4
366-01526		0.85 JOINT	1
366-01551		41.86 PIPE	2
366-01563		ask WASHER	1
366-01660		ask HOUSING	4
366-01661		23.82 PLUG	5
366-01686		20.12 PIECE	1
366-01705		ask JOINT	3
366-01712		20.43 BRACKET	2
366-01974		12.12 BRACKET	2
366-01989		ask BRACKET	2
366-01990		58.41 BRACKET	1
366-02037		9.12 BRACKET	1
366-02038		37.48 CABLE HOLDER	3
366-02090		1.37 JOINT	1
366-02108		11.87 OIL OPIPE	2
366-02137		259.81 HALF COUPLING	17
366-02196		101.02 FLANGE	2
366-02198		ask FLANGE	1
366-02200		ask WASHER	2
366-02201		ask JOINT	3
366-02292		ask BRACKET	2
366-02365		29.52 BRACKET	6
366-02387		195.80 SHIELD	2
366-02478		24.34 DIPSTICK	4
366-02484		40.50 DIPSTICK TUBE	4
366-02814		ask BRACKET	2
366-02815		ask BRACKET	2
366-02918		ask COVER	1

366-02937		0.82 JOINT	1
366-02962		ask PULLEY	11
366-02964		93.80 PULLEY	4
366-03003		38.16 DIPSTICK	3
366-03007		10.61 NUT	3
366-03027		7.43 BRACKET	3
366-03039		ask BRACKET	1
366-03040		ask JOINT	2
366-03041		ask BRACKET	2
366-03042		ask JOINT	1
366-03129		ask BRACKET	2
366-03146		43.86 ADAPTOR PLATE	4
366-03247/6	second hand	ask COVER	3
366-03248		ask FUEL PUMP HOUSING	2
366-03323/6	second hand	ask HOUSING	1
366-03327		ask FLANGE	1
366-03385		28.84 DOOR	2
366-03435		362.22 COVER	2
366-03436		193.34 GEARWHEEL	1
366-03437		261.70 PINION	1
366-03479		ask COVER	3
366-03536		ask STUD	5
366-03614		ask PIPE	1
366-03617		ask OIL OPIPE	9
366-03677		ask BRACKET	1
366-03695		17.18 BRACKET	4
366-03716		5.83 BOLT	5
366-03719		13.94 PIPE	2
366-03720		18.76 DIPSTICK	4
366-03738		13.06 FLEX. OIL PIPE	1
366-03772/6	second hand	ask MANIFOLD	1
366-03773		167.77 MANIFOLD	1
366-03775		91.45 MANIFOLD	1
366-03827		198.42 DRIVE MEMBER	1
366-03829		ask BRACKET	2
366-03834		181.65 HALF COUPLING	3
366-04008		24.99 HOUSING	1
366-04010		1.22 O RING	24
366-04010		1.22 O RING	24
366-04139		56.54 PLATE	1
366-04140		0.28 JOINT	1
366-04142		48.67 HOSE	7
366-04145		ask BEND	2
366-04286		132.40 FUEL PUMP HOUSING	1
366-04286/6	second hand	132.40 FUEL PUMP HOUSING	1
366-04315		ask DYNAMO	8
366-04316		58.51 RELAY	10
366-04317		66.68 CONTROL BOX	12
366-04319		40.13 WARNING LIGHT	16
366-04320		19.48 AMMETER	12
366-04354		93.18 BRACKET	5
366-04476		ask TANK	2
366-04487		303.97 STARTER	1
366-04552		ask NIPPLE	1
366-04616		35.74 YOKE	1
366-04618		5.75 YOKE PIN	6

366-04628		34.27 CONTROL CABLE	2
366-04696		2.39 CUPS	11
366-04735		16.57 WARNING LAMP	2
366-04839		340.42 ADAPTOR	4
366-04839/6	second hand	384.06 ADAPTOR CASING	1
366-04843		123.00 PLATE	3
366-04849		8.79 SHIM	6
366-04867		43.79 PIPE	2
366-04868		16.03 OIL OPIPE	1
366-04948		ask NUT	1
366-04949		3.30 NUT	1
366-04964		5.34 S-PIECE	5
366-04965		5.09 IMPELLOR	1
366-04966		2.45 SPACER	2
366-04967		9.56 STOP PIN	2
366-04969		108.54 CABLE & YOKE	1
366-04971		1.68 SPRING	9
366-04972		18.63 BRACKET	18
366-04997		161.69 PINION	1
366-05125		14.29 OIL OPIPE	1
366-05126		51.68 OIL OPIPE	1
366-05127		32.99 OIL OPIPE	2
366-05252		ask ADAPTOR	3
366-05279		ask ADAPTOR	2
366-05341		0.28 DISTANCE PIECE	4
366-05346		42.95 OIL PIPE	46
366-05347		ask OIL OPIPE	2
366-05348		70.88 OIL PIPE	2
366-05349		68.65 OIL PIPE	2
366-05350		ask OIL OPIPE	2
366-05351		59.02 OIL PIPE	2
366-05356		14.31 SEAT	6
366-05358		18.08 DISTANCE PIECE	1
366-05395		23.37 PIPE	2
366-05407		1.71 DISTANCE PIECE	2
366-05539		19.81 PULLEY	8
366-05540		242.38 PULLEY	1
366-05543		13.51 NIPPLE	2
366-05607		160.80 PULLEY	1
366-05681		31.68 ROD YOKE	26
366-05786		253.53 PULLEY	2
366-05823		145.97 HALF COUPLING	20
366-05851		ask PULLEY	3
366-05874		69.20 CONNECTING TUBE	1
366-05933		28.15 MORSE KIT	1
366-06163		174.08 EXHAUST PIPE	1
366-06228		2.83 PLATE	1
366-06251		36.37 VEE BELT	5
366-06264		57.56 OIL OPIPE	1
366-06278		55.87 AIR DUCT	2
366-06288		68.68 AIR DUCT	4
366-06310		68.68 AIR DUCT	1
366-06335		1.69 THROTTLE STOP	2
366-06346		40.79 ADAPTOR SLEEVE	2
366-06347		179.90 GUARD	4
366-06353		5.75 BRACKET	4

366-06354	11.39	BRACKET	4
366-06360	178.59	AIR DUCT	2
366-06371	9.52	PIPE	2
366-06373	26.87	PLATE	3
366-06378	17.03	PUSH BUTTON	46
366-06379	33.94	KEY SWITCH	23
366-06403	158.00	COVER	7
366-06433	8.82	CABLE	19
366-06456	21.36	CABLE	11
366-06457	6.21	CABLE	6
366-06459	220.39	CABLE	6
366-06468	2.42	FELT	5
366-06502	ask	BRACKET	3
366-06504	ask	COVER	2
366-06551	ask	ALTERNATOR	2
366-06559	169.72	SOLENOID	1
366-06564	113.27	COIL	8
366-06628	88.07	SUCTION VALVE	2
366-06663	91.53	OIL PIPE	4
366-06666	9.11	BRACKET	4
366-06679	1.55	CLIP	2
366-06691	18.81	BACK PLATE	1
366-06714	92.42	PULLEY	1
366-06715	16.49	SUPPORT PLATE	1
366-06718	7.90	BRACKET	1
366-06719	1.90	DISTANCE PIECE	1
366-06720	3.30	DISTANCE PIECE	1
366-06721	6.41	DISTANCE PIECE	1
366-06724	51.68	FUEL PIPE	7
366-06726	11.11	FUEL PIPE	5
366-06736	7.96	DISTANCE PIECE	2
366-06738	9.55	DISTANCE PIECE	1
366-06741	38.74	FOAM ELEMENT	12
366-06742	40.80	OIL PIPE	13
366-06743	26.06	ELBOW	1
366-06745	17.75	BRACKET	1
366-06748	55.02	FLEXIBLE HOSE	1
366-06752	0.07	JOINT	1
366-06761	40.36	GUARD	2
366-06776	93.16	BRACKET	5
366-06781	23.60	LINK	2
366-06782	17.17	BRACKET	8
366-06785	3.36	SPRING	2
366-06809	24.75	BRACKET	5
366-06842	10.83	STUD	20
366-06846	13.23	CONNECTOR	2
366-06847	8.76	BALL JOINT	2
366-06866	ask	PLATE	11
366-06867	ask	KIT	1
366-06876	3.45	KEY	2
366-06902	ask	WIRE	1
366-06906	2.64	SOLENOID	13
366-06926	6.46	WASHER	6
366-06934	6.88	CABLE	10
366-06939	75.02	CABLE LOOM	1
366-06945	12.72	BRACKET	1

366-06988	5.72 CABLE	14
366-07010	12.72 LINK	17
366-07013	14.49 LEVER	15
366-07028	42.28 AIR CLEANER	1
366-07038	21.42 UNION	18
366-07039	22.49 SWIVEL UNION PLUG	1
366-07041	2.88 PLUG	1
366-07042	3.28 BRACKET	1
366-07044	51.74 FLEXIBLE PIPE	11
366-07066	27.58 MOUNTING BRACKET	1
366-07068	1.89 CONTROL LEVER	9
366-07070	8.54 CABLE ADJUSTER	6
366-07071	3.44 CONNECTOR	8
366-07096	ask SHIELD	2
366-07099	33.74 BRUSH HOLDER	4
366-07110	ask BRACKET	1
366-07112	ask OIL OPIPE	1
366-07117	8.63 FUEL PIPE	3
366-07191	13.23 LINK	7
366-07194	4.49 BRACKET	7
366-07204	7.27 SOLENOID	1
366-07207	2.00 CABLE	1
366-07210	10.92 PILLAR	2
366-07211	11.37 PILLAR	2
366-07228	13.92 LAMPHOLDER	5
366-07282	45.35 AIR CLEANER ELEMENT	8
366-07433	ask WIRE	1
366-07434	ask WIRE	1
366-07435	ask WIRE	1
366-07604	ask BRACKET	5
366-07719	14.23 ADAPTOR	22
366-07835	ask MANIFOLD	4
366-07907	ask FUEL PIPE	1
366-07908	ask FUEL PIPE	1
366-07912	5.26 BRACKET	6
366-07970	68.39 LEAK-OFF PIPE	1
366-07986	31.02 PIVOT BRACKET	1
366-08030	6.85 FLEXIBLE MOUNTING	12
366-08092	49.58 CIRCUIT BREAKER	12
366-08093	0.34 WASHER	14
366-08094	5.49 SLEEVE	1
366-08103	18.60 BRACKET	26
366-08110	28.04 AIR CLEANER ELEMENT	4
367-10260	7.68 LEVER	2
367-12490	5.42 BRACKET	1
367-12800	0.66 LEVER	1
367-19561	2.55 TANK SUPPORT	59
367-19571	8.27 STRAP	45
367-34470	52.65 FILTER ADAPTOR	3
367-34490	4.75 WASHER	2
367-34500	69.65 NIPPLE	2
367-35550	107.90 SPEED CONTROL	1
370-00260	ask STUD	20
370-10410	1.39 CIRCLIP	1
370-10670	2.36 BUSH	1
370-12280	7.09 HOSE	4

370-12990	173.12	TEMPERATURE GAUGE	1
372-00190	23.44	RING	1
37531-7221	45.39	COVER	5
382-00066	2.20	CLIP	17
382-00090	ask	COUPLING	1
382-00110	ask	BALL BEARING	1
382-00192	ask	MANIFOLD	1
382-00212	9.12	HAND NUT	4
382-00243	27.58	ADJUSTING SCREW	7
382-00262	ask	FLANGE	1
382-00285	ask	BRACKET	1
382-00339	57.99	CONTROL CABLE	1
382-00466	226.97	PLATE	2
382-00470	ask	PLATE	1
382-00471	ask	COVER	1
382-00494	38.72	GUARD ASSY	1
382-00722	13.95	BRACKET	1
382-00735	169.27	REGULATOR	1
382-00744	35.15	OIL PIPE	2
382-00746	ask	EXTENSION SHAFT	1
382-00798	141.46	AIR DUCT	2
382-00825	3.87	DISTANCE PIECE	2
382-00884	10.82	BRACKET	1
382-00913	120.25	COUPLING DISC	2
382-00941	68.07	BRACKET	3
382-00942	ask	DISTANCE PIECE	2
382-01229	ask	BRACKET	2
382-01296	ask	KEY	1
382-01808	3.08	CIRCLIP	1
382-01862	13.80	DECOMPRESSOR LEVER	2
382-01869	201.63	PULLEY	3
382-01870	ask	PULLEY	4
382-01874	105.69	PULLEY	3
382-02003	ask	RELAIS	2
382-02021	7.54	BELT	2
382-02282	49.11	CIRCLIP	4
382-02300	ask	RING	2
382-02339	ask	SHIELD	1
382-02443	ask	PANEL	1
382-03306	152.29	SHAFT EXTENSION	20
382-03325	1.95	BRACKET	1
382-03361	5.21	NUT	2
382-03498	6.11	DISTANCE PIECE	2
382-03659	63.66	SHAFT	1
382-03667	52.31	PULLEY	1
382-03833	74.72	DAMPER	1
382-03840	22.35	FLANGE	1
382-03904	342.45	AIR CLEANER	1
382-04369	241.34	AIRCLEANER	1
382-04376	53.82	INLET CAP	3
382-04376	53.82	INLET CAP	3
382-04486	ask	ADJUSTING LINK	1
382-04540	ask	SHIELD	1
382-04711	908.31	TACHOMETER	1
382-04847	4.85	CLIP	9
382-05044	137.85	SHAFTEXTENSION	1

382-05062		392.85 FLEX.EXHAUST	9
382-05207		60.42 SHIELD	1
382-05271		30.50 FLEXIBLE PIPE	1
382-05438		ask PULLEY	1
382-06732		125.00 HALF COUPLING	13
382-06746		103.09 BRACKET	2
382-06750		40.64 DRIVE BELT	2
382-06751		355.69 PULLEY	4
382-06752		1.83 KEY	1
382-06767		5.28 BRACKET	4
382-06768		5.20 STUD	3
382-06787		ask COVER	1
382-06850		76.35 SUPPORT BRACKET	3
382-06857		72.30 OIL PIPE	60
382-06872		526.08 SOLENOID	1
382-06872/6	second hand	526.08 SOLENOID	1
382-07006		19.65 BRACKET	4
382-07010		ask COUPLING	2
382-07042		51.30 GUARD	3
382-07052		ask DISTANCE PIECE	8
382-07063		52.46 OIL BLOCK	1
382-07104		ask BRACKET	13
382-07205		ask BRACKET	55
382-07208		1.72 SPACER	3
382-07272		7.33 NUT	3
382-07320		19.54 BLANKING PLATE	1
382-07342		2.78 GROMMET	6
382-07350		26.36 FUEL PIPE	6
382-07369		3.33 SPRING	1
382-07387		405.08 DRIVE GUARD	1
382-07412		ask ADJUSTING LINK	5
382-07413		14.97 BRACKET	1
382-07605		ask BRACKET	7
382-07782		ask BLOK	4
382-07787		ask BLOK	5
382-07807		0.38 TERMINAL	4
382-07935		ask STRAP	2
382-07974		34.81 RELAY	1
382-07991		ask BEND	1
382-08012		ask PLATE	1
382-08016		ask BRACKET	1
382-08016/6	second hand	ask BRACKET	1
382-08033		ask SHIELD	17
382-08034		ask NUT	15
382-08042		23.14 FUSE HOLDER	52
382-08043		2.64 FUSE LINK	1
382-08078		1.36 CABLE CLIP	1
382-08080		0.94 BLANKING PLUG	1
382-08086		ask SENDER	1
382-08250		20.39 INDICATOR	2
382-08256		1.02 CABLE CLIP	4
382-08323		ask SHIELD	2
382-08325		ask SHIELD	3
382-08357		ask WIRE	4
382-08528		ask BLOCK	1
382-08531		32.00 FLEXIBLE PIPE	5

382-08573		40.26 OIL PRESSURE SWITCH	4
382-08580		3.01 ADAPTOR	2
382-08588		29.53 PIPE	6
382-08589		47.00 FLEXIBLE PIPE	29
382-08656		140.10 PULLEY	2
382-08660/6	second hand	ask EXTENSION SHAFT	1
382-08672/6	second hand	ask ADAPTOR	1
382-08677		ask WIRING	4
382-08694		14.07 LINK	1
382-08715		7.37 LEVER	1
382-08780		ask PLATE	1
382-08785		ask WASHER	1
382-08862		85.11 BACK PLATE	2
382-09103		21.75 ADAPTOR	1
382-09104		26.21 PUSH ROD	2
382-09105		38.27 BEARING BUSH	2
382-09115		34.78 ADAPTOR	2
382-09137		ask WIRING	3
382-09176		9.99 CABLE	13
382-09177		10.80 CABLE	7
382-34820		ask BRACKET	2
38413-4002		1.33 O-RING	7
38413-4004		2.91 O RING	23
38451-1001		ask JOINT	9
38451-4001		2.25 JOINT	19
38463-1001		2.00 JOINT	7
38463-1031		4.96 JOINT	31
386-00886		ask PIPE	1
389-00004		89.72 COUPLING	2
389-00292		21.09 PIPE	2
389-00293		29.24 PIPE	2
389-01088		ask PIPE	1
389-01089		18.12 BRACKET	5
389-01313		ask BRACKET	1
389-01783		ask COUPLING	2
389-02460		ask SILENCER	1
389-02515		185.46 OIL COOLER	1
389-02859		37.64 BRACKET	2
389-04322		10.99 PIECE	12
389-04553		8.51 HOSE	1
389-04584		ask BEND	6
390-00927		ask PIPE	1
390-40570		ask FLANGE	1
394-10032		ask CYLINDER HEAD	6
394-10032		ask CONNECTING ROD	6
394-10060		19.66 CON ROD BUSH JA/W/S	4
394-10060/6	second hand	17.50 CON ROD BUSH JA/W/S	10
394-10130		315.10 SHAFT EXTENSION	1
394-10130/6	second hand	315.10 SHAFT EXTENSION	2
394-10150		33.33 OIL THROWER	1
394-10150/6	second hand	29.67 OIL THROWER	1
394-10170		6.92 BUSH	15
394-10180		12.94 ADJUSTING SCREW	49
394-10190		1.57 DOWEL	4
394-10200		506.63 CYLINDER BARREL JA/S	14
394-10200/620	EXCHANGE	40.91 CYLINDER ,020 O/S	6

394-10210		ask	PINION	1
394-10212			357.18 PINION	1
394-10212/6	second hand		357.18 PINION	3
394-10220			1.84 NUT	25
394-10251			37.24 STUD	13
394-10260			47.70 BEARING JA/W/S	1
394-10260/010			34.65 BEARING JA/W/S	2
394-10260/020			47.70 BEARING JA/W/S	5
394-10260/040			47.70 BEARING	2
394-10261/010			42.46 BEARING	5
394-10261/020			47.70 BEARING JA/W/S	7
394-10270/010		ask	BEARING	2
394-10290			9.24 THRUST WASHER JA/W/S	10
394-10302			88.31 VALVE TAPPET	2
394-10302/6	second hand		77.13 VALVE TAPPET	9
394-10310			10.90 PUSH ROD	13
394-10310/6	second hand		9.52 PUSH ROD	26
394-10321			34.88 VALVE GUIDE JA/S	12
394-10330			27.54 VALVE SPRING JA/W/S	195
394-10340			15.58 VALVE SPRING CARRIER	82
394-10370			1.93 CYL HEAD SHIM	38
394-10381			3.44 CYL HEAD GASKET	17
394-10390			2.61 JOINT	69
394-10400			37.41 VALVE GUIDE JW/S	18
394-10401			34.88 VALVE GUIDE JA/S	12
394-10411			89.72 BRACKET	1
394-10411/6	second hand		89.72 BRACKET	16
394-10421			7.54 TAPPET GUIDE	5
394-10441			5.91 TAPPET INSERT	6
394-10450		ask	ROLLER	3
394-10460			8.67 BUSH	3
394-10470			6.38 PIN	4
394-10482			0.53 SHIM	40
394-10482/6	second hand		0.53 SHIM	21
394-10483			1.59 FUEL PUMP SHIM	4
394-10483/6	second hand		1.39 FUEL PUMP SHIM	9
394-10510			14.37 JOINT	16
394-10520			120.36 ROCKER BRACKET	12
394-10530			157.96 ROCKER BRACKET	9
394-10540			0.48 JOINT	154
394-10572			103.41 INJECTOR	28
394-10581			43.48 INJECTOR CLAMP	1
394-10581/6	second hand		43.48 INJECTOR CLAMP	6
394-10590			9.90 FUEL PIPE	13
394-10601			21.04 STUD	13
394-10602			38.03 STUD	7
394-10610			9.74 PILLAR	1
394-10630			17.16 BREATHER TUBE	1
394-10660/6	second hand		6.77 SEALING TUBE	7
394-10700			1.18 VALVE CUTTER	44
394-10700/6	second hand		1.18 VALVE CUTTER	3
394-10731			1.44 O RING	29
394-10741			3.11 JOINT	14
394-10742			4.26 JOINT	12
394-10750			1.65 O RING	32
394-10802		ask	PINION	1

394-10806		340.35 CAMSHAFT GEARWHEEL	3
394-10806/6	second hand	340.35 CAMSHAFT GEARWHEEL	1
394-10824		222.30 IDLER GEAR	16
394-10824/6	second hand	222.30 IDLER GEAR	3
394-10838		ask BUSH	1
394-10840		50.04 SHAFT	1
394-10840/6	second hand	44.40 SHAFT	2
394-10910		37.78 STUD	40
394-10920		35.74 STUD	16
394-10970		35.37 BUSH	1
394-11030		2.85 GOV WT SPRING	3
394-11031		ask SPRING	6
394-11045		18.25 SPEEDER SPRING	17
394-11046		1.85 SPRING	2
394-11049		11.88 SPEEDER SPRING	5
394-11112		11.18 SPRING	3
394-11121		5.75 SPACER	1
394-11140		0.94 SPRING	5
394-11150		3.50 NUT	20
394-11151		3.49 NUT	2
394-11160		48.91 BRACKET	8
394-11180		0.79 FIBRE JOINT	1
394-11190		152.12 FAN	1
394-11190/6	second hand	152.12 FAN	1
394-11191/6	second hand	152.12 FAN	1
394-11250		201.83 FAN SHAFT	2
394-11250/6	second hand	176.29 FAN SHAFT	1
394-11301/6	second hand	ask END COVER	1
394-11321/6	second hand	130.55 PLATE	1
394-11342/6	second hand	227.98 END PLATE	3
394-11350		0.70 JOINT	4
394-11360		4.24 JOINT	13
394-11540/6	second hand	ask PLATE	2
394-11642/6	second hand	ask BRACKET	2
394-11652		ask BRACKET	8
394-11942		ask COVER	1
394-11943		88.76 SHIELD	1
394-11980		40.24 SHIELD	1
394-11980/6	second hand	35.70 SIDE SHIELD	2
394-11990		17.12 SHIELD	3
394-11990/6	second hand	15.19 AIR SHIELD	10
394-12000		1.73 BRACKET	1
394-12010		1.73 BRACKET	1
394-12020		0.81 PLATE	1
394-12020/6	second hand	ask PLATE	1
394-12061/6	second hand	16.63 FUEL PUMP HOOD	2
394-12090		17.39 FLANGE	2
394-12100		2.78 JOINT	30
394-12140		19.69 SWIVEL BOLT	6
394-12140/6	second hand	19.69 SWIVEL BOLT	14
394-12150		8.45 ADJUSTING SCREW	3
394-12160		27.99 CONTROL LEVER	1
394-12170		5.29 SHAFT	1
394-12190		57.33 OPERATING LEVER	2
394-12190/6	second hand	57.33 OPERATING LEVER	1
394-12201		10.89 PIN	1

394-12201/6	second hand	10.89	PIVOT PIN	1
394-12211		9.83	PIN	2
394-12220		ask	HOUSING	1
394-12220/6	second hand	ask	FLYWHEEL HOUSING	1
394-12230		0.70	JOINT	3
394-12240		ask	PLATE	1
394-12270/6	second hand	72.04	CAMSHAFT BEARING	2
394-12290		2.77	PLATE	2
394-12300		3.33	SCREW	6
394-12320		ask	FLANGE	2
394-12321/6	second hand	ask	OIL OPIPE	2
394-12340		44.57	VALVE BODY	19
394-12340/6	second hand	44.57	VALVE BODY	2
394-12351		1.22	BALL	7
394-12360		ask	SPRING	2
394-12361		16.30	SPRING	3
394-12470		0.85	PLUG	1
394-12480		9.15	PLUG	1
394-12500/6	second hand	11.90	DOOR	6
394-12510		0.49	JOINT	10
394-12520		3.35	DOWEL	25
394-12540		1.81	GROMMET	20
394-12560		1.38	GROMMET	12
394-12580		55.36	OVERLOAD STOP	1
394-12590		29.28	OIL STOP SLEEVE	1
394-12590/6	second hand	29.28	OIL STOP SLEEVE	3
394-12600		2.81	BUSH	1
394-12600/6	second hand	3.32	EXCESS FUEL STOP	2
394-12610		34.39	CLAMP	6
394-12610/6	second hand	34.39	CLAMP	16
394-12630		23.51	LEVER	2
394-12640		ask	SPRING	4
394-12641		5.48	SPRING	3
394-12651		3.22	LEVER	3
394-12671		0.98	SPRING	1
394-12680		7.28	PIPE	8
394-12680/6	second hand	8.65	SEALING TUBE	10
394-12690		10.19	RUBBER CUP	34
394-12700		ask	COVER	1
394-12712		87.35	CARRIER	1
394-12730		ask	SCREW	1
394-12760		6.82	PIN	4
394-12781		19.20	SWIVEL UNION	6
394-12781/6	second hand	17.09	SWIVEL UNION	3
394-12810		7.99	BLANKINGPLATE	1
394-12810/6	second hand	7.99	BLANKINGPLATE	1
394-12820		0.64	JOINT	7
394-12890		4.24	JOINT	2
394-12900		8.32	LOCATING SCREW	2
394-12910		4.68	WASHER	3
394-12958		ask	WASHER	1
394-12960		38.40	NUT	1
394-13000		5.23	BUSH	1
394-13010		2.03	BUSH	1
394-13040/6	second hand	ask	PULLEY	1
394-13042		171.70	PULLEY	2

394-13042/6	second hand	171.70	PULLEY	1
394-13051		115.65	PULLEY	1
394-13052		104.34	PULLEY	2
394-13070		72.93	PULLEY	5
394-13081		63.53	BELT	10
394-13091		24.75	BELT	3
394-13140		280.69	COUPLING PLATE	4
394-13171/6	second hand	ask	COVER	2
394-13233		772.37	END COVER	1
394-13280/6	second hand	ask	PINION	1
394-13420		ask	JOINT	3
394-13521		8.52	IDLER SPRING	4
394-13523		14.00	SPRING	4
394-13680		ask	BOLT	3
394-13700/6	second hand	ask	GUARD	1
394-13730		3.66	O RING	8
394-13770/6	second hand	5.20	DISTANCE PIECE	3
394-13780		624.48	DAMPER	1
394-13800/6	second hand	115.77	DAMPER HUB	1
394-13830		14.01	SHIELD	4
394-13830/6	second hand	14.01	AIR SHIELD	2
394-13860		12.21	BALL BEARING	9
394-13900		5.15	STUD	3
394-13940		2.43	SPACER	1
394-13950		0.15	WASHER	2
394-13990/6	second hand	3.45	BRACKET	1
394-14020		0.83	GOV WEIGHT PIN	1
394-14051/6	second hand	10.20	FUEL PUMP HOOD	10
394-14070		0.64	O-RING	15
394-14250		1.89	SWIVEL UNION	32
394-14260		4.24	FUEL HOSE	28
394-14270		22.60	LEVER	1
394-14280		54.42	LEVER	2
394-14320		5.02	NUT	13
394-14351		30.12	BRACKET	11
394-14361		7.68	CONTROL LEVER	12
394-14400		23.33	UNION	6
394-14400/6	second hand	20.38	UNION	1
394-14410		ask	FLANGE	1
394-14430		ask	STUD	3
394-14440		ask	STUD	30
394-14500		475.84	PULLEY	1
394-14771		ask	BRACKET	2
394-14811		ask	BRACKET	1
394-14821		ask	BRACKET	2
394-14860		23.87	EXPANSION PLUG	1
394-14870/6	second hand	120.82	CONNECTING TUBE	2
394-14961		ask	VALVE	1
394-15110		ask	T-PIECE	2
394-15130		9.55	BREATHER TUBE	10
394-15191		2.86	PIPE CLAMP	1
394-15200		ask	PIN	1
394-15310		3.93	VENT PIPE	1
394-15320		20.19	BARRING HUB	3
394-15390		1.65	PLUG	1
394-15950		22.81	SCREW	4

394-16120		ask	SHAFT	1
394-16220			29.48 STUD	1
394-16230		ask	STUD	1
394-16240			5.82 PLATE	1
394-16270			0.96 SHIM	8
394-16390			3.88 WASHER	2
394-16411			13.79 ADJUSTING LINK	1
394-16430			16.49 SPACER	1
394-16690/6	second hand		34.35 CAM	3
394-16710			370.48 GEAR	9
394-16740			5.71 KEY	4
394-16890			5.18 RUBBER STRIP	2
394-17020			182.54 FUEL PIPE	1
394-17890			9.64 RUBBER SEGMENT	4
394-17920			2.00 CIRCLIP	1
394-17960/6	second hand		457.71 GEAR ASSY.	2
394-40023			48.36 VALVE INSERT	12
394-40033			41.64 VALVE INSERT	12
394-40050			4.45 RUBBER JOINT	7
394-40082			2.79 JOINT	10
394-40130			15.67 BREATHER TUBE	5
394-40160/6	second hand		169.05 COVER	1
394-40190		ask	BRACKET	1
394-40190/6	second hand	ask	BRACKET	1
394-40230			2.33 JOINT	14
394-40250			58.15 COVER	1
394-40260			2.81 RUBBER JOINT	7
394-40270			2.54 RUBBER JOINT	14
394-40300			215.12 PULLEY	2
394-40310		ask	BRACKET	4
394-40330			74.24 FUEL PIPE	2
394-40390/6	second hand	ask	COVER	1
394-40400			111.52 FLANGE	3
394-40410		ask	PINION	15
394-40450			8.05 JOINT	3
394-40470/6	second hand	ask	BRACKET	2
394-40480/6	second hand	ask	BRACKET	1
394-40491/6	second hand		21.30 NUT	2
394-40550/6	second hand		131.15 PIPE	1
394-40570			88.05 FLANGE	3
394-40590			32.59 RUBBER ELBOW	2
394-40610/6	second hand	ask	WATER PIPE	1
394-40640			10.56 JOINT WASHER	10
394-40670		ask	PIPE	1
394-40690			38.46 FLEXIBLE PIPE	6
394-40780			176.43 PIPE	1
394-40790			126.73 OIL OPIPE	1
394-40850			6.45 POCKET	2
394-41061			2.74 PLATE	1
394-41110		ask	STUD	1
394-41130		ask	PIPE	1
394-41450		ask	SHIELD	2
394-41680			83.44 PULLEY	3
394-41890		ask	BRACKET	1
394-41930			3.96 JOINT	1
394-42010			60.99 PULLEY	1

394-42010/6	second hand	60.99	PULLEY	1
394-44010		ask	ADAPTOR	1
396-11471/6	second hand	193.20	COWLING	2
396-11493/6	second hand	72.22	BOTTOM COVER	2
396-11521/6	second hand	126.65	AIR COWLING	2
396-11721/6	second hand	ask	SUMP	1
396-11790/6	second hand	210.19	STRAINER ASSY.	2
396-11902		303.71	AIR DUCT	1
396-11942		ask	ADAPTOR	1
396-12071		298.10	EXH.MANIFOLD	1
396-12071/6	second hand	298.10	MANIFOLD	1
396-12081		285.46	EXH.MANIFOLD	1
396-12081/6	second hand	285.46	MANIFOLD	1
396-12111		378.90	MANIFOLD	5
396-12111/6	second hand	378.90	MANIFOLD	6
396-12121		98.91	CONNECTING TUBE	1
396-12121/6	second hand	88.04	CONNECTING TUBE	4
396-13082		29.64	BELT	3
396-13870		263.16	OIL PIPE	1
396-13880		283.40	FLEXIBLE PIPE	2
396-14680		45.21	FLANGE	3
396-14950		50.14	INLET VALVE JA/W/S	40
396-14960		ask	VALVE	2
396-14961		58.94	EXHAUST VALVE JA/W/S	10
396-14990		1.25	JOINT	5
396-15411/6	second hand	ask	EXH.MANIFOLD	1
396-15470		316.95	MANIFOLD	2
396-15490		2.43	O-RING	9
396-15700		6.24	JOINT	20
396-15710		ask	PIPE	2
396-15711		ask	PIPE	3
396-15720		ask	PIPE	1
396-15721		ask	PIPE	2
396-15731/6	second hand	ask	PIPE	2
396-15760/6	second hand	ask	OIL OPIPE	1
396-15770		4.73	NUT	33
396-15790		3.85	FLANGE JOINT	9
396-15800		14.05	FLANGE JOINT	1
396-15820		16.34	STUD	2
396-15840		14.82	STUD	4
396-15880		1.90	JOINT	5
396-15940		6.92	O RING	4
396-15971		162.15	FLEXIBLE PIPE	2
396-16031/6	second hand	130.95	OIL PIPE	1
396-16570		112.71	UNION	1
396-16800		94.09	INJECTOR	6
396-16800/698	exchange	94.09	INJECTOR	1
396-16810		53.92	NOZZLE JA/WS	28
396-17120		42.92	OIL OPIPE	1
396-17170		31.48	O RING	5
396-17210		4.99	JOINT	10
396-17220		62.86	JOINT	4
396-17430		246.02	MANIFOLD	1
396-17440		294.12	MANIFOLD	1
396-17450		240.62	MANIFOLD	1
396-17470		9.95	PIN	2

396-18000		4.86 WASHER	5
396-18030		14.37 BRACKET	3
396-18040		14.37 BRACKET	3
396-18060		18.14 SPACER	3
396-18090		9.97 BRACKET	1
396-18720		11.96 SUPPORT STRIP	3
396-18720/6	second hand	11.18 CLAMP	16
396-18730		2.64 PAD	10
396-18770		39.06 HOSE	2
396-18900		13.51 SPRING	2
396-18940		2.71 MANIFOLD JOINT	6
396-18950		4.06 MANIFOLD JOINT	6
396-19190/6	second hand	279.19 FAN BODY	1
396-19230		6.90 GREASE SHIELD	4
396-19940		2.71 KEY	23
396-42170		67.81 HOSE	3
396-42340		440.23 EXHAUST PIPE	6
396-42380	ask	BLOK	5
396-42500		3.05 JOINT	5
396-42580		3.17 OIL SEAL	2
396-42590		30.00 BELT (3 ea)	6
396-43130		6.13 JOINT	3
396-43320		0.29 JOINT	4
396-43400	ask	MANIFOLD	3
396-43410	ask	MANIFOLD	2
396-43420	ask	MANIFOLD	2
396-43610/6	second hand	ask FLANGE	2
396-43790		14.18 HEAT BAFFLE	2
396-43910		3.56 O RING	13
396-43980/6	second hand	ask FLEX.PIPE	1
396-44010	ask	BRACKET	1
396-44040		98.83 BRACKET	1
396-44050	ask	HOSE	2
396-44160		20.80 HOSE	2
396-44170		2.12 PACKING WASHER	16
396-44640	ask	GUARD	1
396-44910	ask	MANIFOLD	1
396-45270		78.76 OIL PIPE	2
396-46210		59.03 HOSE	1
396-46600		46.86 O RING (4 PER SET)	1
402-08016		0.27 BOLT	15
402-10020		0.54 BOLT	1
402-10040		0.81 BOLT	2
465-18080	ask	BUSH	1
502-10141		52.42 NUT	5
502-10180		8.62 PLUG	2
502-10290		22.25 JOINT	1
502-11022		25.25 NUT	1
502-11081	ask	HOUSING	2
502-11101		118.21 COUPLING	1
502-11110		69.50 BUSH	2
502-11120		8.52 KEY	5
502-11131	ask	PINION	2
502-11181		1.95 PLUG	7
502-11181/6	second hand	1.95 PLUG	4
502-11200		2.23 WASHER	3

502-11210			9.50 KEY	4
502-11240		ask	PLATE	1
502-11260			36.22 NUT	1
502-11270			1.45 PLATE	1
502-11282			22.12 PIN	1
502-11291			31.76 TOGGLE LEVER	2
502-11311			6.21 SCREW	2
502-11322			12.67 BRACKET	2
502-11322/6	second hand		12.67 LINK	2
502-11332			27.70 PIN	2
502-11341			111.98 BUSH	2
502-11362			16.34 PLUG	9
502-11371			118.35 LEVER	2
502-11383			121.40 LEVER	2
502-11392			62.16 SHAFT	1
502-11411/6	second hand		28.05 COLLAR	1
502-11422			52.98 SHAFT	2
502-11451			5.77 SCREW	20
502-11460			34.80 ROLLER	1
502-11461		ask	ROLLER	4
502-11471		ask	SPLIT BOLT	5
502-11472			13.56 PIN	1
502-11512			20.18 SCREW	2
502-11521			70.00 SCREW	4
502-11663			89.21 SOCKET	1
502-11710		ask	BUSH	4
502-11733		ask	ROCKER ARM	2
502-11750			3.76 PISTON	4
502-11760			0.76 SPRING	6
502-11790			1.83 KEY	11
502-11861			171.69 COUPLING	1
502-11870			88.30 COUPLING	2
502-11880			8.61 BOLT	6
502-11910			41.27 BUSH	1
502-11980			60.64 NUT	2
502-14051		ask	EXTENSION SHAFT	1
502-14061			27.14 NUT	2
502-14061/6	second hand		18.72 SHAFT NUT	1
502-14091		087-14091 ask	BRACKET	1
502-14091			46.90 BRACKET	1
502-14110			30.22 BOLT	5
502-14141			58.63 LEVER	4
502-14150			17.84 SCREW	3
502-14160			89.52 TERS	2
502-14170			30.25 LEVER	2
502-14170/6	second hand		30.25 LEVER	2
502-14180			7.67 SHAFT	4
502-14180/6	second hand		7.67 FULCRUM PIN	2
502-14211			55.90 FORK LEVER DIE	1
502-14221			33.24 LINK	4
502-14221/6	second hand		33.24 LINK	4
502-14380			66.98 NUT	2
502-14390			11.88 LINKAGE ROD	4
502-14390/6	second hand		10.38 LINKAGE ROD	2
502-14410			14.21 SCREW	4
502-14430			23.97 NUT	3

502-14460		1.78	KEY	1
502-14460/6	second hand	1.78	KEY	1
502-14490		3.81	KEY	9
502-14521		1.40	SCREW	5
502-14561		73.70	LEVER	1
502-14571		45.06	BRACKET	1
502-15010		ask	DIPSTICK	2
502-15041		121.55	END COVER	1
502-15051		40.75	COVER	1
502-15061		104.41	COVER	2
502-15110		0.21	JOINT	3
502-15140		5.39	DISTANCE PIECE	9
502-17020		142.48	END COVER	1
502-18040	087-18040	ask	SHAFT	1
502-18090		ask	BUSH	1
502-18110		ask	BUSH	1
502-18130		ask	EXTENSION SHAFT	2
502-18150		ask	BUSH	6
502-18180		91.78	PLATE	4
502-18200		ask	SHAFT	2
502-18200		474.67	PINION	2
502-18210		ask	FLANGE	1
502-18220		ask	COUPLING	6
502-18230		90.65	PLATE	5
502-18240		ask	PLATE	1
502-18250		ask	LEVER	2
502-18310		301.80	PINION	3
502-18360		55.92	PLATE	2
502-18370		ask	LEVER	1
502-18770		3.35	JOINT	18
502-18910		21.32	BUSH	1
502-18960		ask	PLATE	1
502-19030		0.49	JOINT	20
502-19060		ask	PINION	1
502-19330		5.72	BOLT	8
502-19340		196.75	COUPLING	1
502-19350		1.50	JOINT	3
502-19540		23.91	NUT	2
502-19550		3.67	WASHER	1
502-19670		2.59	JOINT	2
502-19970		ask	PIECE	6
503-01612		0.26	PIN	30
503-01749		19.05	OIL SEAL	7
503-02191		ask	PLUG	2
503-02214		0.43	JOINT	6
503-02327		4.99	KEY	8
503-02331		110.06	OIL SEAL	2
503-02677		9.45	BALL BEARING	2
503-02711		ask	BALL BEARING	1
503-03288		5.22	KEY	8
503-03289		4.41	KEY	5
503-03542		0.26	JOINT	39
503-03856		3.21	KEY	8
503-03884		2.72	KEY	6
503-04027		41.67	BALL BEARING	5
503-04112		123.69	BALL BEARING	6

503-04131		0.81 GRUB SCREW	5
503-04258		ask DOWEL	9
503-04568		4.49 KEY	9
503-04815		2.14 KEY	5
503-05149		1.02 WASHER	1
503-05203		0.27 SCREW	2
503-05843		13.49 PLUG	1
503-05845		ask JOINT	18
503-05871		2.27 SPRING	1
503-05873		2.52 KEY	5
503-06603		0.04 SPLIT PIN	2
503-07951		0.96 SPRING	11
503-08997		1.19 SCREW	4
503-11052		ask PINION	1
512-10980		ask FLANGE	3
513-00193		0.37 CIRCLIP	7
520-07540		4.88 CLIP	7
520-07577		0.23 O-RING	16
520-07653		0.52 RUBBER RING	2
520-32610		ask TANK	1
530-15690		ask CABLE	1
570-10010/6	second hand	29.13 CONNECTING ROD	2
570-10011		ask CONNECTING ROD	2
570-10023/010		ask PISTON	3
570-10110		90.10 PISTON ASSY.	1
570-10110/040		90.10 PISTON ASSY.	2
570-10151/6	second hand	66.84 ROLLER SCREW	1
570-10162		150.00 FLYWHEEL	3
570-10171		72.84 OIL PUMP PLUNGER	1
570-10190		95.69 GOVERNOR SLEEVE	2
570-10210		3.41 DIPSTICK	1
570-10211		22.18 DIPSTICK	3
570-10220		159.90 TUBE	2
570-10231		15.97 BREATHER TUBE	1
570-10240		127.37 PISTON ASSY.	2
570-10240/010		127.37 PISTON ASSY.	5
570-10240/040		127.37 PISTON ASSY.	2
570-10351/6	EXCHANGE	163.64 CRANKSHAFT	2
570-10380		19.21 DIPSTICK	1
570-10390		24.94 DIPSTICK	1
570-10470		231.27 CLUTCH SHAFT	1
570-10482		35.79 SUCTION VALVE	4
570-10531		ask GEAR	1
570-10630		32.68 TANK STRAP	19
570-10640		32.68 TANK STRAP	2
570-10650		111.84 ADJUSTING RING	4
570-10791		67.48 SUCTION VALVE	4
570-10803		162.75 SUCTION VALVE	1
570-10804		170.69 SUCTION VALVE	1
570-10871		ask BLOK	2
570-10891		ask BLOK	1
570-10900/6	EXCHANGE	425.00 CRANKSHAFT SR1	1
570-10910		623.81 CRANKSHAFT	1
570-10910/6	EXCHANGE	127.27 CRANKSHAFT	1
570-10951		150.00 CON ROD	8
570-10951/6	second hand	150.00 CONNECTING ROD	2

570-10960		285.11	CYLINDER HEAD	1
570-11061		74.74	OIL RELIEF VALVE	3
570-11071		98.59	OIL RELIEF VALVE	3
570-11171		17.44	BEARING SR	3
570-11171/010		17.44	BEARING SR	3
570-11171/020		17.44	BEARING SR	2
570-11171/030		17.44	BEARING SR	6
570-11171/040		17.44	BEARING SR	4
570-11270		116.63	CAP	3
570-11270/6	second hand	116.63	AIR COWLING	1
570-11308		133.22	PISTON LR	2
570-11320		610.21	CRANKSHAFT	2
570-11340		594.81	OIL PUMP	1
570-11374		377.02	CYLINDER HEAD LR	1
570-11374/6	EXCHANGE	377.02	CYLINDER HEAD LR	1
570-11410		464.56	GEAR TRAIN	2
570-11691		543.34	CYLINDER HEAD SW	4
570-11790		29.57	COVER	2
570-12090		ask	BRACKET	2
570-12100		88.61	BRACKET	2
570-12110		34.14	PISTON RING SET LD	1
570-12110/010		18.92	SET OF PISTON RINGS	55
570-12110/020		16.86	SET OF PISTON RINGS	56
570-12110/040		16.86	SET OF PISTON RINGS	20
570-12120		33.31	PISTON RING SET LR	3
570-12120		33.31	PISTON RING SET LR	3
570-12120/010		33.31	PISTON RING SET LR	8
570-12120/020		33.31	PISTON RING SET LR	2
570-12130/010		17.50	SET OF PISTON RINGS	57
570-12130/020		28.57	PISTON RING SET SL	31
570-12130/040		17.50	SET OF PISTON RINGS	5
570-12140/010		27.93	PISTON RING SET SR	2
570-12160		15.13	BEARING	3
570-12160/010		20.13	BEARING	5
570-12160/020		20.97	BEARING SR	5
570-12160/040		15.13	BEARING	5
570-12170/010		11.84	BEARING SR	2
570-12170/030		11.84	BEARING SR	5
570-12170/040		11.84	BEARING SR	1
570-12180		15.25	BEARING LD/SL	14
570-12180/020		15.25	BEARING LD/SL	9
570-12180/040		15.25	BEARING LD/SL	7
570-12190		25.37	BEARING LD/SL	64
570-12190/010		20.00	BEARING LD/SL	3
570-12190/020		12.28	BEARING	1
570-12190/040		12.80	BEARING	10
570-12220		25.17	GOVERNOR WEIGHT	3
570-12271		240.53	COWLING	2
570-12280		405.00	CRANKSHAFT ST1	1
570-12820		ask	DIPSTICK	2
570-12840/010		102.67	PISTON ST/TS	1
570-12910/010		36.20	PISTON RING SET ST/TS	8
570-12910/020		36.20	PISTON RING SET ST/TS	5
570-12910/040		36.20	PISTON RING SET ST/TS	1
570-12960		5.51	THRUST WASHER ST	7
570-12970		10.72	BEARING ST	21

570-12970/020		10.72 BEARING ST	4
570-12970/040		10.72 BEARING ST	3
570-12980/020		10.80 BEARING ST	5
570-12980/030		10.80 BEARING ST	5
570-12980/040		10.80 BEARING ST	5
570-12990/020		14.66 BEARING ST/TS/TR	1
570-12990/030		14.66 BEARING ST/TS/TR	2
570-12990/040		14.66 BEARING ST/TS/TR	6
570-13001		289.11 CON ROD ST	3
570-13001/6	second hand	257.33 CON ROD ST	1
570-13020		ask CRANKCASE	1
570-13070		10.50 OIL PIPE	7
570-13090		8.50 OIL PIPE	4
570-13100		8.74 OIL PIPE	7
570-13110		4.77 OIL PIPE	15
570-13120		4.39 OIL PIPE	17
570-13130		5.39 OIL PIPE	14
570-13270		ask SWITCH	6
570-13400		9.30 OIL PIPE	2
570-13410		5.43 OIL PIPE	2
570-13420		8.23 OIL PIPE	2
570-13430		7.00 OILPIPE	1
570-13440		16.81 PIPE	1
570-13570		54.13 ROCKER LEVER	23
570-13570/6	second hand	48.18 ROCKER LEVER	1
570-13990		170.07 SILENCER	1
570-14060		126.46 SUPPORT FEET	2
570-14110		27,,72 TOOL KIT	13
570-14150		3.12 STOP BONYOL	3
570-14191		133.66 HYDRAULIC PUMP ADAPTOR	2
570-14210		192.18 PUMP ADAPTOR	1
570-14490		46.02 COVER	1
570-14970		87.18 BRACKET	1
570-15220		70.40 ADAPTOR RING	4
570-15550		14.40 DIPSTICK	1
570-15600		270.59 AIR DUCT	5
570-15690		6.22 REMOTE CONTROL	2
570-15780		208.76 SILENCER	2
570-15910		3.61 SEALING COVER	4
570-16370		14.40 DIPSTICK	6
570-16380		14.40 DIPSTICK	1
570-16400		381.06 ANDERTONCLUTCH	1
570-16520		162.17 AIR CLEANER	3
570-16710		109.80 LEVER	5
570-30163		35.24 BELT TENSIONER	1
570-30411		69.74 PISTON ASSY.	1
570-30431		326.35 STARTER	1
570-30602		79.86 BEARING HOUSING	4
570-30603		95.36 BEARING HOUSING	1
570-30730/6	EXCHANGE	314.61 CYLINDER HEAD TS	1
570-30742		36.97 CYL HEAD COVER	1
570-30990		31.23 WIRING	1
570-31240		52.21 PISTON RING SET TL	14
570-31260		46.56 FUEL FILTER	8
570-31370/075		10.17 BEARING TS/TR	4
570-31460		163.01 SHAFT EXTENSION	6

570-31520		341.45	COUPLING	3
570-31610		ask	ADAPTOR	2
570-31670		129.51	AIR DUCT	1
570-31901		132.36	SPEED CONTROL	4
570-31911		56.61	SPEED CONTROL	10
570-31930		100.49	STOP CONTROL	2
570-32400		255.67	SILENCER	3
570-32421		87.42	GAUGE PANEL	2
570-32490		50.44	TOOL KIT	3
570-32570		105.60	MANIFOLD	1
570-32580		46.21	SOLENOID KIT	1
570-32820		50.66	DUCT	2
570-32840		58.23	SOLENOID KIT	1
570-32850		46.21	SOLENOID KIT	3
570-33030		212.57	FUEL PIPES	3
570-33480		50.40	PISTON RING SET TS	8
570-33520		432.52	ALTERNATOR	1
570-33590		195.85	SUMP TS/TR2	1
570-33600		275.11	SUMP TS/TR3	1
570-34160		392.95	HYDRAULIC PUMP ADAPTOR	1
570-34420		197.08	VALVE ROCKER	1
570-34521		117.70	AXIAL FAN	2
570-34700		105.01	FUEL LIFT PUMP KIT	1
570-34830		ask	COUPLING	1
570-35460		47.00	FUEL PIPE KIT	8
570-35970		99.46	TEMPERATURE SWITCH	5
570-36081		39.76	MOUNTINGKIT	1
570-36150		13.77	BEARING TX	2
570-36300		168.00	OIL PUMP	1
570-36590		4.54	PIPE	2
570-42025		534.80	FLYWHEEL TS/TR1	1
570-50590?		ask	PUMP	1
571-10010		ask	GEAR	1
571-10031		65.31	BEARING	4
571-10090		ask	IMPELLER	1
571-10100		ask	IMPELLER	1
571-10160		10.33	DIPSTICK	1
571-10250		ask	DIPSTICK	1
571-10360		64.58	VALVE	3
571-10690		221.37	WATER PUMP	1
571-10830		3.66	VALVE SPRING	7
571-10840		ask	SET OF PISTON RINGS	2
571-10850/010		6.11	BEARING	2
571-11840		ask	EXTENSION SHAFT	1
572-10013		ask	FLYWHEEL	1
572-10022		39.69	LEVER	4
572-10030/6	second hand	ask	COVER	2
572-10032/6	second hand	ask	COVER	1
572-10090		ask	PIPE	1
572-10091		ask	PIPE	2
572-10100		ask	PULLEY	1
572-10101		ask	PULLEY	1
572-10110		69.90	STARTING HANDLE	3
572-10120		45.46	TRUNNION	3
572-10154		ask	FLYWHEEL	1
572-10192/020		149.45	PISTON HA	1

572-10192/040		149.45	PISTON HA	1
572-10200		ask	CONNECTING ROD	1
572-10240		22.04	DIPSTICK	1
572-10250		14.94	DIPSTICK	1
572-10261		ask	CRANKCASE	1
572-10281/6	EXCHANGE	127.27	CRANKSHAFT	1
572-10301		ask	CYLINDER HEAD	2
572-10361		149.94	CONTROL LEVER	1
572-10420		239.80	GOVERNOR	1
572-10430		ask	LEVER	6
572-10546		1.202.57	FAN ASSY.	1
572-10590		48.65	EDGE FILTER	9
572-10600		ask	OIL DIPSTICK	1
572-10611		28.03	NON RETURN VALVE	8
572-10650		6.78	UNION	2
572-10781		ask	CLAMP	3
572-10860		51.30	BY PASS VALVE	7
572-10900		70.02	GEAR SHAFT	1
572-10960		109.29	BY PASS VALVE	1
572-10980		ask	WHEEL	1
572-10990		842.93	OIL COOLER	1
572-11350		48.18	PISTON	1
572-11350/010		72.15	PISTON	1
572-11381		23.60	GOVERNOR WEIGHT	3
572-11391		46.58	GOVERNOR WEIGHT	28
572-11392		43.01	GOVERNOR WEIGHT	1
572-11393		44.33	GOVERNOR WEIGHT	1
572-11411		890.61	OIL COOLER	1
572-11411/6	second hand	890.61	OIL COOLER	2
572-11450/6	second hand	ask	OIL COOLER	1
572-11490		650.53	OIL COOLER	1
572-11580		23.88	GOVERNOR WEIGHT	8
572-11590		15.28	GOVERNOR WEIGHT	1
572-11630		11.46	GOVERNOR WEIGHT	1
572-11640		15.25	GOVERNOR WEIGHT	4
572-11650		11.46	GOVERNOR WEIGHT	5
572-11661		22.97	GOVERNOR WEIGHT	5
572-11662		32.25	GOVERNOR WEIGHT	35
572-11663		20.26	GOVERNOR WEIGHT	26
572-11664		18.03	GOVERNOR WEIGHT	8
572-11665		20.26	GOVERNOR WEIGHT	3
572-11680		27.64	GOVERNOR WEIGHT	1
572-11701		ask	FLYWHEEL	1
572-11741		191.52	OIL PUMP	2
572-11810/6	second hand	129.25	CYL HEAD COVER	15
572-11890		ask	COVER	2
572-11930		49.43	PISTON RING SET HA	1
572-11930/010		49.43	PISTON RING SET HA	6
572-11930/020		49.43	PISTON RING SET HA	1
572-11930/040		39.36	PISTON RING SET HA	13
572-11940		19.21	BEARING HA	1
572-11940/010		25.00	BEARING HA	9
572-11940/020		25.00	BEARING HA	6
572-11940/030		25.00	BEARING HA	3
572-11940/040		19.90	BEARING HA	3
572-11950/010		7.78	BEARING	9

572-11950/020		7.78 BEARING	8
572-12220		ask GOVERNOR WEIGHT	2
572-40001		176.01 CYLINDER BLOCK	3
572-40001/620	EXCHANGE	90.91 CYLINDER ,020 O/S	1
572-40050/6	second hand	36.03 VALVE ROCKER	9
572-40060/6	second hand	85.53 VALVE ROCKER	6
572-40070		ask ADJUSTING LINK	2
572-40220		229.44 CYLINDER	6
572-40220/610	EXCHANGE	90.91 CYLINDER ,010 O/S	6
572-40260		498.51 EXH.MANIFOLD	1
572-50001/6	second hand	ask FLYWHEEL	1
572-50141		259.48 PISTON HRS	3
572-50220		951.51 CRANKSHAFT	1
572-50220/6	EXCHANGE	500.00 CRANKSHAFT	1
572-50240		943.67 CRANKCASE	1
572-50250		1.136.21 CRANKCASE	1
572-50270/6	second hand	ask CRANKCASE	1
572-50280/6	second hand	108.64 VALVE ROCKER	1
572-50350/6	second hand	437.47 CON ROD HR/HL	2
572-50391		63.90 ROCKER LEVER	6
572-50550		574.22 PUMP COUPLING	1
572-50560		128.94 VALVE ROCKER	2
572-50560/6	second hand	112.62 VALVE ROCKER	2
572-50570/6	second hand	112.62 VALVE ROCKER	3
572-50581		250.83 JOCKEY PULLEY	11
572-50620/040		25.00 PISTON RING	6
572-50622/010		48.15 PISTON RING SET HR/HL	25
572-50622/020		48.15 PISTON RING SET HR/HL	4
572-50622/040		48.15 PISTON RING SET HR/HL	2
572-50628		65.26 PISTON RING SET HL	31
572-50650/020		10.76 BEARING HR/HL	6
572-50650/040		10.76 BEARING HR/HL	6
572-50970		266.17 EXHAUST PIPE	1
572-51590		196.53 SHAFT EXTENSION	2
572-51720		691.69 SAE3 ADAPTOR	1
572-52520		37.96 TOOL KIT	1
572-52670		186.14 MANIFOLD	1
572-52910		240.52 COUPLING	1
572-54320		ask FLANGE KIT	2
572-54330		ask FLANGE KIT	1
572-55250		246.43 PISTON HL	7
572-55340		133.08 PISTON	7
572-55500		ask PIPE	1
572-56080		ask SHAFT	1
572-56080/6	second hand	ask SHAFT	1
572-57480		133.92 MANIFOLD ADAPTOR	3
572-60070/6	second hand	154.76 MANIFOLD	3
572-60130		93.10 FUEL TANK	1
572-60150/6	second hand	ask VALVE	1
572-60160/6	second hand	ask VALVE	1
572-71810		215.41 FUEL LIFT PUMP	3
572-72120		42.56 FUEL LIFT PUMP	1
572-72160		101.64 FUEL LIFT PUMP	1
572-72161		195.44 FUEL LIFT PUMP	1
573-10010		28.17 TAPPET	1
573-10060		156.79 OIL PUMP ASSY	2

573-10070		ask	COVER	1
573-10090			55.00 PIPE	2
573-10140			284.34 FUEL FILTER	1
573-10160			89.67 VALVE	4
573-10210			24.13 LEVER	6
573-10440			59.60 STARTING HANDLE	1
573-10510			59.24 CARRIER	1
573-10520			18.06 GOVERNOR LEVER	3
573-10640			286.55 SILENCER	4
573-10770		ask	PIPE	1
573-10940			189.27 HAND START VALVE	1
573-11050		ask	CAMSHAFT	1
573-11210	616-01045		46.05 ROCKER ARM	2
573-11220			153.28 BEARING HOUSING	3
573-11460			251.75 PUMP	1
573-11640			225.95 PINION	3
573-11820			6.72 FILTER WICK	7
573-12010			56.28 PLUG	5
573-12020		ask	VALVE	1
574-10050			34.36 SHAFT	1
574-10130			216.70 OIL PUMP	2
574-10170			22.04 ROCKERLEVER	8
574-10200			316.70 CON ROD 8/1	1
574-10340		ask	PISTON	5
574-10350		ask	PISTON	4
574-10870			455.81 CAMSHAFT 6/1	2
574-10960			22.09 PISTON RING SET 3/1	1
574-10970			25.37 PISTON RING SET 8/1	14
574-10990			37.78 PISTON RING SET 8/1	1
574-11070			302.97 CYLINDER HEAD	2
574-11110			240.73 CYLINDER HEAD	2
575-10520		ask	BEARING	2
582-08185		ask	PIPE	1
582-10023			79.52 GOVERNOR LEVER	1
582-10023/6	second hand		79.52 GOVERNOR LEVER	1
582-10030/6	second hand		720.52 OIL COOLER ASSY	2
582-10071			156.18 CONTROL LEVER	1
582-10081			162.05 BRACKET	3
582-10162			14.47 DIPSTICK	1
582-10180		ask	FILTER	1
582-10180/6	second hand	ask	OIL FILTER	2
582-10193/020			88.23 PISTON	1
582-10194		ask	PISTON	5
582-10240		ask	PINION	1
582-10260/010			30.54 BEARING JA/W/S	1
582-10260/020			30.54 BEARING JA/W/S	4
582-10260/040			30.54 BEARING JA/W/S	8
582-10300			256.82 CONNECTING ROD	4
582-10300/6	second hand		56.54 CONNECTING ROD	8
582-10302			296.18 CONNECTING ROD	11
582-10310		ask	OIL FILLER	2
582-10310/6	second hand	ask	PIPE	1
582-10320/6	second hand		67.47 ROCKER BRACKET	11
582-10330/6	second hand		67.47 ROCKER BRACKET	11
582-10340			59.97 ROCKER ARM	7
582-10340/6	second hand		32.46 ROCKER LEVER	12

582-10351		83.92	TAPPET	6
582-10360		65.38	OIL RELIEF VALVE	1
582-10360/6	second hand	65.38	OIL RELIEF VALVE	1
582-10433		940.00	CYLINDER HEAD JA/S	1
582-10433/6	EXCHANGE	940.00	CYLINDER HEAD JA/S	2
582-10440/6	second hand	ask	PIPE	1
582-10470		ask	OIL COOLER	1
582-10500		46.66	CLAMP PAD	3
582-10520/6	second hand	402.97	OIL FILTER	1
582-10670		307.08	JOCKEY PULLEY	1
582-11101		ask	FLANGE	1
582-11270		259.07	PISTON JA/WS	1
582-40030		967.33	GEAR TRAIN	14
582-40092/6	EXCHANGE	1.229.40	CYLINDER HEAD JW/S	4
591-01151		ask	MANIFOLD	1
600-00106		0.25	WASHER	94
601-20050		1.55	VALVE COTTER	18
601-20261		2.17	NIPPLE	1
601-20300		161.00	INJECTOR LT	1
601-20470		0.39	SHIM	39
601-20471		0.54	SHIM	42
601-20474		1.64	SHIM	13
601-20475		1.67	SHIM	7
601-20476		2.13	SHIM	7
601-20477		2.13	SHIM	4
601-20561		22.49	OIL PUMP PUSH ROD	3
601-20571		8.90	PLUNGER CAP	4
601-20602		3.77	SPRING	1
601-20770		0.66	RETAINING RING	27
601-20800		5.84	ADJUSTING SCREW	11
601-20821		2.92	ADJUSTING SCREW	5
601-20861		18.80	GOVERNOR LEVER	1
601-20900		1.37	BRACKET	4
601-20910		1.08	PIVOT PIN	11
601-21000		0.60	SPACER	70
601-21090		2.08	ADJUSTING SCREW	6
601-21130		0.12	PIN	10
601-21131		0.53	PIN	16
601-21190		1.02	SPRING RING	2
601-21210		0.19	JOINT	29
601-21211		0.28	JOINT	122
601-21217		3.26	JOINT	6
601-21220		27.45	GEAR WHEEL	2
601-21230		1.32	FUEL PIPE	2
601-21266		33.05	FUEL PIPE	2
601-21267		33.34	FUEL PIPE	6
601-21370		2.88	SCREW	2
601-21390		7.29	TAPPET ROLLER	1
601-21400		7.29	ROLLER BUSH	1
601-21410		1.57	ROLLER PIN	3
601-21460		1.35	BOLT	1
601-21620		1.00	BLEED SCREW	5
601-21660		1.18	THRUST WASHER	4
601-21670		3.03	CAMSHAFT BUSH	1
601-21711/098		35.00	FUELPUMP	3
601-21712/098		35.00	FUELPUMP	5

601-21714/098	35.68 FUEL PUMP	27
601-21750	1.83 THRUST PAD	5
601-21780	11.04 TAPPET GUIDE	1
601-21788	ask BUSH	1
601-21860	5.29 TAPPET INSERT	1
601-21870	0.92 FUEL PUMP SHIM	5
601-21871	0.25 FUEL PUMP SHIM	10
601-21990	2.12 WASHER	4
601-22000	2.12 WASHER	1
601-22010	2.36 WASHER	1
601-22020	1.53 WASHER	1
601-22048	ask BOLT	1
601-22080	1.60 BUSH	1
601-22091	ask BRACKET	1
601-22122	1.28 SPRING	3
601-22130	1.83 JOINT	7
601-22340	2.36 PLUG	2
601-30050	ask BOLT	3
601-30060/050	14.93 BEARING LT/LV	1
601-30061/050	16.54 BEARING LT/LV	1
601-30100	1.29 CIRCLIP	7
601-30140	7.66 STUD	8
601-30150	5.67 CON ROD BUSH LT	4
601-30170	93.00 SUMP	2
601-30180	0.13 SUMP JOINT	21
601-30221	2.84 VALVE SPRING LT/LV	39
601-30222	2.35 VALVE SRING LT/LV	2
601-30244	36.55 STUB SHAFT	3
601-30260	1.30 RUBBER SEAL	4
601-30262	2.08 RUBBER CUP	15
601-30263	2.08 RUBBER CUP	13
601-30271	187.21 CYLINDER BARREL LT	1
601-30280	1.89 PUSH ROD TUBE	2
601-30281	8.68 PUSH ROD TUBE	4
601-30300	24.49 VALVE TAPPET	18
601-30300	24.49 VALVE TAPPET	18
601-30310	6.49 PUSH ROD	6
601-30321	5.29 VALVE GUIDE LT/LV	8
601-30330	7.29 VALVE INSERT	1
601-30350	2.30 VALVE SPRING CARRIER	17
601-30351	9.68 VALVE SPRING CARRIER	20
601-30361	9.28 INLET VALVE LT/LV	12
601-30372	10.64 EXHAUST VALVE LT/LV	25
601-30380	1.64 CYL HEAD GASKET	2
601-30390	0.58 JOINT	18
601-30401	ask PIN	5
601-30402	5.74 VALVE GUIDE LT/LV	10
601-30411	1.80 CYL HEAD SHIM	1
601-30510	1.84 JOINT	28
601-30511	1.98 JOINT	8
601-30513	2.10 JOINT	2
601-30540	1.89 INSPECTION DOOR	1
601-30550	0.86 JOINT	14
601-30553	0.57 JOINT	7
601-30600	ask SHIELD	1
601-30681	296.44 CYLINDER HEAD	1

601-30880	5.36 BOLT	2
601-30890	37.79 NOZZLE	1
601-30943	2.14 SWIVEL UNION PLUG	7
601-30946	9.34 SWIVEL UNION	6
601-30948	9.34 SWIVEL UNION	1
601-30960	12.02 CLAMP	2
601-31010	ask SWIVEL UNION PLUG	1
601-31011	8.04 SWIVEL UNION	5
601-31030	29.01 OIL PIPE	1
601-31100	0.25 DOWEL PIN	10
601-31222	ask WASHER	6
601-31361	0.48 SEALING RING	4
601-31491	ask SILENCER	3
601-31510	174.78 FANSHROUD	1
601-31520	34.41 COWLING	2
601-31582	8.97 FAN	2
601-31622	3.21 SEALING RING	41
601-31630	0.78 SHIM	14
601-32150	10.00 FILTERADAPTOR	1
601-32151	71.93 FILTER ADAPTOR	3
601-32170	2.98 STAY	17
601-32340	0.12 O RING	1
601-32420	6.57 BREATHER BOX	1
601-32470	0.61 WASHER	6
601-32480	1.18 WASHER	3
601-32570	4.26 BUSH	2
601-32590	ask DISTANCE PIECE	1
601-32600	0.44 CONTROL LEVER	1
601-32660	0.65 SPRING	2
601-32670	0.60 SPRING	2
601-32681	1.84 CONTROL PLATE	1
601-32780	0.71 FELT RING	6
601-32790	1.41 O RING	4
601-32821	0.79 FELT RING	27
601-32830	94.14 FLEXIBLE DISC	5
601-32891	14.40 STUD	5
601-32900	0.82 TAB WASHER	13
601-32910	0.46 WASHER	20
601-32920	1.08 KEY	3
601-32934	ask GOVERNOR WEIGHT	4
601-32936	ask GOVERNOR WEIGHT	4
601-32940	ask SPRING	1
601-32950	10.25 OIL FILTER	12
601-33037	177.02 SHAFT EXTENSION	18
601-33039	173.72 SHAFT EXTENSION	4
601-33040	4.99 STUD	44
601-33041	3.85 STUD	25
601-33130	4.87 SCREW	2
601-33220	1.84 GOVERNOR SHOE	2
601-33300	1.40 SHIM	93
601-33412	4.70 ROCKER BUSH	4
601-33500	0.39 CLIPS	4
601-33501	0.81 PIPE CLIP	4
601-33510	1.20 SPACER	8
601-33560	ask CLIPS	10
601-33632	1.34 JOINT	11

601-33740		2.31 GROMMET	2
601-33771		3.77 SPRING	6
601-33942		3.66 SPRING	1
601-33950		1.15 SCREW	2
601-33951		2.36 ADJUSTING SCREW	3
601-33970		0.82 SPRING	8
601-33971		3.60 SPRING	1
601-33975		3.44 SPEEDER SPRING	1
601-33976		4.47 SPEEDER SPRING	3
601-33980		0.23 CIRCLIP	11
601-34000		0.92 SPRING	10
601-34180		10.40 FUEL HOSE	3
601-34251		7.44 BUSH	1
601-34440		0.32 SHIM	9
601-34441		0.70 SHIM	12
601-34442		0.81 SHIM	17
601-34450		0.78 COLLAR	26
601-34710		1.08 SEALING RING	10
601-34890		1.21 KEY	11
601-35271	ask	JOINT	20
601-35382		48.60 ROCKER LEVER	2
601-35410		1.26 STUD	3
601-35440		0.25 FELT RING	1
601-35660		20.23 OIL SEAL LT	23
601-35680		204.93 SHAFT EXTENSION	1
601-35690		0.26 SHIM	3
601-36130		21.83 INJECTOR CLAMP	1
601-36160		7.13 UNION ADAPTOR	1
601-36920		0.15 JOINT	1
601-36921		0.48 JOINT	9
601-37140		1.36 FUEL HOSE	20
601-37560		0.39 JOINT	16
601-37620		0.28 TRANSFERS	11
601-37650		11.67 BRACKET	5
601-37860		46.97 FUEL TANK	1
601-37860C		31.79 FUEL TANK	1
601-38050		5.23 BUSH	2
601-38320		16.98 OIL SEAL LT	2
601-38360		0.61 NIPPLE	41
601-38370		5.01 NUT	2
601-38450		3.22 UNION	3
601-39540/9	non genuine	11.61 OIL SEAL LT	2
601-39690		8.99 SLEEVE	1
601-39860		4.56 CATCH PIN	1
601-39870		187.59 SHAFT EXTENSION	1
601-39911		1.40 JOINT	1
601-40090		3.44 CON ROD BOLT	5
601-40540		1.70 CYL HEAD GASKET	11
601-40550		0.75 CYL HEAD SHIM	8
601-40551		0.94 CYL HEAD SHIM	9
601-40890		42.28 MANIFOLD	1
601-41050		10.72 ELBOW	6
601-41190		11.62 GOVERNOR LINK	1
601-41790		6.56 OIL SEAL	1
601-41970		8.63 THRUST WASHER	1
601-42072		4.97 TAPER LOCK BUSH	3

601-43460	5.30 FUEL PIPE	1
601-50012	ask STARTING HANDLE	2
601-50015	28.12 STARTING HANDLE	1
601-50023	43.20 STARTING HANDLE	4
601-50060	ask FUEL FILTER	1
601-50070	ask CONNECTING ROD	2
601-50150	15.30 GOVERNOR SLEEVE	1
601-50180	81.21 FUEL PUMP TAPPET	4
601-50190	210.16 PISTON LT	2
601-50280	ask BEARIING HOUSING	1
601-50282	57.93 BEARING HOUSING	1
601-50340	ask SHIELD	1
601-50360	104.38 SHAFT EXTENSION	2
601-50370	188.66 BB COUPLING	1
601-50420/025	11.32 BEARING LT/LV	2
601-50420/050	11.32 BEARING LT/LV	1
601-50430	ask SHIELD	4
601-50451	51.74 FUEL FILTER	2
601-50461	6.30 SHIELD	1
601-50660	19.45 GOVERNOR WEIGHT	1
601-50670	21.30 GOVERNOR WEIGHT	2
601-51080	34.63 CAMSHAFT GUARD	2
601-51141	55.90 PISTON ASSY.	3
601-51320	16.47 GOVERNOR WEIGHT	1
601-51400	19.45 GOVERNOR WEIGHT	4
601-51570	96.51 BD SHAFT EXTENSION	1
601-52060	217.87 FUEL TANK	1
601-52080	166.02 FUEL FILTER	2
601-52090	23.16 EXHAUST BEND	1
601-52780	232.03 CON ROD LT/LV	5
601-52790	13.94 SIDE SHIELD	1
601-53630	37.35 PISTON RING SET LV	2
601-53900	220.50 COUPLING	1
601-54960	17.39 FUEL PIPE	1
602-20610	59.45 OIL PUMP CYLINDER	5
602-20611	46.01 OIL PUMP CYLINDER	1
602-30180	0.13 SUMP JOINT	6
602-36270	12.80 MAIN BEARING	3
602-36340	8.02 WASHER	1
602-36660	32.19 ADAPTOR	14
602-36710	21.47 BLANKING PLATE	6
602-36720	0.25 JOINT	3
602-37030	38.17 STUD	3
602-37060	0.33 TAB WASHER	3
602-37070	2.77 BLANKING PLATE	1
602-37590	1.48 O RING	6
602-37600	1.08 CABLE STRAP	5
602-38140	87.12 SILENCER	3
602-38141	80.86 SILENCER	2
602-38200	10.44 RECTIFIER COVER	3
602-38250	15.48 UNION	2
602-38330	3.62 STUD	4
602-38350	1.23 DISTANCE PIECE	12
602-38800	10.62 UNION	4
602-53980	21.36 PIPE	1
602-54040	ask LEAK-OFF PIPE	1

605-00012	4.26 BULB	1
606-00662	ask FLANGE	2
606-20190/003	49.07 END COVER	3
606-20190/004	27.38 END COVER	4
606-20190/005	11.75 END COVER	2
606-90165/003	26.08 IMPELLOR	1
607-10000	0.70 TERMINAL COVER	2
607-10019	1.01 TERMINAL BLOCK	2
607-10030	ask WIRE	1
611-00723	54.02 EXH.MANIFOLD	6
612-00212	ask SHAFT	2
612-00245	49.67 VALVE	12
612-00271	0.44 JOINT	1
612-00309	34.27 NUT	5
612-00310	29.73 CC PLUG	2
612-00323	ask BEARING	1
612-00323/001	ask BEARING	1
612-00337	36.18 BUSH	4
612-00359	1.24 JOINT	9
612-00361	1.23 JOINT	15
612-00455	70.25 PINION	1
614-00128	123.65 FUEL PUMP GEAR	1
614-00205	0.18 JOINT	7
614-00207	47.38 PINION	1
614-00208	60.32 PINION	1
614-00211	9.02 BUSH	3
614-00212	16.69 SHAFT	4
614-00213	15.26 BUSH	3
614-00230	ask PULLEY	2
614-00247	0.12 JOINT	9
614-00349	1.08 FLANGE JOINT	24
614-00359	1.16 JOINT	29
614-00370	18.10 HOUSING	10
614-00371	ask FLANGE	3
614-00434	0.12 JOINT	2
614-00435	ask FLANGE	3
614-00450	0.95 JOINT	5
614-00557	0.25 JOINT	1
614-00558	0.12 JOINT	1
614-00568	ask WHEEL	3
614-00580	0.43 JOINT	3
614-00581	88.43 GOVERNOR SLEEVE	1
614-00586	408.52 MANIFOLD	1
614-00592	ask SHAFT	1
614-00593	ask SHAFT	1
614-00594	ask JOINT	4
614-00600	ask COVER	3
614-00601	0.33 JOINT	4
614-00613	33.38 SHAFT	1
614-00618	0.17 JOINT	10
614-00667	60.28 SHAFT	2
614-00671	28.18 AIR PIPE	1
614-00672	3.41 BUSH	22
614-00673	6.13 NUT	5
614-00674	0.62 LOCK WASHER	2
614-00702	0.18 JOINT	6

614-00708	211.20	SHAFT	1
614-00711	ask	BRACKET	1
614-00715	31.88	BUSH	5
614-00716	25.44	BUSH	3
614-00718	0.17	JOINT	8
614-00719	2.00	JOINT	18
614-00720	24.13	LEVER	6
614-00723	92.24	EXH.MANIFOLD	5
614-00724	0.81	SCREW	1
614-00725	27.41	PUSH ROD	11
614-00729	1.00	JOINT	22
614-00749	125.56	DISTRIBUTOR BODY	1
614-00756	48.31	COVER	1
614-00759	23.14	HALF COUPLING	1
614-00760	41.75	COUPLING	4
614-00764	18.22	VALVE	1
614-00771	0.60	SPRING	6
614-00772	0.45	JOINT	5
614-00792	64.01	GEARWHEEL	2
614-00793	45.41	SHAFT	2
614-00809	ask	BRACKET	1
614-00823	6.87	PIN	14
614-00824	19.30	HOUSING	2
614-00830	0.16	JOINT	3
614-00831	6.02	INLET VALVE	1
614-00833	5.21	VALVE SPRING CARRIER	20
614-00835	0.25	JOINT	3
614-00837	ask	COVER	1
614-00838	0.73	JOINT	3
614-00839	0.65	JOINT	7
614-00905	41.16	STRAINER	1
614-00914	ask	VALVE	2
614-00924	1.49	JOINT	5
614-00926	40.37	SWIVEL UNION	2
614-01125	ask	MANIFOLD	1
614-01141	13.21	DOOR	2
615-00723	52.86	EXH.MANIFOLD	3
616-00252/007	114.19	CYLINDER LINER	7
616-00319	0.54	JOINT	4
616-00365	ask	COVER	1
616-00367	1.52	JOINT	21
616-00401	ask	JOINT	2
616-00493	5.21	CIRCLIP	1
616-00501	ask	GOVERNOR WEIGHT	10
616-00502	9.77	SHAFT	1
616-00574	29.38	ADAPTOR	4
616-00670	ask	HOUSING	1
616-00676	ask	COVER	1
616-00677	ask	COVER	1
616-00680	ask	COVER	1
616-00700	0.17	JOINT	9
616-00701	ask	JOINT	9
616-00707	0.12	JOINT	5
616-00786	ask	BOLT	12
616-00790	26.44	WATER PUMP COVER	1
616-00860	27.48	RETAINER	2

616-01014	35.82	WATER INLET PIPE	3
616-01015	53.28	WATER INLET PIPE	2
616-01144	0.15	JOINT	2
616-01162	ask	VALVE	13
616-01163	ask	VALVE	7
616-011901	ask	HOUSING	1
616-01294	ask	GEAR RING	2
616-01300	0.17	JOINT	11
616-01301	0.32	JOINT	9
616-01302	0.34	JOINT	9
616-01303	0.89	JOINT	18
616-01304	0.17	JOINT	6
616-01305	0.34	JOINT	9
616-01356	ask	HOUSING	1
616-01461	0.17	JOINT	17
616-01522	ask	PIPE	4
616-01538	ask	BOLT	6
616-01586	0.09	CIRCLIP	8
616-01621	ask	BRACKET	1
616-01623	0.08	SPRING	1
616-01669	ask	VALVE	5
616-01670	ask	HOUSING	2
616-01719	ask	PUMP	1
616-01721	76.42	IMPELLER	1
616-01722	82.69	IMPELLER	4
616-01741	ask	FILTER	1
616-01759	ask	BRAKE BAND	2
616-01779	0.53	WASHER	21
616-01841	0.34	JOINT	3
616-01864	ask	FLANGE	1
616-01891	0.60	JOINT	4
616-01892	5.83	BUSH	2
616-01894	70.60	SHAFT	1
616-01895	2.12	O RING	100
616-01896	ask	PINION	1
616-01898	0.53	JOINT	11
616-01902	ask	COVER	3
616-01916	7.28	SPRING	1
616-01929	ask	BRACKET	4
616-01981	ask	FILTER	2
616-01983	ask	JOINT	10
616-02042	ask	BEND	3
616-02046	ask	PIPE	1
616-02048	ask	BEND	1
616-02092	ask	MANIFOLD	1
616-02096	14.20	PIPE	1
616-02144	69.90	INJECTOR	3
616-02145	27.33	NOZZLE	1
616-02147	22.17	FUEL PIPE	3
616-02148	26.83	FUEL PIPE	3
616-02149	21.08	FUEL PIPE	5
616-02150	17.36	FUEL PIPE	3
616-02151	12.87	FUEL PIPE	3
616-02273	15.69	PIPE	8
616-02275	2.75	STUD	2
616-02284	609.91	CAMSHAFT	1

616-02285	ask	MANIFOLD	1
616-02286		88.21 WATER OUTLET PIPE	1
616-02292		22.94 PLUG	4
616-02293		19.17 PLUG	3
616-02308		25.74 TEE PIECE	1
616-02344		36.89 STUD	16
616-02345		27.99 COUPLING BOLT	21
616-02833		16.51 MOUNTING BRACKET	4
616-02834		21.01 PANEL	2
616-02923/020		127.10 BEARING	2
616-02924/020		142.20 BEARING	4
616-02925/020		252.45 BEARING	2
616-02926/020		148.40 BEARING	3
616-02926/040		148.80 BEARING	2
616-02927		232.90 BEARING	1
616-02927/020		232.90 BEARING	2
616-03192		2.87 JOINT	6
616-03670	ask	JOINT	10
616-16690		47.74 NUT	2
624-21220		27.34 FUEL FILTER	9
624-21700		71.99 AIR CLEANER ELEMENT	1
630-10430	ask	PINION	1
632-10030	ask	OIL SEAL	4
632-10260	ask	OIL SEAL	2
632-10450	ask	BEARING	2
632-15150	ask	O-RING	3
632-15320	ask	PINION	1
633-10280	ask	LEVER	2
636-10000		14.41 COVER	4
636-21651		219.46 HOUR RECORDER	1
639-10350		2.60 WASHER	89
639-11070		2.79 SPRING WASHER	138
639-12991		123.83 OIL PIPE	2
642-00175		61.11 SOLENOID	1
642-00178	ask	SPEED CONTROL	3
642-00555	ask	COIL	3
642-00663		609.72 SOLENOID	2
642-01549/12V		157.05 CONTROL UNIT	1
6420-200	ask	WATER PUMP	1
644-00105		87.15 LEVER	15
644-00106		46.22 LEVER	2
644-00107		41.62 LEVER	2
657-10085		36.23 JOINT SET SL3 D/C	1
657-10095		67.48 JOINT SET SL3 O/H	1
657-10380		18.89 JOINT SET 6-1 D/C	3
657-10391		12.67 JOINT SET 6/1 O/H	5
657-10400		17.22 JOINT SET 8-1 D/C	9
657-10411		12.21 JOINT SET 8/1 O/H	4
657-10712		121.84 JOINT SET HA6 D/C	1
657-10724		228.30 JOINT SET HA6 O/H	3
657-10748		31.12 JOINT SET SR1 O/H	1
657-10775		12.33 JOINT SET SR3 D/C	1
657-10789		56.80 JOINT SET SR3 O/H	3
657-10791		18.47 JOINT SET VA D/C	6
657-10803		29.32 JOINT SET VA O/H	2
657-10803		29.32 JOINT SET VA O/H	2

657-10840	ask	SET OF JOINT	2
657-10870	ask	JOINT	3
657-11050	ask	SET OF JOINT	2
657-12133	47.06	JOINT SET HW2 O/H	1
657-12191	ask	SET OF JOINT	1
657-13251	ask	KIT	1
657-17026	55.86	JOINT SET LR2 O/H	1
657-17041	14.93	JOINT SET LR1 O/H	1
657-17045	40.61	JOINT SET LR1 O/H	1
657-17212	153.24	JOINT SET	1
657-18980	21.25	JOINT SET SR4 D/C	4
657-19151	ask	VALVE	2
657-19160	ask	NIPPLE	6
657-19697	23.56	JOINT SET HR2 D/C	2
657-19751	49.96	JOINT SET HR6 D/C	2
657-19754	131.92	JOINT SET HR6 D/C	4
657-20040	ask	GEAR	1
657-20807	177.25	JOINT SET HRW3 O/H	1
657-20816	168.45	JOINT SET HRW4 D/C	4
657-20828	278.04	JOINT SET HRW4 O/H	1
657-20837	245.47	JOINT SET HRW6 D/C	2
657-20848	386.60	JOINT SET HRW6 O/H	5
657-21547	168.90	JOINT SET HRS6 D/C	1
657-21588	264.72	JOINT SET HRWS6 D/C	3
657-21596	396.49	JOINT SET HRWS6 O/H	4
657-22140	136.31	ADAPTOR RING	3
657-22175	305.93	JOINT SET JA6 O/H	1
657-22186	187.44	JOINT SET JA6 D/C	2
657-22541	ask	FILTER	1
657-22550	ask	FILTER	1
657-22550	ask	COVER	1
657-23267	283.89	JOINT SET JW6 D/C	3
657-23276	534.65	JOINT SET JW6 O/H	1
657-23364	231.38	JOINT SET JAS6 D/C	2
657-23373	439.42	JOINT SET JAS6 O/H	1
657-23503	12.01	JOINT SET ST1 D/C	3
657-23511	14.84	JOINT SET ST1 O/H	2
657-25998	5.85	JOINT SET LT1 D/C	4
657-28574	12.30	JOINT SET LT1 O/H	1
657-28680	236.04	JOINT SET JWSC6 O/H	1
657-29022	31.84	JOINT SET LT2 D/C	2
657-29442	11.71	JOINT SET LV1 O/H	1
657-29452	16.91	JOINT SET LV2 O/H	4
657-29460	4.78	JOINT SET LV1 D/C	2
657-29461	12.70	JOINT SET LV1 D/C	1
657-29470	8.44	JOINT SET LV2 D/C	1
657-29471	27.74	JOINT SET LV2 D/C	1
657-29501	29.26	JOINT SET TS2 D/C	2
657-29540	13.10	JOINT SET TL2 D/C	4
657-29541	36.67	JOINT SET TL2 D/C	4
657-29551	62.96	JOINT SET TL2 O/H	1
657-29560	18.98	JOINT SET TL3 D/C	1
657-31440	112.28	JOINT SET HL3 O/H	2
657-314427	ask	JOINT	4
657-31450	95.81	JOINT SET HL4 D/C	1
657-31460	166.55	JOINT SET HL4 O/H	2

657-31470	138.54 JOINT SET HL6 D/C	5
657-31480	218.64 JOINT SET HL6 O/H	4
657-31490	64.14 HOINT SET HLT6 D/C	3
657-31491	169.35 JOINT SET HLT6 D/C	3
657-31501	242.43 JOINT SET HLT6 O/H	1
657-32670	9.45 JOINTSET	3
657-32680	11.61 JOINT SET TS1 O/H	4
657-32681	30.76 JOINT SET TS1 O/H	2
657-33430	224.30 JOINT SET CS4 O/H	1
657-33450	108.40 JOINT SET CS6 D/C	1
657-33460	97.31 JOINT SET CST6 D/C	1
657-33480	59.73 JOINT SET CS/T6	1
657-33500	15.41 JOINT SET	1
657-33520	40.19 JOINT SET CR3 D/C	6
657-33960	38.52 JOINT SET TX2 D/C	3
657-33970	55.75 JOINT SET TX2 O/H	1
657-34181	61.46 JOINT SET LPA2 O/H	2
657-34231	39.20 JOINT SET LPW/S2 D/C	5
657-34241	66.94 JOINT SET LPW/S2 O/H	3
657-34260	39.09 SET OF JOINT	1
657-35160	104.19 JOINT SET DWS4 D/C	1
658-13450	ask SET OF JOINT	1
658-16411	74.70 JOINT SET STW3 D/C	1
658-16431	119.55 JOINT SET STW3 O/H	3
660-10030	0.33 WASHER	64
660-10040	0.02 JOINT	2
660-10060	1.10 WASHER	4
660-10110	ask CAMSHAFT	1
660-10160	ask COVER	2
660-10190	0.45 JOINT	3
660-10200	14.34 SCREW	2
660-10210	14.61 QUADRANT	4
660-10220	0.34 SCREW	13
660-10230	ask SCREW	3
660-10240	1.04 OIL THROWER	7
660-10250	0.55 SHIM	8
660-10260	0.62 SHIM	4
660-10320	0.38 NUT	15
660-10340	6.57 SCREW	1
660-10390	12.04 PLUG	3
660-10410	4.95 SCREW	2
660-10420	0.21 NUT	1
660-10430	6.29 SEAT	5
660-10480	1.32 WASHER	8
660-10490	ask SEAT	5
660-10520	117.49 CONTROL ROD	2
660-10530	68.55 CONTROL ROD	1
660-10550	1.50 JOINT	3
660-10560	15.10 BUSH	2
660-10570	9.10 SCREW	1
660-10590	ask WASHER	2
660-10600	18.18 DELIVERY VALVE	12
660-10610	3.22 VALVE SPRING	14
660-10650	12.09 BUSH	2
660-10660	16.28 PLUG	1
660-10690	3.91 SCREW	17

660-10710		0.85 SCREW	5
660-10800		5.84 NUT	1
660-10810		2.15 SPINDLE	1
660-10830		1.24 WASHER	1
660-10900		18.15 FUEL PUMP ELEMENT	1
660-10910		44.64 FUEL PUMP ELEMENT	9
660-10950		10.79 BUSH	6
660-11040/9	non genuine	17.84 FUEL PUMP ELEMENT	4
660-11080		10.35 BALL BEARING	28
660-11110		5.20 NUT	9
660-11130	ask	SCREW	25
660-11330		0.04 JOINT	13
660-13050		12.42 FUEL PUMP ELEMENT	8
660-13060		7.64 TAPPET	1
660-13080	ask	HOUSING	2
660-13090	ask	CAMSHAFT	14
660-13100		18.58 CAMSHAFT	6
660-13130		22.39 FUEL PUMP ELEMENT	11
660-13130/9	non genuine	19.93 FUEL PUMP ELEMENT	1
660-13160	ask	CAMSHAFT	7
660-13330	ask	JOINT	6
660-13630		22.19 FUEL PUMP ELEMENT	10
660-13650		32.60 FUEL PUMP ELEMENT	2
660-13680		0.29 SPRING	30
660-13700		7.19 BALL BEARING	12
660-13720		178.73 CAMSHAFT	26
660-13730		1.49 BEARING	9
660-13760/9	non genuine	19.75 FUEL PUMP ELEMENT	10
660-13830		5.03 JOINT	4
660-13880		44.64 FUEL PUMP ELEMENT	12
660-14200		16.00 FUEL PUMP ELEMENT	4
660-14260		23.03 FUEL PUMP ELEMENT	9
660-14270		9.73 DELIVERY VALVE	8
660-14280		1.56 SHIM	6
660-14310		1.71 SHIM	1
660-14350		1.55 SHIM	1
660-14360		1.55 SHIM	15
660-14380		1.55 SHIM	9
660-14390		1.55 SHIM	2
660-14410		1.02 SHIM	4
660-14500		22.39 FUEL PUMP ELEMENT	1
660-14511		29.92 FUEL PUMP ELEMENT	3
660-14550		58.80 NON RETURN VALVE	1
661-10160	ask	PLATE	1
661-10260	ask	RIVET	9
661-10270	ask	PLATE	2
661-10440	ask	LINING	3
662-10110		0.05 SCREW	16
662-10130		0.54 SPRING	1
662-10170		0.31 SHAFT	4
662-10180		0.05 LOCK	5
662-10190		1.72 LEVER	8
662-10200		0.06 WASHER	8
662-10210		7.23 ROCKER ARM	2
662-10220		0.15 SPRING	3
662-10240		0.27 SCREW	2

662-10290	10.85	UPPER CASTING	1
662-10300	4.45		1
662-10340	1.57	LEVER	1
662-10350	0.10	WASHER	8
662-10370	0.52	PIN	2
662-10390	1.15	SPRING	1
662-10640	66.32	FUEL LIFT PUMPO	4
663-10000	ask	RING	3
663-10010	ask	BEARING	5
663-10020	ask	NUT	2
663-10040	ask	PLATE	1
663-10060	ask	PLATE	1
663-10070	ask	RING	1
663-10080	ask	VALVE	19
663-10090	ask	SPRING	19
663-10110	ask	SPLIT BOLT	8
663-10120	ask	SPLIT PIN	12
663-10150	ask	SPLIT BOLT	20
663-10160	ask	SPLIT PIN	6
663-10180	ask	YOKE	3
663-10200	ask	NUT	4
663-10220	ask	LEVER	3
663-10250	ask	SHAFT	2
663-10290	ask	PIPE	2
663-10300	ask	NUT	1
663-10350	ask	KEY	7
663-10380	ask	KEY	1
663-10450	ask	NUT	1
663-10460	ask	SPRING WASHER	2
665-10020	ask	HOUSING	1
665-10040	ask	HEAT EXCHANGER	1
665-10060	ask	PIPE	1
665-10070	ask	ELEMENT	1
665-10080	26.53	COVER	7
665-10100	11.05	COVER	6
665-10110	ask	RING	2
665-10120	ask	RING	1
665-10130	3.15	JOINT RING	25
665-10140	9.65	STUD	18
665-10150	ask	STUD	13
665-10160	9.16	STUD	8
665-10170	ask	WASHER	1
665-10240	11.22	NUT	25
665-10340	ask	COVER	5
665-10350	ask	COVER	1
665-10390	2.83	O-RING	71
665-10400	5.25	JOINT RING	67
665-10410	24.50	STUD	9
665-10420	ask	NUT	21
665-10430	ask	JOINT	1
665-10480	ask	COOLER	1
665-10510	ask	RING	15
671-10450	ask	CYLINDER HEAD	1
679-10020	0.87	BLEED SCREW	19
679-10030	1.11	JOINT	127
680-10200	ask	COIL	1

680-10260		ask	COVER	1
684-30200		ask	SWITCH	1
691-00001			49.18 BRACKET	4
691-00008			106.83 EXTENSION SHAFT	5
691-00013/6	second hand	ask	MANIFOLD	1
691-00014/6	second hand	ask	MANIFOLD	1
691-00045			265.00 HALF COUPLING	2
691-00117			350.00 EXHAOST BELLOWS	4
691-00125/009		ask	MORSECABLE	1
691-00126			0.40 WASHER	96
691-00134		ask	PULLEY	4
691-00140		ask	PULLEY	3
691-00156			15.10 OIL OPIPE	6
691-00157			19.67 OIL OPIPE	3
691-00159/6	second hand		41.60 OIL PIPE	1
691-00161			14.16 BRACKET	6
691-00163			6.40 BRACKET	3
691-00170			1.31 BRACKET	8
691-00185		ask	PANEL	5
691-00193		ask	BUSH	2
691-00201		ask	BRACKET	5
691-00205			36.80 LEVER	2
691-00229		ask	FLANGE	2
691-00244		ask	GOVERNOR	1
691-00246		ask	GOVERNOR	1
691-00256		ask	GAUGE	1
691-00273			218.81 INJECTOR PIPE	21
691-00292		ask	SHIELD	1
691-00390		ask	CYLINDER	2
691-00415		ask	AIR FILTER	2
691-00436		ask	COVER	1
691-00453		ask	HOSE	1
691-00519		ask	BRACKET	1
691-00625			26.29 BOLT	5
691-00761		ask	PLATE	2
691-00761		ask	JOINT	2
691-01163			102.72 MOUNTING CLAMP	1
691-01184			346.55 AIR CLEANER	1
691-01313			41.99 HOSE	2
691-01315		ask	PIPE	2
691-01355		ask	WIRE	1
691-01379		ask	BRACKET	7
700-00334			19.33 FUSE	1
750-10055			93.46 PISTON LPA	1
750-10191			154.99 AIR DUCT	2
750-10213			79.43 GOVERNOR LEVER	1
750-10260			57.65 HEAT SHIELD	3
750-10312			24.14 DIPSTICK	2
750-10320			20.88 SPEED CONTROL	1
750-10340			8.46 BRACKET	3
750-10351			76.81 OIL PRESSURE GAUGE	1
750-10401			47.14 OIL SENDER	3
750-10425			24.58 RELAIS	1
750-10430			32.28 CHARGE INDICATION KIT	2
750-10474			24.14 DIPSTICK	3
750-10480			42.37 ADAPTOR	5

750-10490	65.83 OIL BLOCK	3
750-10663	81.91 GOVERNOR LEVER	1
750-10790	250.84 COUPLING	1
750-10800	67.27 COUPLING	1
750-10873	224.64 SILENCER	1
750-11120	16.26 INDICATOR LAMP	2
750-11210	9.37 BEARING LPA/W/S	4
750-11240	9.55 BEARING LPA/W/S	6
750-11250	9.37 BEARING LPA/W/S	1
750-11271	41.20 PISTON RING SET LPA	13
750-11272/050	24.63 PISTON RING SET LPA	4
750-11280	21.67 ROCKER LEVER	1
750-11480	48.35 BRACKET	5
750-11490	44.25 FLEX.MOUNTING	1
750-11581	ask SOLENOID KIT	1
750-11583	71.97 SOLENOID KIT	4
750-11840	59.93 SOLENOID	1
750-12002	71.97 COIL	2
750-12170	235.46 SILENCER	1
750-12250	22.07 DRIVE COUPLING	1
750-12660	21.96 THRUST SLEEVE	1
750-12684	36.22 GOVERNOR WEIGHT	4
750-13120/025	26.39 PISTON RING SET LPW/S	5
750-13392	17.88 RELAIS	2
750-13840	80.82 KEYSWITCH	2
750-14870	19.28 OIL PRESSURE SWITCH	1
750-40092	115.42 PISTON LPWS	4
750-40141	200.12 RADIATOR	3
750-40170	66.97 RADIATOR FAN	2
750-40252	84.13 MOUNTING BRACKET	1
750-40710	43.20 GUARD	2
751-10222	16.86 ROCKER COVER	7
751-10232	3.26 CON ROD BOLT	19
751-10252	5.03 SEALING TUBE	6
751-10330	1.82 SPRING	3
751-10580	11.13 INJECTOR CLAMP	2
751-10590	4.20 O RING	6
751-10771	0.69 GASKET	1
751-10772	0.69 GASKET	2
751-10901	2.02 VALVE GUIDE	4
751-10913	3.92 VALVE SPRING PLATE	3
751-11091	3.33 GOVERNOR WEIGHT	4
751-11110	3.64 SPACER	4
751-11260	0.74 BEARING	1
751-11280	0.97 GOV WEIGHT SPRING	20
751-11810	1.10 WASHER	65
751-11930	6.61 SHIM	9
751-11932	6.61 SHIM	1
751-12230	0.48 FUEL HOSE	5
751-12381	4.89 VALVE INSERT	4
751-12391	4.89 VALVE INSERT	6
751-12460	8.22 EXHAUST VALVE LPA	9
751-12530	4.57 BOLT	2
751-12710	6.29 NUT	8
751-12771	0.73 DOWEL	8
751-12786	2.23 SPRING	1

751-12800	9.76 COVER JOINT	1
751-12823	10.72 THRUST COLLAR	1
751-12870	3.98 OIL FILTER ELEMENT	5
751-12980	8.94 GOVERNOR WEIGHT	12
751-13130	1.64 THRUST WASHER	4
751-13181	1.28 WASHER	10
751-13220	1.75 SPACER	5
751-13390	0.25 HOSE CLIP	8
751-13451	8.54 SPRING	2
751-13452	24.15 SPEEDER SPRING	1
751-13453	17.30 SPEEDER SPRING	1
751-13454	8.54 SPRING	1
751-13455	9.16 SPRING	2
751-13570	1.64 VALVE STEM SEAL	40
751-13971	5.94 RETAINING PLATE	12
751-14000	1.83 SEALING RING	7
751-14470	2.85 PLUG	1
751-14780	44.67 FUEL PIPE	2
751-14880	7.36 PLUG	2
751-15060	1.93 SPRING	1
751-15070	1.75 PIVOT	1
751-15240	23.69 SPEEDER SPRING	2
751-15300	9.40 SPEEDER SPRING	2
751-15460	11.10 GOVERNOR WEIGHT	4
751-15750	5.18 NIPPLE	13
751-15751	10.57 FILTER ADAPTOR	2
751-15872	33.05 NOZZLE	36
751-15874	33.05 NOZZLE	46
751-15940	2.47 THRUST WASHER	1
751-15950	2.83 THRUST WASHER	1
751-16230	ask COIL	1
751-16240	9.98 GOVERNOR WEIGHT	2
751-16611	4.89 SPEEDER SPRING	2
751-16613	4.89 SPEEDER SPRING	2
751-16614	12.23 SPEEDER SPRING	3
751-16620	14.92 BRACKET	1
751-16911	6.47 ADAPTOR	22
751-17560	13.31 BELT	1
751-17620	6.47 CYL HEAD BOLT	8
751-17670	2.40 BRACKET	1
751-17800	1.55 RETAINING PLATE	8
751-17810	15.95 BELT	4
751-17951	0.25 O RING	6
751-18061	0.70 O RING	6
751-18140	11.55 SPRING	2
751-40173	4.12 CYL HEAD BOLT	9
751-40184	5.95 CYL HEAD BOLT	2
751-40192	5.03 SEALING TUBE	8
751-40312	11.36 SPACER	4
751-40312	11.36 SPACER	4
751-40440	3.81 ADAPTOR	1
751-40520	4.94 NUT	4
751-40680	5.49 PLUG	1
751-40853	45.75 FUEL PUMP	2
751-40860	36.83 NOZZLE	2
751-40906	4.99 SPEEDER SPRING	1

751-41011	21.51 DIPSTICK	1
751-41220	2.64 CAP	1
751-41230	1.33 FUEL HOSE	4
751-41263	58.33 FUEL PUMP	1
751-41701	1.54 VALVE STEM SEAL	5
751-43470	4.71 BELT	2
752-13490	87.69 MANIFOLD	1
752-40751	40.27 CYL HEAD GASKET	4
752-40752	18.24 GASKET	1
753-12347	56.88 FUEL PIPE	1
754-10632	93.62 MANIFOLD	1
754-42640	1.65 JOINT	2
754-43731	69.12 FUEL PUMP	2
754-45260	58.97 INJECTOR	2
757-10211	33.63 SENDER	1
757-10301	ask PLATE	2
757-10320	4.57 MOUNTING	6
757-10432	84.13 SUPPORT BRACKET	1
757-10441	33.33 BRACKET	3
757-10491	1.51 REBOUND PAD	2
757-12100	9.88 OIL BLOCK	1
757-12130	23.01 OIL PIPE	1
757-12211	17.32 FUEL PIPE	1
757-12440	16.62 O RING	2
757-12630	21.29 RADIATOR STAY	2
757-12670	4.20 HOOK BOLT	4
757-12871	242.56 TACHOMETER	1
757-13120	ask BEND	1
757-13192	17.77 BRACKET	2
757-13251	148.74 COUPLING	1
757-13631	19.52 RADIATOR HOSE	4
757-13640	8.99 RADIATOR HOSE	2
757-13980	0.31 SCREW	25
757-13990	3.77 CONNECTION PLATE	1
757-14150	0.92 TERMINAL	12
757-14160	0.37 COVER	26
757-14480	1.16 GROMMET	20
757-15230	14.92 AIR FILTER ELEMENT	6
757-15420	12.37 OIL PRESSURE SWITCH	13
757-15690	15.30 BELT	1
757-15710	1.47 FUEL PIPE	1
757-15903	46.97 COIL	2
757-16270	46.64 BEARER	2
757-16410	3.83 CABLE	1
757-16580	12.56 COVER	1
757-16670	49.49 HEAT BAFFLE	1
757-16910	6.54 MOUNTING CAP	4
757-17063	15.40 CABLE LOOM	1
757-17330	3.94 TERMINAL	1
757-17390	7.90 BOOT	12
757-17400	12.32 ADAPTOR	1
757-17420	18.99 SPACER	5
757-17650	10.76 ADAPTOR	1
757-18191	18.93 PUSH/PULL ROD	1
757-18201	ask ROD	1
757-18240	8.60 STUD	2

757-18801	69.62 FUEL PIPE	1
757-19520	5.76 ALTERNATOR PLUG	2
757-19640	134.39 FAN	1
757-19840	25.57 BRACKET	11
757-19860	23.34 PILLAR	11
757-19870	8.48 PILLAR	12
757-19880	5.11 PILLAR	11
757-20790	4.16 BRACKET	2
757-21331	8.24 SHAFT EXTENSION	1
757-22360	0.45 ADAPTOR	1
757-24000	23.80 TEMPERATURE SENDER	2
757-24690	1.29 ROLLER	1
757-24740	1.21 SPACER	1
757-27560	14.18 RADIATOR HOSE	2
757-61471	4.35 HOSE	3
77018/1033	ask PIPE	2
803-02182	12.84 CLAMP	2
803-02186	207.14 WATER PUMP	1
803-02207	158.25 WATER PUMP	2
803-02285	48.58 DIPSTICK	1
804-00356/001	28.40 MOUNTING	8
805-00229	ask BUSH	10
808-40043	ask SKIN FITTING	1
842-00180	12.78 SHAFT	8
842-00322	ask PULLEY	1
842-00322	ask CKUTCH	1
842-00358	6.39 SWIVEL UNION	4
842-00359	12.02 SWIVEL UNION	55
842-00394	1.08 SCREW	9
842-00491/001	0.17 DISTANCE PIECE	9
842-00523	2.32 OIL SEAL	3
854-00059	ask PULLEY	1
854-00110	150.00 COVER	1
854-00124	ask HOSE	1
854-00127	124.40 FLANGE	1
854-00237	21.59 PIPE	1
854-00393	49.62 CHAINWHEEL	1
854-00405	63.25 SUPPORT PLATE	1
854-00408	79.60 SUPPORT PLATE	1
854-00413	155.69 TENSIONER	1
854-00422	ask SHAFT	1
854-00429	ask PIPE	1
854-00526	245.58 BRACKET	1
854-00673	14.42 VALVE SPRING	1
854-00902	1.53 JOINT	2
854-00950	9.58 BEND	1
854-00953	32.64 PIPE	2
854-00992	2.89 HOSE	3
854-00998	9.38 FLANGE	1
854-01056	24.28 PIPE	3
854-01057	15.87 PIPE	1
854-01119	4.95 GASKET	7
854-01156	ask DIPSTICK	2
854-01158	ask PIPE	2
854-01173	96.41 BEND	3
854-01191	25.12 WATER PIPE	2

854-01192	32.16	WATER PIPE	2
854-01194	16.75	HOSE	2
854-01195	4.73	HOSE	3
854-01196	24.07	FLEXIBLE PIPE	1
854-01197	26.54	FLEXIBLE PIPE	1
854-01227	2.26	HOSE	3
854-01230	ask	WATER PIPE	2
855-00021	ask	PULLEY	8
855-12391	68.21	PUMP	1
858-00108	6.85	STUD	14
873-03381	ask	VALVE	6
873-03382	ask	SPRING	2
901-18000	ask	FAN	1
901-18210	ask	COOLER	1
901-18220	12.20	TOP HOSE	1
901-18230	ask	HOSE	1
901-18320	4.00	TOP STAY	1
901-18490	ask	BAND	4
901-19040	11.02	TEMPERATURE SWITCH	1
901-19070	9.93	OIL PRESSURE SWITCH	1
904-21001	929.88	FUEL PUMP	1
950-10033	ask	AIR FILTER	1
950-10081	ask	GUARD	1
970-00450	ask	INJECTOR	1
A 36174	ask		5
A 42382	ask		1
A 62003	ask		1
A 732	ask	PIPE	4
AJB84	ask	SCREW	3
AJE43	ask	PIPE	4
AJE6B	ask	PIPE	3
B-0019	40.96		2
B-0041	4.34	JOINT	6
BRYCE 106-118	0.26	WASHER	5
BRYCE 106-62	0.38	JOINT	5
BRYCE 11-121	0.10	JOINT	983
BRYCE 11-152	2.18	SPRING	2
BRYCE 1-295	1.91	JOINT	4
BRYCE 13-154C	3.41		2
BRYCE 13-158	0.82	PIN	3
BRYCE 1-370	2.50		1
BRYCE 13-82	0.91	JOINT	8
BRYCE 1-496	57.61		2
BRYCE 1-594D	16.15		1
BRYCE 1-74	5.82	BUSH	2
BRYCE 1-86D	14.56		4
BRYCE 51-414	0.06	WASHER	10
BRYCE 51-453	21.52	NUT	1
BRYCE 64-14B	1.71	SHIM	7
BRYCE 64-14G	1.90	SHIM	10
BRYCE 64-14H	1.90	SHIM	10
BRYCE 64-14J	1.90	SHIM	10
BRYCE 64-14K	1.90	SHIM	10
BRYCE 64-14P	1.90	SHIM	10
CAV 100601 C	0.03	WASHER	5
CAV 100836	0.02	JOINT	4

CAV 126064-5	0.11	2
CAV 126065-3	0.14	4
CAV 129981	0.08	6
CAV 188216	0.11 FUSE	1
CAV 188219	0.11 FUSE	3
CAV 19007	0.07	5
CAV 20078	0.06 BUSH	1
CAV 201003	0.07 SCREW	9
CAV 206200	0.38 NUT	1
CAV 20672	0.07 SHIM	7
CAV 20673	0.09 SHIM	4
CAV 23811	6.21 BUSH	5
CAV 23892	1.89 JOINT	9
CAV 24443	40.84 TOOL	1
CAV 25870	0.49	2
CAV 25871	0.15 SCREW	6
CAV 25876	0.85	3
CAV 25883	0.74 SPRING	10
CAV 25884	0.41	1
CAV 25895	0.27 WASHER	8
CAV 25896	0.27 WASHER	5
CAV 25902	0.76 WASHER	2
CAV 25903	0.70 WASHER	9
CAV 25904	0.70 WASHER	7
CAV 25970	1.42 JOINT	3
CAV 26197	0.75 BUSH	1
CAV 26280	2.15 LEVER	1
CAV 26377	6.32 BOLT	4
CAV 26387	0.36	3
CAV 26403	184.92	1
CAV 26512	0.65 NUT	3
CAV 26576	0.19 WASHER	13
CAV 26785	0.21 SCREW	4
CAV 26982	3.12 BUSH	1
CAV 27572	0.36	2
CAV 4402	0.11 SHIM	11
CAV 500361	0.11 JOINT	2
CAV 500644	1.26 SCREW	2
CAV 501438	0.22 SCREW	1
CAV 502070	0.61 SCREW	7
CAV 502220	0.04 JOINT	6
CAV 502706	2.56	1
CAV 503320	0.37 JOINT	7
CAV 503700	15.91 NIPPLE	2
CAV 503701	0.13 JOINT	14
CAV 504875	7.14 SPRING	1
CAV 505155	7.14 SPRING	4
CAV 505253	50.01 CONNECTING ROD	1
CAV 506967	1.15 BOLT	3
CAV 507094	0.40 JOINT	1
CAV 507707	0.12 NUT	4
CAV 514836	ask LEVER	1
CAV 514850	26.26	3
CAV 5330-132	0.02 NUT	15
CAV 5330-183	2.86 NUT	7
CAV 5335-172	ask	5

CAV 5339-256B	ask		11
CAV 5339-308	ask	WASHER	30
CAV 5658-339	ask	NUT	2
CAV 5855-30G	ask	O-RING	163
CAV 5998-22N	ask		2
CAV 7008-428A		0.11	18
CAV 7009-156	ask	SCREW	2
CAV 7010-11		7.60 BUSH	4
CAV 7010-172		1.93 PIN	4
CAV 7010-409		0.30 JOINT	6
CAV 7010-548		1.72 JOINT	2
CAV 7010-549		0.62 WASHER	7
CAV 7016-30	ask	COVER	1
CAV 7017-25	ask	COVER	1
CAV 7032-11		0.86	2
CAV 7032-134A		0.86	3
CAV 7032-16	ask	SPRING	3
CAV 7032-17		5.95	7
CAV 7032-9		1.65	8
CAV 7033-11		1.32	2
CAV 7033-133	ask	NIPPLE	3
CAV 7033-14A		0.95 BUSH	1
CAV 7033-18		1.32 BUSH	1
CAV 7033-26A	ask	BOLT	8
CAV 7033-334		0.62 SPRING	10
CAV 7033-345		1.53	6
CAV 7033-378A		0.46 SCREW	17
CAV 7033-45J		15.61	1
CAV 7097-28A	ask		4
CAV 7112-37		0.43 WASHER	2
CAV 7118-113		0.12 BOLT	1
CAV 7118-12		2.24 NIPPLE	1
CAV 7118-16		1.54 BUSH	5
CAV 7118-17		0.93 PLATE	1
CAV 7118-21		0.48 SHAFT	5
CAV 7118-34		0.89 SCREW	5
CAV 7118-98		0.93 SCREW	2
CAV 7137-147	ask	JOINT	2
CAV 7137-148	ask	JOINT	3
CAV 7244-6A		1.01	1
CAV 7244-6AB		1.01	1
CAV 7244-6AC		1.01	1
CAV 7244-6AD		1.01	1
CAV 7244-6AE		1.01	1
CAV 7244-6AF		1.01	1
CAV 7244-6AG		1.01	1
CAV 7244-6AH		1.01	1
CAV 7244-6B		1.01	6
CAV 7244-6C	ask		1
CAV 7244-6D		1.01	13
CAV 7244-6E		1.01	6
CAV 7244-6F		1.01	7
CAV 7244-6G		1.01	2
CAV 7244-6H		1.01	1
CAV 7244-6K		1.01	1
CAV 7244-6N		1.01	1

CAV 7244-6P		1.01	1
CAV 7244-6Q		1.01	1
CAV 7244-6R		1.01	1
CAV 7244-6S		1.01	1
CAV 7244-6T		1.01	1
CAV 7244-6U		1.01	1
CAV 7244-6V		1.01	1
CAV 7244-6W		1.01	1
CAV 7244-6X		1.01	1
CAV 7244-6Y		1.01	1
CAV 7244-6Z		1.01	1
CAV 87847		0.20 NUT	2
CAV NS 49-8Y1		0.26	1
CRD 11353		15.04	1
CRD 124201		9.71	1
CRD 124601		19.59	1
CRD 21192 A		28.60 COWER	1
CRD.46669	ask	TUBE STACK	1
CSG-7		10.02 BUSH	6
FE34	ask	PIPE	1
FWA 05 2526	ask		1
FWA05-2526	ask	AIR CLEANER	1
H16/39	ask	CAMSHAFT	1
H16/66	ask	CAMSHAFT	1
HB3	ask	COVER	1
HB69	ask	CYLINDER	1
JA155	ask		8
JA62	ask	PIN	3
JC12B	ask	PISTON RING	6
JC52	ask		2
JD51	ask	SHAFT	6
JF6	ask	TAP	2
JG119	ask		4
JG36	ask	LEVER	1
JG76	ask	PIN	2
JL12	ask	DIPSTICK	4
JL12A	ask	DIPSTICK	2
JL13	ask	STUD	1
K 20504	ask		6
K 20614	ask		5
K 22744	ask		50
K 22748	ask		50
K 60600	ask		1
K 60634	ask		4
K 60636	ask	NUT	1
K 60654	ask		3
K 60659	ask		2
K 60675	ask	SPRING	1
K 60681	ask		8
K 60702	ask		13
K 60744	ask		5
K 60759	ask		10
K 60760	ask	WASHER	40
K 60776	ask	MAIN SHAFT	1
K 60808	ask	BOLT	7
K 61135	ask		1

K 61720	ask		3
KB29	ask		3
KL 22714	ask		50
KL 40007	ask		2
M 102	ask	VALVE	2
MIC-10977		0.18	46
MIC-11056		0.57 SPRING	6
MIC-14670		0.57	6
MIC-4096		0.71	1
MIC-4732		30.80	1
MIC-4733		0.36	2
MIC-4734		0.95	6
MIC-4738	ask	BOLT	1
MIC-4948		4.92 WASHER	8
MIC-5326	ask		2
MIC-5603		2.74	4
MIC-5604		4.20	8
MIC-7896		0.47 SPRING	2
MIC-8396		0.57	2
MIC-8883		0.14 SPRING	12
MIC-K19111		0.36 WASHER	3
SA-2858		5.27	6
SA-2968		3.51	4
SA-3054		1.26 SPRING	33
SA-3055		1.26 SPRING	5
TIMKEN 05079		5.82	2
TIMKEN 05185S		4.22	2
VPE21B	ask	PIPE	6
ZPB8	ask	WASHER	2